USER MANUAL / MANUAL DE USUARIO / MANUAL DE USUARIO / MANUEL DE L'UTILISATEUR / MANUALE DELL'UTENTE / BENUTZERHANDBUCH / GEBRUIKERSHANDLEIDING - **SW/19**

INNOVA

Innova Smart Watch

Fitness Snow

Innova Smart Watch

Fitness Snow

Thank you for using our smart watch INNOVA.

Please read carefully the recommendations in this user manual **prior to first use of this product and keep it for future reference. Keep it away from moisture and extreme weather conditions. Do not use in wet or humid environments.**

Avoid contact of liquids, cleaners, mild aggressive agents and solvents with the product. If the product has been in contact with any of these substances, rinse with clean water and dry it with a soft cloth. Do not use any type of electric or electronic heating device to dry the product. Do not use the product if it has been in water or other liquids.

Exposure to temperatures outside the range specified in the technical specifications may temporarily affect the proper operation of the product. Do not place it near sources of heat, flammable materials or explosives.

Do not disassemble, open, crush, bend or deform the product, battery or accessories. Do not pierce the product or battery with sharp objects. Do not drop, throw or shake the product. Improper handling may damage the internal circuits and components.

Do not paint the product or battery. Paint may clog moving parts and prevent proper operation.

Do not place the product or battery in microwave ovens, pressure cookers or on induction cookers. Improper use may cause overheating, explosion or fire.

If the strap is worn too tight, it may cause skin irritation. Wear it loosely and clean it regularly.

Prolonged exposure to heat, sunlight, humidity or moisture may cause discoloration, deformation or damage to the product. Avoid prolonged exposure to these conditions.

If the strap is worn too tight, it may cause skin irritation. Wear it loosely and clean it regularly.

If you wear the device for prolonged periods of time, remove it to give your skin time to breathe.

Do not use the product if the screen is broken, cracked or damaged. Broken glass or sharp edges may cause injury. Contact an authorized INNOVA service center for repair or replacement