说明书：70x90mm

Smart Global Locator

PB08

Azok stamp

Quick Start Guide

Works with Apple Find My

Getting Started

1 power On / Off:
Press AZOK stamp function button once to turn on - it should beep once indicating it is powered onTo power off: hold the same button for at least 3 seconds. You will hear 2 beeps indicating AZOK stamp is powered off

2.Check For Updates:
To use the Apple Find My app or the Find Items app on Apple Watch to locate AZOK stamp, the latest version of ioOS, iPadoS, watchOs or macOs is recommended

Add Your azok stamp

1.Start the App
. Open Find My app on your supported iPhone or iPad.
. Allow notifications from the app

2.Connect AZOK stamp
. Power on azok stamp
. Tap "+ " then "Add Other tem"
. Once azok stamp is located, tap "Connect"
. Choose a recognizable name and emoji for your azok stamp and tap"Continue"
. Find My will ask for confirmation to add your azok stamp your Apple ID - tap "Continue"
Tap "Finish" and your azok stamp will be set up

Locate Your item

1.Find AZOK stamp when it is Nearby
. Open Find My app and select the "Items" tab or Open the Find Items app on your Apple Watch
. Tap on your azok stamp from the list
. Tap"Play Sound" to make your azok stamp beep
. Tap "Stop Sound" to stop the beeps once you find it

2.Find Item Locators Last Known Location
. Open Find My app and select the "Items"" tab or Open the Find Items app on your Apple Watch
. Tap on your azok stamp from the list
. Your azok stamp last known location will appear on the map
. To navigate to that last known location, tap "Directions" to open the Maps app

Find AZOK stamp When Out of Range

1 Enabling "Notify When Left Behind"
. Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch
. Tap on your azok stamp from the list
. Under "Notifications" enable the "Notify When Left Behind "toggle
. You will receive a "notifications" when you leave your azok stamp behind and it's no longer in Range of your device.

2.Enabling "Notify When Found"
. Under "Notifications" enable the "Notify When Found" toggle
. When your azok stamp is seen by another Find My enabled device, you will receive a notification of its updated location
. Note: "Notify When Found"can only be activated when your azok stamp is out of range

When Your item is Lost

1.Enabling "Lost Mode"
. Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch
. Tap on your azok stamp from the list
. Under "Lost Mode" tap"Enable"
. A screen detailing Lost Mode will pop up, tap "Continue"
. Enter your phone number or email address and tap"Next"
. You may enter a message that will be shared with the person that finds your azok stamp
. Tap "Activate" to enable "Lost Mode"
. Note: When "Lost Mode" is enabled, "Notify When Found" is automatically enabled
"Note: When "Lost Mode" is enabled, your azok stamp is locked and cannot be paired to a new device

Resetting Your item Locator

1 Remove the azok stamp from Find My app
. Open Find My app and select the "Items" tab
. Tap on your azok stamp from the list
. Please ensure "Lost Mode" is disabled
. Scroll to the bottom of the screen and tap "Remove Item"
. A summary will open, tap "Remove" to confirm

2. Factory Reset Your Item Locator:
. After successfully removing azok stamp from Find My app,press your azok stamp function button four times rapidly then hold it a fifth time until you hear a ringing chime.
. the azok stamp is now reset and ready to be paired to a new device

But Wait...There's More

1 Replace the Battery:
. Replace the battery with a new CR2032 battery

2Unwanted Tracking Detection:
If any Find My network accessory separated from its owner is seen moving with you overtime, you'll be notified in one of two ways:
(1) If you have an iPhone,iPad, or iPod touch, Find My will send a notification to your Apple device. This feature is available on iOS or iPadOSs 14.5 or later.
(2) If you don't have an iOS device or smartphone, a Find My network accessory that isn't with its owner for a period of time will emit a sound when its moved. These features were createdspecifically to discourage people from trying to track you without your knowledge.

The Fine Print

Use of the Works with Apple badge means that product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safetyand regulatory standards.

@ Apple, Apple Watch, watchOS, iPad, iPadOS, iPod touch, Mac, and macoOs are trademarks of Apple Inc.,registered in the U.S. and other countries. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different
from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction