boAt

NIRVANA ION

Get ready to immerse yourself in musical bliss with your very own pair of boAt Nirvana Ion. Please consider this manual as your guiding map towards the realm of sound bliss. Knowledge of Bluetooth and device connectivity is essential for exploring its depth and therefore we encourage recommend thorough reading of this manual, ensuring you stay safe in the realm of sound when you face any sort of difficulty in future.

PACKAGE CONTAINS

- 1 x Pair of Ion Earbuds
- 1 x Charging Case
- 1 x Type C Charging Cable
- 1 x Pair of Ear Cushions (S/M)
- 1 x User Manual
- 1 x Warranty Card
- 1 x Warranty Card
- 1 x Safety Card
- 1 x Sticker

POWER ON (FIRST TIME USER)

Step 1: To switch the earbuds on (Smart Power On) simply take one or all the charging case (either earbuds are on/off) and take into ANY of the slots in Ion Charging case, making the earbuds to power on automatically, get connected and enter the connection mode.

Step 2: Both the earbuds automatically pair with each other. The earbuds enter into connection mode, indicated and signaling using LED on the inside earbud.

CONNECTION MODE

Step 3: Turn on the Bluetooth functionality on your mobile device & scan Step 4: Select Ion (Single ear / Both ear according)

Successfully Ion TWS earbuds are now connected successfully via Bluetooth

Note:
- During Music mode, if there for 5 minutes, (TWS earbuds) time is minute, then you are asked to reconnect the earbuds and follow the above mentioned connections.
- Unpaired Mode: Remove the earbuds from the charging case and follow the above mentioned connections.
- Disconnection: Turn off the Bluetooth on the mobile device and then on, and earbuds automatically disconnect the Bluetooth connection device.

SINGLE EARBUD USAGE

Step 1: Please ensure that both the earbuds are kept in pairing mode, one (Left) / (Right) Earbud for functioning of the desired earbud.
Step 2: The desired earbud automatically enters into connection mode indicated by slow pulse LED flashes.
Step 3: Turn on Bluetooth on your mobile/tablet device and search for the device (Ion vs. Ion left).

Notes:
- In case of an (Stereo mode, simply take out and the other earbud from ear and it will automatically switch on and pair with the previously selected earbud (Mono usage).
- The earbuds are connected back to the previous device in Mono mode.

QUICK GUIDE ON FUNCTIONALITIES

1 Click	Accepting an Incoming call / Ending an ongoing call / Rejecting an incoming call
2 Tap	Activate Siri on IOS or Google Assistant on Android, Voice Assistant
3 Tap	Play / Pause music, Accept call
3 Tap	Play the last played track, Reject incoming call, Ending ongoing call
4 Tap	Volume up
5 Tap	Volume down
3 Tap & Hold	Switch on Light Mode (Low Latency Mode) for 3 seconds to enjoy an uninterrupted gaming experience
3 Tap & Hold	Switch off Light Mode (Low Latency Mode) for 3 seconds to enjoy an uninterrupted listening experience
3 Seconds	Long press the Right Earbud for 3 seconds to switch on/off the Gaming mode

CHARGING THE EARBUDS

Step 1: Place both the earbuds back inside the charging case in an ear pairing and ensure the case is on.
Step 2: Once the earbuds are fully charged, the charging case automatically switches off its operation.

LED INDICATOR

State	Charging Status
Earbuds - Charging	LED slow pulse
Earbuds - Fully Charged	LED slow pulse OFF

CASE LED INDICATOR, EARBUDS REMAINING BATTERY

- When earbud's capacity is >50%, the charging case LED shows series of seconds interval. The earbuds are taken out or put back into the case.
- When earbud's capacity is 20%-70%, the charging case LED shows series of seconds interval. The earbuds are taken out or put into the case.
- When earbud's capacity is <20%, the charging case LED shows series for 5 seconds interval. The earbuds are taken out or put into the case.

Note:
1. Before using the earbuds for the first time, it is recommended to fully charge the ear buds. This allows them the full of the charging and ensure better energy.

CHARGING THE CASE

Step 1: To charge the case, plug one end of the provided cable into the case and connect the other end to a computer / wall adapter / powerbank, etc.

NIRVANA CASE BATTERY INDICATOR

When earbuds are outside the case and the case is open:
- Charging Status: LEDs will LED blinks 4 times.
- In the battery 80%-100%, will LED blinks 3 times.
- In the battery >70%, will LED blinks 2 times.
- In the battery <70%, will LED blinks 1 time.
- In the battery <10%, charging, the case LED stays solid green for 5 seconds.

BASIC FUNCTIONS

- Voice Assistant: Tap the right earbud's touch control 2 times to activate default voice assistant.
- Answer Call: Put an active earbud in ear or incoming call.
- Hang Up Call: Double tap the CTC on either earbud.
- Reject Call: Double tap the CTC on either earbud.
- Play/Pause Music: Put an any earbuds in ear, a single tap/pause music when from your ear to pause play. The in-ear detection feature triggers a earbud play or pause.

OR

Single tap on either earbud's CTC to play or pause music.
- Next Track: While playing music, double tap the right earbud's touch control to go to the next song.
- Previous Track: While playing music, double tap the left earbud's touch control to go to the previous song.
- Volume Up: 3 tap on right earbuds increase volume by 20%.
- Volume Down: 3 tap on left earbuds decrease volume by 20%.

CRYSTAL SOUND SOUND WITH DUAL EQ

boAt Ion is a sound earbud with Crystal Sound Technology (qualcomm aptX enabled).

You can choose a mode at the top EQ modes. A. Bass mode for more bass sound enhance experience and for a comfortable and secure experience. Bass mode that an earbud sound tailored to a special or change the frequency.

SMART™ MODE

Switch on the boAt earbuds touch control for 2 seconds to switch the ear pairing mode from bass to the BASS EQ Mode. Hear from the earbud's. By default, BASS EQ Mode. Bass is the sound that Powers and improve the sound quality experience. After BASS EQ Mode, the earbuds provide one sound. Crystal sound EQ Mode for earbuds.

To change the SMART™ mode is a bass to standard mode, a bass mode to a standard mode.

Mic™ TALK

boAt Ion's Mic™ talk feature allows a professional quality call experience. Both ear-bud earbuds have built-in mics and Bluetooth connectivity. Mic™ talk feature allows a crystal call experience.

Calling from your earbuds can be a challenging task. With noise cancelling, your voice sound clear and audible.

SMART POWER OFF

Step 1: While usage, remove both the earbuds from your ears.
Step 2: Place the earbuds back into the charging case in random orientation and close the case lid.
Step 3: The earbuds are automatically switch off (and enter charging mode).

FACTORY RESET

Perform the Factory Reset if you are facing any difficulty while operating your Ion ear bud.

Only for Battery performing mode: Open "Ion ear bud" from pairing device history by forgetting device.

Step 1: Place the earbuds inside the case.
Step 2: Take the earbuds out, make the case lying down and open the Bluetooth. The earbud enters into mode for 10 seconds, and the LED flashes 5 times on the earbuds as well as the case.
Step 3: Close the case lid, wait for 5 seconds and then remove it again.

Unsuccessful: Your Ion ear bud Reset, now you may perform a hard reset and connection to Bluetooth connection.

WARNING

- Please read the instructions in capsule.
- Please don't use the earbuds in extreme temperature.
- Please don't use the product near water.
- Please keep the product away from heat sources, as the heat may damage it.
- Don't use the product in a damaged port / USB port, etc.
- It is recommended to store the product when you are not using it in order to protect hearing and avoid the ear buds' aging life.

Available: The earbuds can at a 30% volume and it may need to be repaired when the earbuds are connected to a mic.

TROUBLESHOOTING

Potential Problem	Solution
Wireless earbud is not working	Perform the Factory Reset
Earbuds are not in connection mode	Perform the Factory Reset
Unable to pair	Perform the Factory Reset
Earbuds automatically stop playing music	Charge the earbuds or perform the Factory Reset
Earbuds are never recognized in usage	Place the earbuds back into the charging case and try using them again or perform the Factory Reset
While Touch Controls don't seem to respond	After long usage, earbud need a recalibration call. Utilize the touch control while inside case a clear cloth to clean the ear sensor.

DESCRIPTIONS

Bluetooth Chip	QCC3040
Bluetooth Version	V5.2
Bluetooth Profile	A2DP, AVRCP, HFP, HSP
Bluetooth Range	10 Meters
Frequency Response	20 Hz - 20 KHz
Charging Port	Type-C
Charging Time	1.5 Hours (Case) & 1.5 Hours (Earbuds)
Playtime	Upto 4 Hours (Earbuds) & Upto 20 Hours (Case)
Charging Case	Yes
Voice Assistant	Yes
Call Function	Yes
Mic	Yes
Mic Type	Dual
Touch Control	Yes
Touch Control Type	Yes
Water Resistance	IPX4
Earbuds Size	20.7 x 23.1 x 22.8 mm
Earbuds Weight	4.5 Grams
Case Size	65.1 x 44.1 x 27.3 mm
Case Weight	45.5 Grams
Driver	6 mm
Case Material	ABS