产品质保(Product Warranty)

感谢您对我们客户产品的信任!为此,我们立即提供此用户手册,以帮助您顺利安装,设定及使用产品。我们相信,您将会享受到我们高品质的产品。

1.保修有效期:自购买日起两年内。

2.保修内容:按照您计算机正确使用要求提供免费技术支持。

3.产品不保修范围:

a.因使用不当,自行拆卸,改装,自行维修,保养,滥用等原因造成的;

b.因外力因素造成的产品外观损伤(如:刮花,变形,变色,脱漆,烧焦,碰伤,进水等);

c.因未按产品说明,操作,维护,保养,安装,使用,储存,运输等原因造成的;

d.因未经授权擅自拆卸,改装,维修,测试,安装,使用,储存,运输造成的;

e.因不可抗力因素造成的产品故障,产品丢失;

f.超出保修期产品不在保修内容范围内(如:键,轴,电子元件等);

g.人为因素导致产品不在保修内容范围内(如:键,轴,电子元件等);

h.其他由产品引,起,的,其,他,直,接,间,接,偶,然,性,的,原,因,造,成,的,产,品,故,障,问,题,不,在,保,修,范,围,内。

质保卡(Warranty Card)

产品型号:

购买日期:

客户姓名:

联系电话:

联系地址:

*本保证书是产品在正常使用情况下,提供技术支持,维修,或更换产品的依据。

*此用户手册用,不为其他情况公示可变更条款。

尊敬的

AJAZZ-AK870

客户

了解更多产品信息请关注

微信公众号:请搜索"AJAZZ键盘专家"

抖 音 号:请搜索"2903903212"

地址:深圳市宝安区沙井街道新桥工业区

Address: Industrial Zone, Xinqiao Street, Shajing Town, Bao'an District, Shenzhen

邮编:518104 CHINA

邮件服务:CS@7.AMKO.2018

目 录

CATALOG

中文 1-10

English 11-20

Indonesia 21-31

非常感谢您选购了我们AJAZZ系列产品,这款产品是各电脑游戏电竞玩家,电竞爱好者和商务办公人士,提供高品质的键盘。

1.产品参数

产品名称:黑鹏AK870 PLUS

产品型号:黑鹏AK870 PLUS

键盘形式:108键标准键盘

驱动类型:键盘驱动程序(Type-C接口)

产品尺寸:370x136x22mm

产品重量:≈1010g

电池容量:8000mAh

产品颜色:Gunkhole(灰)

工作电流:≤0.12A

线材长度:1.5M

打光效果:RGB,256级灯效

键盘布局:104键+功能键盘+独立全屏时间/温度/日期/时间/星期显示屏

按 键:全键无冲

适用系统:Windows Vista/7/8/10/11, MAC

2.Indicator/Sleep Mode Description

1."Caps"Caps lock indicator light

Press Caps lock and the indicator light Press Caps lock and the white light will stay on to indicate that uppercase is turned on. Press Caps lock again and the white light will go out to indicate that lowercase is restored.

2.Display on the screen: Press the Caps lock icon to light up to indicate that uppercase is turned on, and press Caps lock again to turn it off to indicate that lowercase is restored.

2."Wireless"Wireless indicator light

1. Key indicator light (Win key): When Fn+Win is pressed, the white light of the Win key is always on, and when pressed again, the white light goes out to indicate unlocking.

2. Display on the screen: When you press Fn+Win, the text light on mode is displayed in red, and when pressed again, the text goes out to indicate unlocked.

3."Fn key"-battery indicator light

1.Charging indicator light (Fn key):

a.Low battery status: The low battery indicator "Fn key" flashes red.

b.Charging status: The Fn key lights up in red when the battery is being charged.

c.Full power status: The red light of the full power indicator "Fn key" goes out, and the light follows the system.

1. The battery icon displays on the screen:

a.Low battery status: The battery icon on the screen displays 0 bars.

b.Charging status: The icon displays five grids with a lightning logo next to it.

c.Fully charged status: The icon displays five grids.

4.✱/☀"RGB streamer indicator light

Press Fn+SEL to turn off the light, and press again to turn it on. It can fly battery default.

3.Power-saving sleep state (level 1 sleep)

The keyboard backlight will turn off after 5 minutes of no key operation. Press any key to wake up the keyboard backlight and connect back to BT1/2/3/4G.

4.Deep sleep state (secondary sleep)

The keyboard will go into deep sleep, after 30 minutes of no key operation. BT2/3/4G will be disconnected and sleeping. Press any key to wake up the keyboard backlight and reconnect to BT2/3/4G.

3.Mode/system switch description

1.Mode switching key

①: Mode toggle switch (left): BT mode

②: Mode toggle switch (middle): USB wired mode

③: Mode toggle switch (right): 2.4G mode

2.Two-speed system cutting light switching

1.Two-speed system switch (Windows/Mac/iOS/iPad/Android/Delete default)

2.System toggle switch (Delete): Mac system mode

4.Lighting mode description

FN+[]: Light effect switching, 20 kinds of light effects cycle in sequence

FN+'-': Light brightness + (six levels, default factory brightness level when adjusted to the limit, the current backlight flashes 3 times.

FN+'=': Light brightness - (sixth level): is adjusted to the limit, and the overall backlight is turned off.

FN+←/→:Light effect direction adjustment (press once to go left, press again to go right)

FN+↑/↓:Adjust the backlight color (the order is: RGB red-orange-yellow-green-cyan-blue-purple-white RGB)

FN+,:Light speed - (sixth gear, factory default: three gears) when adjusted to the limit, the overall backlight flashes 3 times.

FN+.:Light speed + (sixth gear): is adjusted to the limit, the overall backlight flashes 3 times.

FN+0/Ins:Press to turn off the three lights at the bottom of the screen, then press to turn them on (a fly factory default).

FN+1:Turn off the lights on the screen.

FN+Space/F:Press and hold for 3 to 5 seconds, the keyboard backlight will flash 3 times, and the factory settings will be restored.

FN+Backspace:Press the FN+BACK key combination (supports 2.4G/BT mode), the backlight goes out, and the number keys 1 to 0 light up to display the battery percentage. (For example: 1 on means 10% battery, 2 2 on means 20%)

Turn on light according mode:

1. FN+[]:Q8:Three sets of game lighting effects can be customized

2. FN+[]:Default FN+Mode: W/A/S/D/↑/←/↓/→

3. FN+[]:Default US: Header Q/W/E/R/T/Y/U/I/O/S/D/F/G/H/J/K/L/Z/X/C/V/B/Space/1-4/Enter

4. FN+[]:Default US: Header A-Z,0-9,English letters,[/],/,/,/,