hornbill Smart Lock

Detailed Instructions of TTLock App

Download TT Lock App & Register

3:21

Register

Email   Phone

✉ Enter your Email

🔑 Password

🔑 Confirm Password

Verification Code   Get Code

Your password must have 8-20 characters, and include a minimum of two types of numbers, letters and symbols

Register

By Registering you agree to our Privacy Policy

3:21

Register

Email   Phone

Country/Region   United States+1

👤 Enter your Phone number

🔑 Password

🔑 Confirm Password

Verification Code   Get Code

Your password must have 8-20 characters, and include a minimum of two types of numbers, letters and symbols

Register

By Registering you agree to our Privacy Policy

Pair Your Phone with Smart Lock

TTLock

+

The Phone needs to be within 2 meters of the Smart Lock during the Pairing process.

Choose Lock Type

All Locks
Scan all types of locks

Door Lock | Padlock

Safe Lock | Lock Cylinder

Parking Lock | Bicycle Lock

Remote Control

**Nearby Locks**

M203T_2eb76a

M203T_94e092

+

Note:

1. Please wake up the keypad of the smart lock when you add it.

2. The first device which added the lock will possess administrator permission.

*If you cannot add the lock into app (all gray even if touch the keypad), please reset the smart lock or contact customer service.

Generate Passcode

Manage Passcode

Note:
The system will generate an 8-digit passcode randomly, and click "Passcode" to change it to the 4-9-digit passcode as you like. (The first random passcode should be used on the keypad once before modification)

Send eKey

Note:
The recipient should download the TT Lock app and register their own account. They can lock/unlock on the app after received the eKey.


*Home Page of the eKey Recipient

Authorized Admin

Note:
The recipient should download the TT Lock app and register their own account.
They can generate or modify the passcode on the app.

*Home Page of the Admin Recipient

Manage eKey & Admin

Records

# Settings--Admin Passcode

Note:

1. The admin passcode can be changed as you like.

2. When all generated passcodes are deleted, you can use the admin passcode to unlock.

Settings--Auto Lock

Settings	
Basics	>
Wireless Keypad	>
Remote Unlock	Off >
Auto Lock	Off >
Passage Mode	Off >
Lock Sound	On >
Tamper Alert	Off >
Privacy Lock	Off >
Reset Button	On >
Door opening direction	>
Lock Clock	>
Diagnosis	>
Upload Data	>
Import from another lock	>
Firmware Update	>
Attendance	
Unlock Notification	

Delete

Auto Lock	Save
Auto Lock	
Current Setting	5s >

The lock willl lock automatically after the time. Please unlock it for one time first to make the setting available.

| Cancel	Time	OK

15s
30s
60s
Custom

## Note:

Customize auto-lock time on the app, the smart lock will auto-lock after you close the door.
(It will still lock even if the door is not closed.)

Please click "save" after setting.

Settings--Touch to Unlock

Note:

Why my lock will unlock when I just input one number on keypad?

Please open the app and click the upper right 'three bars' >click 'Settings'> turn off 'Touch to Unlock'.

Customer Service

If you have any further questions about the lock or app, please feel free to contact us.

Email: ruilink@boilli.com

Thank you for your support!!!