bloody

QUICK START GUIDE

GPW70

2.4G Wireless RGB Gaming Controller

WHAT'S IN THE BOX

KNOW YOUR PRODUCT

- Home Button
- Turbo Button
- Clear Button
- Profile Button
- Start Button
- LED Button
- LED Indicator
- 3D Left Joystick / LSB
- D-Pad
- 3D Right Joystick / RSB
- Left Button
- Left Macro Button (M5)
- Right Macro Button (M6)
- RGB 3.5mm Port
- Right Button (M4)
- Left Button (LB)
- Right Trigger (RT)
- Left Trigger (LT)
- USB Type-C Port
- Reset Button

BUTTON FUNCTIONS

Function	PC/X-Input	PC/X-Input	Android	Switch	PS3
Home	Home	Home	Home	Home	Home
Turbo	Turbo	Turbo	Turbo	Turbo	Turbo
Clear	Clear	Clear	Clear	Clear	Clear
Profile	Profile	Profile	Profile	Profile	Profile
Start	Start	Start	Start	Start	Start
LED	LED	LED	LED	LED	LED
LB	LB	LB	LB	L	L1
RB	RB	RB	RB	R	R1
LT	LT	LT	LT	ZL	L2
RT	RT	RT	RT	ZR	R2
M4	M4	M4	M4	M4	M4
M5	M5	M5	M5	M5	M5
M6	M6	M6	M6	M6	M6
Up	Up	Up	Up	Up	Up
Down	Down	Down	Down	Down	Down
Left	Left	Left	Left	Left	Left
Right	Right	Right	Right	Right	Right
A	A	A	A	B	Cross
B	B	B	B	A	Circle
X	X	X	X	Y	Square
Y	Y	Y	Y	X	Triangle
L3	L3	L3	L3	L3	L3
R3	R3	R3	R3	R3	R3
Back	Back	Back	Back	Back	Back

WIDE COMPATIBILITY

Note: You can only choose one mode to connect with the Controller. Can not operate different modes at the same time.

CONNECTING 2.4G DEVICE

Power On:

1. Plug the 2.4G USB Receiver.
2. Press the Home Button to turn on the Controller.
   The LED indicators light up once the Controller is turned on.

Power Off:

Long press the Home Button for 3s to turn off the Controller.

Note:

You can plug in the cable to charge the Controller if low battery during game playing.

CONNECTING WIRED DEVICE



1. Plug the cable to the Controller and Computer.
2. Press the Home Button to enter Wired Mode, otherwise, it will be in charging mode.
3. The LED indicator lights up once the Controller is connected.

Note:

The Controller will prioritize connecting to 2.4G mode by default. If you plug in the cable and 2.4G Receiver at the same time, the wired function will be just in charging mode.

LED INDICATOR

Platform Mode	LED Name	LED Location	How to Connect
PC/X-Input	LED-2		Plug and Play
PC/X-Input	LED 1 + LED 2		Press Home Button for 3s to switch to PC/X-Input
Andoid	LED-3		Plug and Play
Switch	LED-1		Plug and Play
PS3	LED-1		Plug and Play

CONNECT WITH PC PLATFORM

PC/X-Input Mode

1. Plug the 2.4G Receiver to the PC.
2. Press the Home Button to turn on the Controller.
3. The LED indicator flash when pairing.
4. The LED 2 lights up once the Controller is connected.

Mode Exchange (PC/X-Input to PC/D-Input)

1. Long press the Home Button for 3s to turn into PC/D-Input. The LED-1 & LED-2 light up.
2. Long press the Home Button for 3s again to back to PC/X-Input. The LED 2 lights up.

CONNECT WITH ANDROID PLATFORM

1. Plug the 2.4G Receiver to the Android Device.
   Note: Some Android OTG may not be compatible with Android v7.x and above devices. For OTG compatibility, please contact the manufacturer of your Android device.
2. Press the Home Button to turn on the Controller.
3. The LED indicator flash when pairing.
4. The LED 3 lights up once the Controller is connected.

The OTG adapter is for demo only, not included in the package.

Change to Mouse Mode:

Under this mode, you can change the Controller to Mouse Mode: Long press and hold the Home and LB Button simultaneously.

The LED 3 & LED 4 light up. Repeat the same steps to return to the default function.

CONNECT WITH NINTENDO SWITCH

1. Turn on the "Pro Controller Wired Communication" in the console.
   System Settings > Controllers and Sensors > Pro Controller Wired Communication > On
   Note: The "Pro Controller Wired Communication" must be turned on before connecting the Controller to the Switch via 2.4G USB Receiver.
2. Plug the 2.4G Receiver into your Nintendo Switch console.
3. The LED indicators flash when pairing.
4. The LED-1 lights up once the Controller is connected.

Note: No Sensor Function and Capture Button in the Switch platform.
In the Switch platform, Button "A" & "B" Exchanged, Button "X" & "Y" Exchanged, Button "Back" change to "-", Button "Start" change to "+".

Audio Function

Under this mode, you can connect a headset or a microphone to the AUX 3.5mm Audio Port.

CONNECT WITH PLAYSTATION 3

1. Plug the 2.4G Receiver to your PS3.
2. Press the Home Button to turn on the Controller.
3. The LED indicators flash when pairing.
4. The LED 1 lights up once the Controller is connected.

3D JOYSTICK AND D-PAD SWITCHING

You can exchange the D-Pad function to the 3D Left Joystick function by pressing the Clear Button and LT Button simultaneously.
Repeat the same steps to return to the default function.

ADJUST VIBRATION INTENSITY

1. **Increase the Vibration Intensity:**
   Long press and hold the Profile Button then slide up the RT Right Joystick.
2. **Decrease the Vibration Intensity:**
   Long press and hold the Profile Button then slide down the RT Right Joystick.

TURBO & CLEAR FUNCTION SETTING

Enable Turbo Setting:

1. Press and hold any one or more buttons from A/B/X/Y/LB/RB/LT/RT, then press the Turbo Button to save the turbo function.
2. You may only set one of the combination buttons at the time.
   Note: Turbo Speed is fixed at 20 times per second.
3. For example: If you like to set Button B to the Turbo function, first press and hold B Button, then press the Turbo Button. If you like to set the combination buttons B + RB, first press and hold B Button and hold Button RB, then press the Turbo Button. Repeat the for all the buttons you like to set.

Adjust Turbo Speed:

Increase the Turbo Speed:
Long press and hold the Turbo Button then slide right the RT Right Joystick.

Decrease the Turbo Speed:
Long press and hold the Turbo Button then slide left the RT Right Joystick.

Disable Turbo Setting:

Press two or more buttons with Turbo function, then press the Turbo Button to clear the Turbo Setting.

To clear all the previously set Turbo Settings, you need to clear them one by one.
Repeat the steps until all keys are cleared.

CUSTOMIZE ML/MR MACRO BUTTONS

The macro setting can be programmed to the function buttons and joysticks.
Includes: A/B/X/Y/LB/RB/LT/RT/D-Pad/3D Joysticks/Joystick Buttons

Set the Macro Function:

1. Press and hold the M5 or M6 Button for 3s, the LED-2 & LED-3 flash slowly.
2. Press the function buttons that need to be recorded as macros.
3. Press the M5 or M6 Button again to save the setting.

Clear the Macro Setting:

1. Press and hold the M5 or M6 Button for 3s, the LED-2 & LED-3 flash slowly.
2. Press the M5 or M6 Button again to clear the setting.

RGB LIGHTING EFFECT SETTING

RGB Light On/Off
Press and hold the Profile Button for 3s to turn on / off the RGB Backlit.

Change Lighting Effect
Lighting Effects: **Breathing**, **Solid**, **Breathing Cycle**, Lighting Colors: **Red**, **Green**, **Blue**, **Cyan**, **Magenta**, **Yellow**, **White**

Zone 1 Lighting Location:
Change Effect: Press and hold the Profile Button then press the D-Pad Left / Right Button to adjust lighting effect.

Change Color: Press and hold the Profile Button then press the D-Pad Left / Right Button to adjust lighting color.

Zone 2 Lighting Location:
Change Effect: Press and hold the Profile Button then press the Back Button to adjust lighting effect.

Change Color: Press and hold the Profile Button then press the Back Button to adjust lighting color.

CHARGING/LOW BATTERY INDICATOR

Flashing red light indication when the battery is below 10%.

Playtime:
Up to 13 Hrs (Vibration & Light Off)
Up to 7 Hrs (Vibration & Light On)

Sleep Mode:
The LED indicator will turn off and the Controller goes to sleep after 5 minutes of no usage.
Note: You can press the Home Button to wake up the Controller.

SPECIFICATIONS

Connection:	2.4G Wireless + USB Wired
Operating Range:	Up to 10 m
Receiver:	USB Receiver
Supported Platform:	PC, Android, PS3
Buttons:	2 Zone RGB
Trigger Type:	Linear Hall Magnetic Induction Trigger
Macro Buttons:	ML, MR
ACR Port:	3.5 mm
Battery Type:	1000mAh Lithium Battery
Charging Time:	2.5 Hours
Playtime:	Up to 13 Hrs (Vibration & Light Off) Up to 7 Hrs (Vibration & Light On)
Type-C Charging Cable:	1.5 m
Size:	156 x 106 x 58 mm
Weight:	293 g
Color:	Sports Black, Sports White

bloody

www.Bloody.com

Scan for E-Manual