RAPID SET™ SYSTEM

INSTALLATION INSTRUCTIONS

Do not remove side wood stabilizers until anchored to concrete.

Attach rigging with spreader bar to lifting eyes

⚠ CAUTION

STAY CLEAR FROM SUSPENDED LOAD

LIFTING EYE CAPACITY: 700lbs combined max

Place Rapid Set on concrete pad.



⚠ WARNING!

Tip Over Hazard

Anchor Rapid Set to the concrete pad

Only use specified anchor bolts, 4 bolts required

- 0.5 DIAMETER WEDGE ANCHOR, ICC APPROVED,
  MINIMUM TENSION CAPACITY OF 3000 LBS



Remove side wood stabilizers



* Some models do not include the sunshield.



		NAME	DATE
UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN INCHES	DRAWN	X.XXXXX	XX-XX-XX
TOLERANCES: ANGULAR: MACH - ±2° BEND - ±2° TWO PLACE DECIMAL - ±0.01 THREE PLACE DECIMAL - ±0.005	CHECKED		
	ENG APPR.		
	MFG APPR.		
INTERPRET GEOMETRIC TOLERANCING PER:	Q.A.		
MATERIAL: SEE NOTES	COMMENTS:		
FINISH			
DO NOT SCALE DRAWING			

PROPRIETARY AND CONFIDENTIAL
THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF SJE. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF SJE IS PROHIBITED.

TITLE:
RAPID SET V1-122

SIZE	DWG. NO.	REV
B		01

SCALE: 1:1 | WEIGHT: | SHEET 1 OF 1

Manufactured by: SJE Inc.
Technical support: +1-800-746-6287
techsupport@sjeinc.com

www.csicontrols.com www.primexcontrols.com www.sjerhombus.com

© 2020 SJE, Inc. All Rights Reserved. PN 1067842C 11/24