

English Русский язык
한국어 ประเทศไทย
Português France
Español Українa
Deutsch Indonesia
Italian

Functions and Indicators

Product features

Stylish design with Gasket construction and a fine, soft and flexible feel
Keycaps and mechanical switches are pluggable.
4000mAh*2 large-capacity lithium battery can be recharged, with power switch, environmental protection and energy saving, saving worry and money, effectively extending battery life.
FN+[] key combination to switch between 15 RGB light effects
With the drive with music rhythm RGB lighting effect, there are 5 lighting effect modes to choose from under this lighting effect.
Cooperate with the drive keys with custom functions and macro definitions.
Humanized design of the keyboard, adding a series of commonly used shortcut

Specifications

Connection: Type-C wired & 2.4G wireless & BT
• Number of keys: 99 keys
• Pluggable mechanical switch
• RGB switchable lighting effects
• Lithium battery: rechargeable lithium battery4000mAh*2
• Charging voltage/current: DC 5V/830mA
• Rated voltage: DC 3.7V
• Dimensions:390,63(L)x146,78(W)x42,57(H) ±0,5mm
• Weight: 1183g
• Operating system: WIN XP7/8/10/Android/IOS/MAC

Description of shortcut keys (you have to switch to the corresponding mode FN+ ~/1/2/3 in the upper left corner to be able to long press on the code)

Fn+	ESC	~`	1	2
Combination Function	restore the default	2.4G	BT 1#	BT 2#
Fn+	3	Q	W	E
Combination Function	BT 3#	Android	Windows	Mac
Fn+	R	\\|	TAB	↑
Combination Function	IOS	Lighting mode switch	Colour switching	Brightness+
Fn+	↓	←	→	WIN
Combination Function	Brightness-	Speed-	Speed+	Lock WIN
Fn+	Shift-R	/ ?	B	Alt-R
Combination Function	Switching RGB ambient light bar mode	Switching RGB ambient light bar colours	Switch RGB ambient light bar to power mode	Cycles the brightness of the RGB ambient light bar
Fn+	Ctrl-R	DEL	U	I
Combination Function	Cycle through RGB ambient light bar speeds	INS	PRTSC	SCRLK
Fn+	O			
Combination Function	PAUSE			

FN+Q=Android system (Q button red light flashes for 3s), F area single press function and F area FN combination function.

Key	F1	F2	F3	F4	F5	F6
Single press	Screen brightness-	Screen brightness+	Convert window	Return to Desktop	Brightness-	Brightness+
Fn Combination	F1	F2	F3	F4	F5	F6
Key	F7	F8	F9	F10	F11	F12
Single press	previous	Play/Pause	Next song	Mute	Volume -	Volume+
Fn Combination	F7	F8	F9	F10	F11	F12

FN+W=Windows system (W key red light flashes for 3s), F area single press function and F area FN combination function.

Key	F1	F2	F3	F4	F5	F6
Single press	F1	F2	F3	F4	F5	F6
Fn Combination	homepage	email	Convert window	Open Explorer	Brightness-	Brightness+
Key	F7	F8	F9	F10	F11	F12
Single press	F7	F8	F9	F10	F11	F12
Fn Combination	previous	Play/Pause	Next song	Mute	Volume -	Volume+

FN+E=Mac system (E button red light flashes for 3s), F zone single press function and F zone FN combination function.

Key	F1	F2	F3	F4	F5	F6
Single press	Screen brightness-	Screen brightness+	Convert window	Return to Desktop	Brightness-	Brightness+
Fn Combination	F1	F2	F3	F4	F5	F6
Key	F7	F8	F9	F10	F11	F12
Single press	previous	Play/Pause	Next song	Mute	Volume -	Volume+
Fn Combination	F7	F8	F9	F10	F11	F12

FN+R=IOS system (R key red light flashes for 3s), F-zone single press function and F-zone FN combination function.

Key	F1	F2	F3	F4	F5	F6
Single press	Screen brightness-	Screen brightness+		Return to Desktop	Brightness-	Brightness+
Fn Combination	F1	F2	F3	F4	F5	F6
Key	F7	F8	F9	F10	F11	F12
Single press	previous	Play/Pause	Next song	Mute	Volume -	Volume+
Fn Combination	F7	F8	F9	F10	F11	F12

Operating instructions

2.4G mode: the upper left switch is dialled to 2.4G mode, the cyan light of the ~ key blinks slowly, and then press FN+ ~ key for 3 seconds to enter the code pairing state, then plug in the receiver to finish the code pairing, the cyan light of the ~ key is on for 2s, the 2.4G connection is successful. The factory default has been pairing code.

BT Mode: Top left switch toggle to Bluetooth mode BLE5.0/BLE3.0 (device name AULA-F99 3.0/AULA-F99 5.0), can connect 3 devices:
FN+1=BT 1, the blue indicator light under the key is flashing fast, back to the connection is flashing slowly, the blue light is on for 2s when connected,
FN+2=BT 2, the blue indicator light under the key is fast flashing, back to connect slow flashing, connect to blue light 2s,
FN+3=BT 3, the blue light under the key is flashing fast, back to connect the slow flash, connect the blue light 2s.

Wired mode: Top left switch to centre position = wired mode, white light on "4" button lights up for 2s

Fn+Esc long press for three seconds = Restore default. The originall connected BT device save will not be cleared.
FN+Shift-R=Switch light bar light mode, FN+/? = switch light bar colour; FN+Alt-R = light bar brightness cycle, FN+Ctrl-R = light bar speed cycle.
Fn+↑=Brightness+ Fn+↓=Brightness- Fn+←=Speed- Fn+→=Speed+.
FN+Q=Android, FN+W=Windows, FN+E=Mac, FN+R=IOS.
Fn+Tab=Toggle light effect colour.
Fn+WIN-L=Lock/open left WIN window key (Lock WIN indicator light is always on when locking WIN, under WIN system).
After switching to Mac/IOS system, WIN-L/ALT-L position is swapped (without locking WIN).
FN+B=RGB ambient light bar can show keyboard power level, charging streaming light display. Full long bright green, 5 lights each green light indicates 20% battery, Low battery all red indication.

soai
Dongguan Suoai Electronics CO.,LTD
www.aulastar.com
SOAI Industry Park,Huayu Street Changlong Village Huangjiang Town Dongguan City Guangdong Province
Execution Standard:GB/T 14081-2010
Made in China

ИНСТРУКЦИЯ ПО ПРИМЕНЕНИЮ

Пожалуйста, прочитайте инструкцию перед первым использованием.
Спасибо за выбор продуктов AULA.

Компьютерные Клавиатура и мышь – основные устройства управления компьютером, предназначены для ввода данных (могут быть проводными или беспроводными (2.4 Гц с передатчиком в комплекте или Bluetooth без передатчика)).

Компьютерная гарнитура является устройством ввода/вывода данных, предназначена для ввода данных (голоса) посредством микрофона и для вывода данных через наушники. (Могут быть проводными и беспроводными (2.4Гц, Bluetooth, 2.4Гц+ Bluetooth).

Коврик для компьютерной мыши необходим, чтобы обеспечить хорошее сцепление с поверхностью и добиться оптимального скольжения мыши. Коврик устанавливается на поверхности стола, мышь помещается сверху.

Стенд/Подставка для ноутбука/планшета необходима для размещения устройства под удобным углом для работы/игр и дополнительного охлаждения.

Колонки 2.0/2.1 предназначены для воспроизведения музыки и других аудио файлов, подключается к ПК, ноутбукам, планшетам, смартфонам через разъем 3.5 мм, питаются от USB.

USB хаб - это устройство, позволяющее подключить в 1 порт Type-C ряд устройств, таких как: устройства ввода, накопители памяти, дополнительные мониторы и проводной интернет.

Подробные характеристики товара находятся на сайте www.aulagaming.ru

Подключение:

Аккуратно распакуйте изделие. Разместите на столе, подключите к компьютеру, к свободному порту USB (видеокарьеру (для гарнитур)/ колонок) и проверьте работоспособность.

Изготовитель: DONGGUAN SUOAI ELECTRONICS CO.,LTD Address: NO.1 HUAYU STREET,CHANGLONG VILLAGE HUANGJIANG TOWN,DONGGUAN CITY, Дистрибьютор/импортер: ООО «ЕВРОТРЕЙД» Адрес: 142703, Российская Федерация, г. Видное, ул. Ленинградская, д. 1, стр. 1, пом. 1, ком. 1 Продукция соответствует требованиям технических регламентов Таможенного союза: ТР ТС 004/2011 «О безопасности низковольтного оборудования», ТР ТС 020/2011 «Электромагнитная совместимость технических средств», ТР ТС 037/2016 «Об ограничении применения опасных веществ в изделиях электрического и электронного оборудования». Для комфортного использования, а также для ТР ТС 020/2011 «Электромагнитная совместимость технических средств» (для сертификата, Bluetooth 5.0 и ниже) рекомендуется использовать на расстоянии не менее 1 метра от других электронных устройств. Сертификат соответствия № ЕАЭС RU C-CN.АЮ73.В.00125/24 Срок действия с 17.01.2024 по 16.01.2029 Орган по сертификации Общество с ограниченной ответственностью «Центр Инновационных Технологий» Аккумуляторы, встроенные в изделие, не подлежат замене. Для полной зарядки аккумулятора потребуется 2 часа. Не допускается использование продукции не по назначению, разбирание, вскрытие, модификация, попадание влаги, воздействие высоких температур, а также прямых ударов. Хранить в сухом, прохладном и проветриваемом помещении. Не допускать попадания влаги и агрессивных веществ. Не допускать перегрузки и перегрева. Не допускать попадания в изделие посторонних предметов. Не допускать использования изделия детьми. Не допускать использования изделия в условиях, не соответствующих заявленным характеристикам. Не допускать самостоятельного ремонта изделия. Не допускать использования изделия с повреждениями корпуса, кнопок, клавиатуры, бурты и иные, торчащие и колющие изделия. Не допускать попадания посторонних предметов внутрь