Manufacturer: Dongguan Technology Electronics Co., LTD.
Address: Room 1026, 4th Floor, Building 2D Hardware Business Park, Gaobeng Civil Center, Nankeng Hamlet, Dongcheng, China.
✉ **Email:** dongxingservice@outlook.com

RoHS FC CE

QUICK START GUIDE

B5
Switch Power Bank with Magnetic Clip

TABLE OF CONTENTS

- P03 - P06 English
- P07 - P11 Deutsch
- P12 - P16 Français
- P17 - P21 Italiano
- P22 - P26 Español
- P27 - P32 U.S.B.D

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment.

The devices have been evaluated to meet general RF exposure requirement.
The devices can be used in portable exposure condition without restriction.

The antenna(s) used for this transmitter must be installed to provide a separation distance of at least 5 mm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

PACKAGE CONTENTS

B5 Power Bank × 1 | Switch Magnetic Clip × 1 | Switch 2 Magnetic Clip × 1

USB-A to Type-C Cable × 1 | USB-C to USB-C Cable Set × 1

PRODUCT DESCRIPTION

① **Magnetic Wireless Charging Zone:** Compatible with iPhone 12/13 series or Magsafe cases. Supports 15W fast charging for iPhone 13 series.

② **Power Button:** Short press to power on. Double press to power off. Long press to activate/deactivate the Magnetic Wireless Charging Function.

③ **USB-A Output Port:** Supports 18W fast charging output. Compatible with most USB-A devices.

④ **Battery LED Indicator.**

LED INDICATOR GUIDE

Charging Status

- Flashing: When USB-A port is flashing, power is for the Switch 2 and Switch series consoles.
- Solid: When USB-A port is solid, power is for other USB-A devices.

Battery Status

- Green LED Indicator: 75-100% remaining battery level left. Blue LED is connected.
- Yellow LED Indicator: 25%-50% remaining battery level left.
- Red LED Indicator: 0%-25% remaining battery level left.
- Flashing Red LED: Battery level too low. Please charge the power bank.
- Flashing Green LED: Battery level full. Please unplug the power bank and the Magnetic Clip to prevent overcharging.

Note:
Please wait for the battery indicator, charging will automatically shut down after 20 minutes, and the current power level will be displayed.

COMPATIBILITY

Magnetic Wireless Charging for iPhone:
Compatible with iPhone 12/13 series and Magsafe cases.

Magnetic Wireless Charging:
Compatible with Magsafe-compatible and Qi-Magsafe-ready cases. Other QI2 devices may be charged, but not fast.

Note:
Only the Switch series, the compatible with Switch/Switch OLED, with the Switch 2 Dock clip is only compatible with Switch 2.

SWITCH MAGNETIC CHARGING CLIP SET

① Align the clip with the protruding antennas on the rear of the Switch 2 and gently press. Once you hear a click, the clip is secure.

② To remove the clip, gently lift the edge of the clip using your fingers or a pry tool, and then pull it forward.

③ To remove the Switch 2 with the clip, pull it in the reverse sequence. Ensuring that the Switch 2 is not dropped when removed.

SWITCH 2 MAGNETIC CHARGING CLIP SET

① Align the clip with the protruding antennas on the rear of the Switch 2 and gently press. Once you hear a click, the clip is secure.

② To remove the clip, gently lift the edge of the clip using your fingers or a pry tool, and then pull it forward.

③ To remove the Switch 2 with the clip, pull it in the reverse sequence. Ensuring that the Switch 2 is not dropped when removed.

SPECIFICATIONS

Battery Capacity	10000 mAh (Rated capacity: 9500 mAh)
USB-A Output	5V=3A/9V=2A/12V=1.5A
USB-C Output	5V=3A/9V=3A/12V=3A/15V=3A/20V=5A
Wireless Charging Power	7.5W/10W/15W (Iphone 13 Pro)
Wired Charging Power	20W MAX
Product Size/Weight	6.87*3.07*0.9inch/ 5.3oz (150.5g)

PACKEINHALT

B5 Power Bank × 1 | Magnetische Clip für Switch × 1 | Magnetischer Clip für Switch 2 × 1

USB-A zu Type-C Kabel × 1 | USB-C zu USB-C Kabel Set × 1

PRODUKTBESCHREIBUNG

① **Magnetische kabellose Ladezone:** Kompatibel mit iPhone 12/13 Serie und Magsafe-Hüllen. Unterstützt 15W Schnellladung für iPhone 13 Serie. Andere Qi2-Geräte können geladen werden, aber nicht schnellladen.

② **Ein/Aus-Schalter:** Kurz drücken zum Einschalten. Doppelt drücken zum Ausschalten. Lange drücken zum Aktivieren/Deaktivieren der Magnetischen Kabellosen Ladefunktion.

③ **USB-A Ausgangsport:** Unterstützt 18W Schnellladung. Kompatibel mit den meisten USB-A Geräten.

④ **Batterie-LED-Anzeige.**

LED-ANZEIGEANLEITUNG

Ladestatus

- Blinkt: Wenn USB-A Port blinkt, wird der Strom für den Switch 2 und Switch Serien verwendet.
- Leuchtet: Wenn USB-A Port leuchtet, wird der Strom für andere USB-A Geräte verwendet.

Akkustatus

- Grün LED: Verbleibt 75-100% LED-Anzeige der verbleibenden Akkukapazität. + Blaue LED Anzeige ist verbunden.
- Gelbe LED Anzeige: Verbleibt 25%-50% der Akkukapazität.
- Rote LED Anzeige: Verbleibt 0%-25% der Akkukapazität.
- Blinkt Rot LED: Akkuladestand zu niedrig. Bitte die Powerbank aufladen.
- Blinkt Grün LED: Akku voll. Bitte Powerbank und Magnetische Kabellose Ladezone vor Überladung schützen.

Hinweis:
Bitte warten Sie die Akkuanzeige ab, die nach 20 Sekunden automatisch ausgeht, und der aktuelle Akkustand wird angezeigt.

KOMPATIBILITÄT

Magnetische kabellosen Ladezone für iPhone:
Kompatibel mit iPhone 12/13 Serie und Magsafe-Hüllen.

Magnetische kabellose Ladung:
Kompatibel mit Magsafe-kompatiblen und Magsafe-bereit Hüllen, andere Geräte mit QI2 können aufladen, aber nicht schnellladen.

Hinweis:
Nur Switch Powerbank ist kompatibel mit Switch/Switch OLED, während der Switch 2 Powerbank nur mit Switch 2 kompatibel ist.

SWITCH MAGNETISCHER LADECLIP-SATZ

① Richten Sie den Magnetischen Ladeclip an den Tiefen (2) der Antenne hinter dem Switch 2 aus, drücken Sie ihn sanft und er rastet ein, wenn er sicher ist.

② Entfernen Sie den Ladeclip, indem Sie ihn mit den Fingern oder einem Kunststoffwerkzeug hebeln und dann nach vorne ziehen. Vorsicht beim Entfernen des Ladeclips.

③ Entfernen Sie den Switch 2 mit dem Ladeclip, ziehen Sie den Switch 2 in umgekehrter Reihenfolge heraus. Vermeiden Sie das Fallenlassen des Switch 2 beim Entfernen.

SWITCH 2 MAGNETISCHER LADECLIP-SATZ

① Richten Sie den Magnetischen Ladeclip an den Tiefen (2) der Antenne hinter dem Switch 2 aus, drücken Sie ihn sanft und er rastet ein, wenn er sicher ist.

② Entfernen Sie den Ladeclip, indem Sie ihn mit den Fingern oder einem Kunststoffwerkzeug hebeln und dann nach vorne ziehen. Vorsicht beim Entfernen des Ladeclips.

③ Entfernen Sie den Switch 2 mit dem Ladeclip, ziehen Sie den Switch 2 in umgekehrter Reihenfolge heraus. Vermeiden Sie das Fallenlassen des Switch 2 beim Entfernen.