Manual Edition 1.0, May 2018
IB-200-B00080-00

Edifier International Limited
P.O. Box 6264
General Post Office
Hong Kong

Tel: +852 2522 6989
Fax: +852 2522 1989
www.edifier.com
© 2018 Edifier International Limited. All rights reserved.
Printed in China

NOTICE:
For the need of technical improvement and system upgrade, information contained herein may be subject to change from time to time without prior notice.
Products of EDIFIER will be customized for different applications. Pictures and illustrations shown on this manual may be slightly different from actual product. Picture for reference only, actual product prevails.

EDIFIER®

B8 Soundbar

Active Speaker system
Sound Bar/Home Theatre

HDMI

User manual | Manuel d'utilisateur | Manual de usuario | Bedienungsanleitung | Manuale dell'utente | Manual do utilizador

名　　称：	B8 Soundbar（英法西德意葡）说明书	东莞市漫步者科技有限公司	
材　　质：	80g米黄色欧维斯纸 对折，胶装	版面设计：	
尺　　寸：	127×127（MM）	校　　对：	
版本号及料号：	V1.0/IB-200-B00080-00	批　　准：	

IB-200-B00080-00 说明书B8 Soundbar/英法西德意葡

Important safety instruction

1. Please read the instructions carefully. Keep it in safe place for future reference.
2. Use only accessories approved by the manufacturer.
3. Install the instrument properly by following the instructions in the device connection section.
4. Using the product in a 0-35°C environment is recommended.
5. To reduce the risk of fire and electric shock, do not expose the product to rain or moisture.

Unpack the box

Illustrations

Remote control Illustration

Wall mount bracket installation

Connection

Operations Guide

Bluetooth Function

HDMI Operation

Specification

Power output:	R/L (Treble): 12W+12W R/L (Mid-range): 30W+30W SW: 70W
Frequency response:	45Hz~20KHz
Input:	HDMI/AUX/Line in/Bluetooth/Optical/Coaxial
Frequency Band 1:	5.725GHz ~ 5.820GHz
Frequency Band 2:	2.402GHz ~ 2.480GHz
RF Power output:	≤20 dBm (EIRP)

There are no restrictions of use.

Note:
Reference frequency used for electrical parameter during test: treble is 10KHz; mid-range and bass is 500Hz; subwoofer is 80Hz.

Troubleshooting

Problem	Solution
No sound	• Check if the power indicator light is ON. • Try to turn up the volume using either the master volume control or remote control. • Ensure the audio cables are firmly connected and the input is set correctly on the speakers. • Check if there is a signal output from the audio source.
Cannot connect via Bluetooth	• Make sure the speaker is switched to Bluetooth input. If it is in other audio input modes, Bluetooth will not connect. Disconnect from any Bluetooth device by pressing and holding in Bluetooth mode, then try again. • Effective Bluetooth transmission range is 10 meters; please ensure that operation is within the range. • Try another Bluetooth device for connection.
The B8 Soundbar does not turn on	• Check if main power is connected, or if the wall outlet is switched on.

To learn more about EDIFIER, please visit www.edifier.com
For Edifier warranty queries, please visit the relevant country page on www.edifier.com and review the section titled Warranty Terms.
USA and Canada: service@edifier.ca
South America: Please visit www.edifier.com (English) or www.edifierla.com (Spanish/Portuguese) for local contact information.