PIVOT-ALL MOTION TOOLS
AMENDMENT TO INSTALLATION INSTRUCTIONS
SPLIT HANDLE

M

Note direction

O

Slide lower handles into upper
handles and install hardware as shown
(note hardware direction)

M

LEAVE NUTS LOOSE
UNTIL STEP 3
THEN TIGHTEN

Pivot-All Steel HeavyDuty Wheelbarrow Instructions

PIVOT-ALL

MOTION TOOLS

A Product of M2iT Technologies

Packaging Contents

A- Handle x2

B- Riser x2

C- Wheel Guard x1

D- Tub x1

E- Axle Bracket x2

F- Axle x1

G- Wheel x1

H- Leg Brace x1

I- Tub Brace x2

J- Tub Brace x2

A
B

K- Leg x2

Hardware Contents

L Bolt X

M Bolt X

N Bolt X

O Bolt X

Q Washer X

P Nut X16

L- M8*120 Bolt x2
M- M8*70 Bolt x2
N- M8*60 Bolt x6
O- M8*19 Bolt x6
P- Nut x16
Q- Rubber Washer x4

1 Push Bolts (L &M) through bottom of tub (O) and through Riser (B). Thick section of riser should face toward front of tub. Use Rubber Washer (Q) to hold bolts in place. Repeat for second riser

2 Turn tub over, place Cross Brace-A and Cross-B (J) over bolts and lower onto risers. Place Handles (A) over bolts and lower. Make sure each handle offset faces outward. See packaging content (A) for directions

3 Make sure the holes in Leg (K) are facing the back of the Tub and then place leg over bolts and loosely attach to handle with Nuts (P). Repeat for other leg.

4 Place Leg Brace (H) across back of leg and loosely attach using two Bolts (O) and nuts (P). Repeat to attach the other end of the leg brace to other leg.

5 Use two Bolts (N) and two nuts (P) to attach Wheel Guard (C) to front of handles.

Bolts should point to the inside of the handles. Use a ? in. wrench or socket to fully tighten Wheel Guard. Leave the rest of the nuts and bolts loosely fastened.

6 Attach Axle Bracket (E) to bottom of handle using bolt (N) pushed through the hole closest to tub. Push second bolt (N) through hole in bottom of Tub Brace (I) then through handle (using hole closest to Wheel Guard) and finally through axle bracket.

7 Slide Axle (F) through Wheel (G) and then into attached bracket. Then slide second axle bracket (E) over other end of axle. Loosely attach second axle bracket to handle.

8 Use bolts (O) and nuts (P) to attach tops of tub braces to tub.

Use a 13mm wrench or socket to fully tighten all nuts.