AUSDOM

User Manual

KAM200

Wireless Keyboard and Mouse Combo

Thank you for purchasing AUSDOM Wireless Keyboard and Mouse Combo

AUSDOM®
Enjoy Smart Life

For more information, please visit our official website www.ausdom.com.

Your valuable comments and suggestions on improving AUSDOM products are welcome!

support@ausdom.com sales@ausdom.com
www.ausdom.com

1. Product Overview

2. Packing list

1* Wireless Keyboard
1* Wireless Mouse
1* USB Receiver (Keyboard and mouse use the same USB Receiver)
1* USB To Type-C charging cable
1* User manual

3. Connections

Wireless Keyboard

Turn on the keyboard power switch

Plug the USB Receiver into your computer device to use

Wireless Mouse



Turn on the mouse power switch

Plug the USB Receiver into your computer device to use

4. Function key description

Key	System Functions	Key	System Functions
F1	Mute	F9	Fn+Scroll Lock
F2	Volume-Volume-	F10	Fn+Insert
F3	Play/Pause	F11	Fn+Pause
F4	Previous/Brightness-	F12	Fn+Print
F5	Calculator	Esc	Fn+Esc
F6	Setting	Del	Fn+Del
F7	Wireless Switch	Pg Up	Fn+Pg Up
F8	Display Desktop	Pg Dn	Fn+Pg Dn
Fn + Esc	Hold & pressed down for 3 seconds to PC Fn Fn function		

5. Indicator

	Status	Meaning
Keyboard	Power switch on	Power on
	Keyboard Pairing Mode	Keyboard Pairing Mode
	Keyboard Pairing Mode Success	Keyboard pairing mode success
	Keyboard Battery Low	Battery low
	Keyboard Charging	Keyboard is fully charged
	Keyboard Fully Charged	Keyboard is fully charged
	Keyboard Battery Low	Keyboard
Mouse	Mouse Pairing Mode	Mouse Pairing Mode
	Mouse Pairing Mode Success	Mouse pairing mode success
	Mouse Battery Low	Battery low
	Mouse Charging	Mouse is fully charged
	Mouse Fully Charged	Mouse is fully charged
Caps Lock	Caps Lock on	Caps Lock on
	Caps Lock off	Caps Lock off
Scroll Lock	Scroll Lock on	Scroll Lock on
	Scroll Lock off	Scroll Lock off
Num Lock	Num Lock on	Num Lock on
	Num Lock off	Num Lock off

6. Charging

When the power of the keyboard and mouse is too low, the power indicator light will flash red. Please charge in time to ensure normal use.

Note: When the power level is low, the transmission of the keyboard and mouse will be delayed, stuck and unstable.

7. Specifications

Keyboard	Connections	2.4G wireless Technology USB Receiver
	Effective Range	10m
	Battery Capacity	500mAh
	Continuously working time	>200 hours
	Standby Time	>720 days
	Charging Time	<1.5 hours
Mouse	Drain Life	3 million times
	Connections	2.4G wireless Technology USB Receiver
	Effective Range	10m
	Battery Capacity	300mAh
	Continuously working time	>90 hours
	Standby Time	1 year
	Charging Time	<1.5 hours
	IP	IP64 (DIN 5350)

Note: Features and technical specifications are subject to change without notice; we apologize for any inconvenience.

8. Warranty

The Wireless Keyboard and Mouse Combo is covered by a 1-year manufacturer warranty. For more information, visit www.ausdom.com

CAUTION
RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE
DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

RECYCLING

This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycled or dismantled to minimize its impact on the environment.
User has the choice to give his product to a competent recycling organization or to the retailer when he buys a new electrical or electronic equipment.

CE FC RoHS Green Product

DC voltage

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

1. 产品概览

2. 包装清单

1*无线键盘
1*无线鼠标
1*USB接收器（键盘和鼠标共用一个USB接收器）
1*USB-C充电线
1*用户说明书

3. 连接方式

无线键盘

打开键盘的电源开关

将USB接收器插入电脑设备即可使用

无线鼠标

打开鼠标的电源开关

将USB接收器插入电脑设备即可使用

4. 按键交互功能

键盘组合	系统功能	键盘组合	系统功能
F1	静音	F9	滚屏锁
F2	音量减	F10	Fn+Insert
F3	音量加	F11	Fn+Pause
F4	上一曲/亮度-	F12	Fn+Print
F5	计算器	Esc	Fn+Esc
F6	设置	Del	Fn+Del
F7	无线开关	Pg Up	Fn+Pg Up
F8	显示桌面	Pg Dn	Fn+Pg Dn
Fn + Esc	长按3秒后切换至PC Fn Fn功能		

5. 指示灯

	模式	状态	含义
键盘	电源/充电模式	关闭	长按电源键关闭
		红灯闪烁	电量不足，请充电/换电
		红灯常亮	充电中
		绿灯常亮	电量充满
	无线配对模式	红灯闪烁	无线配对
	Num Lock模式	绿灯亮	Num Lock开启
鼠标	电源/充电模式	红灯常亮/闪烁	开机状态
		红灯闪烁	电量不足，请充电/换电
		红灯常亮	充电中
		绿灯常亮	充电完成
	配对模式	红灯闪烁/绿灯闪烁	电量充满
		红灯闪烁/绿灯常亮	长按3秒进入配对模式
		红灯闪烁/绿灯闪烁	长按3秒配对成功

6. 充电

当键盘或鼠标电量过低时，电源指示灯会一直闪烁红灯，请及时充电/换电，请及时充电以确保有足够电量保证您的工作顺畅。

提示：当电量过低时，键盘和鼠标的传输可能会出现延迟、卡顿、连接不稳定的情况。

7. 参数

键盘	连接方式	2.4G无线技术
	有效距离	10M
	电池容量	500毫安时
	连续工作时长	>200天
	待机时长	>720天
	充电时长	<1.5小时
鼠标	连接方式	2.4G无线技术
	有效距离	10M
	电池容量	300毫安时
	连续工作时长	>90小时
	待机时长	1年
	充电时长	<1.5小时
	IP4	IP64(DIN 5350)

温馨：功能和技术规格如有更改，恕不另行通知，对于造成的您带来的不便不便，我们深表歉意。

8. 保修

您的键鼠套装享1年的质量保障，更多详情请，请登录www.ausdom.com

9. 安全须知

警告：不遵循以下安全说明可能会导致起火、触电、烧伤或受伤害

除拆卸或改装零部件或 ⚠ 表示可以改变零部件，⚠ 表示拆卸会损害设备。

1. 注意通风口
2. 注意通风口周围保持
3. 远离火源和热源
4. 不要让液体进入
5. 注意油烟、蒸汽、灰尘等或者静电和振动

产品中有害物质的名称及含量

产品中有害物质名称及含量							
	有害物质						
部件名称	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溶溴联苯 (PBB)	多溶二苯醚 (PBDE)	
电路板组件	×	○	○	○	○	○	
塑料部件	○	○	○	○	○	○	
金属部件	×	○	○	○	○	○	
电池	○	○	○	○	○	○	
其它零件	○	○	○	○	○	○	

本表格依据SJ/T 11364的规定编制。

○：表示该有毒有害物质在该部件所有均质材料中的含量均在SJ/T 11363-2006规定的限量要求以下。

×：表示该有毒有害物质至少在该部件的某一均质材料中的含量超出SJ/T 11363-2006规定的限量要求。

注：“环保使用期限”是指在正常工作条件下，产品或其“环保使用期限”内，不会发生有毒有害物质的泄漏或变异的时间。

SJ/T 11364所规定的有毒有害物质不含有SJ/T 11363-2006所规定的限量要求。

10

危险品
Dangerous Goods
生产日期
Date of Production
YYYY-MM-DD

保修卡

保修期

产品自售出之日起12个月，发生质量问题，消费者可以直接退换，换货或维修，产品自售出之日起12个月，发生质量问题，消费者可直接换货或维修，本产品的品质保证期指出产品售卖日起12个月内有效。

免责提示：

在产品使用时，凡属产品自身质量不达标范畴，请用户将此保修卡和购买凭证与经销商取回维修，以享受免费保修。

以下情况恕不免费维修：

1.未保持卡固定用户盲标签。
2.部分因素造成的损坏。
3.因未长期保存造成的表面及人为机械损坏。
4.因不可抗力造成的损害或损坏。

客户姓名:	
联系电话:	
联系地址:	
产品型号:	
产品名称:	
购买日期:	
经销商:	
S/N 号:	
维修记录:	

WARRANTY CARD

ATTENTIONS:

- Please read the return procedures and warranty policy carefully on www.ausdom.com before sending items back to point-of-purchase.
- Please fill the card and send it to your reseller together with the product if your product's warranty is valid.

S.N:	
Date of Purchase	
Product Model:	
RMA Number:	
Return Reason:	
Customer Name:	
TEL:	
E-mail:	
Address:	

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.