# TFX1
APP SMART LOCK
QUICK START MANUAL

### Need Help?

For technical documents and more information, please contact us.

Email: vgfkstore@tom.com
Tel: (626)539-5825(first choice) / 6262063917

What's in the box

1 pcs Front Panel	1 pcs Back Panel	2 pcs Rubber mat	1 pcs Lock Latch
1 pcs Strike Plate	1 pcs Side Cover	1 pcs Spindle	4 pcs Wooden Screw
2 pcs M4 Screw	1 pcs Allen Key	2 pcs Mechanical Key	1 pcs Hole Template

💡 Verify that all parts of the smart lock are account for. If any parts are missing, please contact us.

Product Specification

Back Panel   **Front Panel**

Battery Box

Back Handle

Micro USB Charging Port

Fingerprint Reader
Keypad
Card Sensing Area
Hidden Key Hole
Front Handle

💡 If there are some scratches on the film, please don't worry. There is a protective film on the front panel, it can be removed.

Determine Handle Direction

The handle direction is determined from the secure side of the door. The term "secure" means the side from which you initially unlock and enter from outside.

Left Push   Right Push   Left Pull   Right Pull

Change Handle Direction

Step 1
Use the allen key to take off the screw from the handle.

Step2
Take off the handle.

Step 3
Rotate the handle 180 degree.

Step 4
Fix the direction that you need and tighten the screw.

Installation Guide

Please scan this QR code or visit https://youtu.be/dEhKvu-JOd8 to watch the installation video.

1. Line drawing & Hole drilling	**2. Install the latch**
Make out holes for the lock panel and mortise according to the hole template.	Insert the latch into the side hole, using 2 screws to fix the latch.

3. Install the lock panel

Install the front panel

1) Cover the rubber mat to the front panel. (Refer to ①)
2) Make the square shaft hole on the panel aim at the latch.
3) Insert the spindle and fix the front panel to the door. (Refer to ②,③)

Install the back panel

1) Remove the rubber mat and base plate from the back panel at first.
2) Cover the rubber mat to the back panel base plate and fix them to the door. (Refer to ④,⑤)
3) Connect the cables on the front panel to the cables on the back panel. (Refer to ⑥)
4) Fix the back panel to the door. (Refer to ⑦)
5) Install 4pcs 1.5V AA alkaline batteries and fix the battery cover. (Refer to ⑧)

TTLock APP Operation Guide

Please scan this QR code or visit https://youtu.be/qZO4RR2UDAU to watch the operation video.

💡 In factory default status, the samrt lock (no power on) is always on open state. It means that the lock handle is free and the door can't be locked. You have to power on the samrt lock with batteries, add administrator and pair the smart lock with TTLock APP, the open mode will be changed to private mode automatically.

GET IT ON Google Play

Download on the App Store

1. Search on APP store or scan the QR code above we provided to download TTLOCK APP and install it.
2. Open the app, register TTLock APP and log in the account.
3. Make sure the smart lock is factory mode.
4. Turn on bluetooth on the phone, stay near by the smart lock (within 10ft / 3m). Pair the samrt lock with TTLock APP follow the operation steps in the video and start to use it .

💡 Please TURN ON your phone's BLUETOOTH FUNCTION before any operation. The smart lock can work without the app, but more convenient functions only works with TTLock APP.

FAQs

1. Installation completed, but there is no power on smart lock ?

• Use only 4pcs AA batteries. Do not mix old and new batteries or batteries from different brands. Never insert objects into the lock other than batteries.
• Check the direction of the batteries. Positive pole should be Upward.
• On Internal Assembly, check if the wire is connected to the receiver correctly.

2. How to use passcode to unlock ?

Please enter the default status passcode (123456), press the "#" button on the keypad to unlock.

3. How do I keep the lock in the unlocked status ?

Please go to "lock settings' in the app to set up lock under "Passage Mode".

4. Does it have a low battery warning ?

The smart phone will push notification to you to change the battery if the battery going low. Also, on the bottom of front panel, there is a connection port to power bank, you could use power bank as back up power.

5. How to unlock remotely ?

WiFi gateway is required for remote control. With the gateway, you can control your bluetooth smart lock even in far distance. Revise or delete ekey / passcode that you created anywhere, anytime. View the door opening records (Card, Passcode, APP) instantly. Support remote unlock the door via app.

Gateway

💡 The gateway is not included in the package. It needs to be purchased separately.