包装设计稿件信息

基本信息	品牌	KUULAA		
	产品名称	2024-12-20 KL-YD74弧光1W-说明书		
	尺寸			
	纸盒材质		吸塑材质	
	工艺描述			
	包装设计	潘声慧		
	文案	张宇		

版本历史

版本	变更日期	变更描述
YD74	2024-12-20	初始版本（张宇）
YD74	2024-12-25	增加为手表充电（张宇）
YD74	2024-12-31	修改电池容量描述（张宇）

温馨提示：请印刷供应商严格按照图纸印刷生产。如贵司有生产上的原因需要调整图纸的字体、图形、颜色、刀模尺寸等，请必须通知相关负责的包装设计师，修改文档并发回存档。

KUULAA

KL-YD74

10000mAh Magnetic Battery(Magon)

USER MANUAL

Please read this instructions completely and keep it properly

Warning: Please follow the above safety instructions otherwise it will cause fire, electric shock, damage and other damage.

1. Product Parameter

Model: KL-YD74
Battery Type: Li-Polymer battery
Total Cell Capacity: 10000mAh
Rated Capacity: 6000mAh(5V=2A)
Rated Energy：38.7Wh(7.74V/5000mAh/2 in series)
Input: 5V=3A, 9V=3A, 12V=2.5A, 15V=2A, 20V=1.5A(30W Max)
Output: 5V=3A, 9V=3A,12V=2.5A,15V=2A,20V=1.5A(30W Max)
Wireless Charging: 15W for iPhone, 15W for Android，2.5W for Apple Watch
Size: 106×71×18mm
Weight: about 238g
Storage Temperature: -10~40℃
Working Environment Temperature: 0~40℃

2. Overview

1.Charging Status Indicator
2.Battery Level Indicator
3.USB-C Port
4.Power Button



3. Charge Mobile Device with a Cable



Status	Status Indicator	Battery Level Indicator
Charging	Off	Showing the current battery level
Fully charged	Off	Constant light

4. Charge a Phone Wirelessly

To activate wireless charging, place your device on the power bank as illustrated below. It will be held in place by magnetic coil, then wireless charging begins.



Status	Status Indicator	Battery Level Indicator
Wireless charging	Constant light	Showing the current battery level
Charging & Discharging	Constant light	Showing the current battery level
Fully charged	Constant light	Constant light

5. Charge a Smart Watch Wirelessly

To activate wireless charging, first press the power button,then place your smartwatch device on the power bank as illustrated below,it will be held in place by the magnetic coil,then wireless charging begins.



Status	Status Indicator	Battery Level Indicator
Wireless charging	Off	Showing the current battery level
Charging & Discharging	Off	Showing the current battery level
Fully charged	Off	Constant light

6. Charge Device Wirelessly and Recharge the Product Simultaneously



7. Charge the Product



Status	Status Indicator	Battery Level Indicator
Charging	Off	Flashing light
Fully charged	Off	Constant light

Note: When your power bank exceeds the temperature limit, the battery level indicator will turn off. Let power bank cool down before next use.

8. Important Safety Instructions

When using this product, basic precautions should always be taken, including the following:

1. Kept the product at normal temperatures and in shade places.

2. Do not store the product in a hot or humid environment.

3. Use of a power supply or charger not recommended or sold by the product manufacturer may result in injuries to people.

4. Operating temperature should be between 0℃ to 40℃.

5. Do not disassemble the product. Take it to the professional servicemen when repair is required. Incorrect disassembly or reassembly may result in a risk of accidents to people and damage to product, the adverse consequences caused by this behavior should be borne by the user.

6. If the product is not used for a long time, you should charge and discharge it every three months.

7. When charging a device, the product may heat up within a certain temperature range. This is a normal operating condition.

8. In normal conditions, battery performance will slowly decline over the course of a few years.

9. Do not dispose of the product in heat or fire.

10. Do not clean the product with harmful chemicals or detergents.

11. Misuse, dropping, or excessive force may cause damage to products.

12. Well disposed the disused battery, keep cells or batteries of different electrochemical systems separate from each other.

13. Be aware that a discharged battery may cause fire or smoke. Tape the terminals to insulate them.

9. Warranty Clause

Users can enjoy free warranty service within 12 months of the date of purchase.

The limited warranty does not apply in the following cases.

● Any damages caused by human factors, misuse of the product, unauthorized alternation or change of parts components of the product, etc.

● Any damages caused by bad transportation or other irresistible factors such as floods, fire, lightning, earthquakes, etc.

● The company reserves the right, at its discretion, to change, modify, add or remove portions of these terms at any time.

⚠

FCC Warning Statement: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user’ s authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
· Reorient or relocate the receiving antenna.
· Increase the separation between the equipment and receiver.
· Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
· Consult the dealer or an experienced radio/TV technician for help.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
FCC Radiation Exposure Statement
The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.

KUULAA

Kuulaa
Support@kuulaa.cn

Kuulaa is a trademark registered in the USA, EU and UK.
All rights reserved

KUULAA

KL-YD74

10000mAh磁吸无线充移动电源

用户手册

请完整阅读本说明并妥善保管。

警告：请遵守上述安全说明，否则会引起火灾、触电、烟坏和其他损坏。

1. 产品规格

型号：KL-YD74
电池类型：锂聚合物电池
电芯总容量：10000mAh
额定容量：6000mAh(5V=2A)
额定能量：38.7Wh(7.74V/5000mAh/两枚电芯串联)
输入：5V=3A，9V=3A，12V=2.5A，15V=2A，20V=1.5A(30W Max)
输出：5V=3A，9V=3A，12V=2.5A，15V=2A，20V=1.5A(30W Max)
无线充电：iPhone 15W，Android 15W，Apple Watch 2.5W
尺寸：106×71×18mm
重量：约238g
储存温度：-10~40℃
工作环境温度：0~40℃

2. 示意图

1.充电状态指示灯
2.电池电量指示灯
3.USB-C接口
4.电源键



状态	充电状态指示灯	电池电量指示灯
正在充电	关闭	显示当前电池电量
已充满电	关闭	常亮

3.为移动设备有线充电



状态	充电状态指示灯	电池电量指示灯
正在充电	关闭	显示当前电池电量
已充满电	关闭	常亮

4.为手机无线充电

要激活无线充电，先将您的设备放在充电器上（如下图所示），磁吸线圈会将设备固定到位，随后无线充电开始。



状态	充电状态指示灯	电池电量指示灯
无线充电	常亮	显示当前电池电量
同时充放电	常亮	显示当前电池电量
已充满电	常亮	常亮

5. 为智能手表无线充电

要激活无线充电，先按下电源键，再将您的智能手表设备放在充电器上(如下图所示)，磁吸线圈会将设备固定到位，随后无线充电开始。

状态	充电状态指示灯	电池电量指示灯
无线充电	关闭	显示当前电池电量
同时充放电	关闭	显示当前电池电量
已充满电	关闭	常亮

6.为设备无线充电的同时为本产品充电



7.为本产品充电



状态	充电状态指示灯	电池电量指示灯
正在充电	关闭	显示当前电池电量
已充满电	关闭	常亮

注意：当您的充电宝超过温度限制时，电池电量指示灯将关闭。在下次使用前让充电宝冷却。

8. 重要安全说明

使用本产品时，应采取基本的预防措施，包括：

1.将产品存放在阴凉干燥处。

2.请勿将产品存放在高温或潮湿的环境中。

3.使用非本产品制造商推荐或出售的电源或充电器可能会导致人身伤害的风险。

4.工作温度应介于0℃至40℃之间。

5.请勿拆卸产品，需要维修时，请将其交给专业维修人员。不正确的拆卸与组装可能会导致产品损伤甚至人身伤害，进行为引起的不良后果商用产品损。

6.如果产品长期不用，应每三个月充放电一次。

7.充电时，本产品可能会发热，这是正常现象，无需担心。

8.在正常情况下，电池性能会在几年内逐渐下降。

9.请勿将本产品置于高温或火中。

10.请勿使用有害化学品或清洁剂清洁本产品。

11.使用不当、摔落或过度用力可能会导致产品损坏。

12.处置废旧电池时，请将不同电化学体系的电池互相分开。

13.请注意，放电的电池可能会引起火灾或冒烟。请用胶带贴住正负极以实现绝缘。

9. 保修条款

用户自购买之日起12个月内可享受免费保修服务。

有限保修不适用于以下情况：

● 凡因人为因素、误用产品、擅自改动或更改产品零部件等原因造成的损坏。

● 一切因运输不当或其他不可抗力因素如水灾、火灾、雷电、地震等造成的损坏，恕不道歉。

● 公司保留自行决定随时更改、修改、添加或删除这些条款部分内容的权利。

KUULAA

Kuulaa
Support@kuulaa.cn

Kuulaa is a trademark registered in the USA, EU and UK.
All rights reserved