VADER 2

Wireless Version

SELECT

LEFT JOYSTICK

CROSS BUTTON

STATUS LIGHT1

STATUS LIGHT2

SELECT

START

Y

X

B

A

Z

C

START

ABXY

CZ

RIGHT JOYSTICK

+ HOME -

RB

RT

M3

M1

LB

LT

M4

M2

Other Accessories： Charging cable,USB receiver

Wired Version

SELECT

LEFT JOYSTICK

CROSS BUTTON

STATUS LIGHT1

STATUS LIGHT2

SELECT

START

Y

X   B

A

Z

C

START

ABXY

CZ

RIGHT JOYSTICK

+   HOME   -

RB

RT

M3

M1

LB

LT

M4

M2

Part instruction

Replaceable joystick （Additional purchase required）

Left and right joystick can be replaced on habits.Operate as shown in the figure and pull it upwards to remove or install the joystick. Joysticks of different heights can be purchased in the official store for different games

Dual-segment Detachable phone stand
(Additional purchase required)

The stand has two adjustable rotating axes which are easy to adjust the phone barycenter and ease the burden on hands.Slide up to push out the card slot to remove the bracket.Adjust to the right angle to support the phone to stand on the table

Basic Operation

wireless version	power on	Turn the power switch to ON
	power off	Turn the power switch to OFF
	stand by	If it's out of use 20 minutes,the joystick will standby automatically. Press the pairing button to wake up the joystick
	low battery	The power led flashes in red when the battery is less than 10%
	charging mode	Connet to the power adapter via the USB cable to charge
	charging	Connect the charger port to the USB cable,the power led lights on in green
	charge OK	Charge OK,the power led lights off
wired version	power on	Connect the device via data cable
	power off	Unplug the data cable connected to the device
	stand by	If it's out of use 20 minutes,the joystick will standby automatically. Press the pairing button to wake up the joystick

Wireless version connection instruction

Turn on the joystick first during the initial use,then connect to the device as required to switch to an appropriate connection mode.The USB dongle is firstly required to be plugged into the device's USB port with 2.4Ghz connection,the receiver will connect to the controller automatically.If you can't connect, please refer to FAQ for troubleshooting.

You wish to use the controller	Connet to mobile phone ,tablet	Connect to computer	
Connetion Mode	Press the pairing button and B button simultaneously for 3 seconds	Press the + button and A button simultaneously for 3 seconds. 2.4Ghz dongle needed	Connect the USB cable to computer USB wired
Support Mode	Bluetooth Mode	360 Mode(Successful switching, strong vibration of the gamepad) Android Mode(Successful switching, slight vibration of the gamepad)	
Way for switch mode	Switch with Flydigi Game Center App	Press + button and SELECT button simultaneously for three seconds to switch between 360 mode and Android mode	
Indicator Instruction	Status light1 blue	Status light 1 white	

* Connect to the computer in Android mode, click the + button to additionally turn on or off the flying mouse function, shake the gamepad to control the mouse pointer, and the M1 button can be used as the left mouse button.

Wired version connection instruction

Connetion Mode	Connect the USB cable to computer USB wired
Support Mode	360 Mode(Successful switching, strong vibration of the gamepad)
	Android Mode(Successful switching, slight vibration of the gamepad)
Way for switch mode	Press + button and SELECT button simultaneously for three seconds to switch between 360 mode and Android mode
Indicator Instruction	Status light1 white

Use on computer

Download Flydigi Space Station
Visit Flydigi official website to download Flydigi Space Station, you can customize the buttons, joysticks, lights, and somatosensory settings, and enable more hidden functions.

Play PC game

With 360 mode,you can play gaming masterpieces licluding GTA5,Assassin's Creed,Resident Evil and Tomb Raider directly.With 2.4G wireless or wired to connect to PC,press the + button and "SELECT" button simultaneously for 3 seconds to switch in mode of 360 and android.
Strong vibration of the gamepad indicates that it is currently in 360 mode.

Use on mobile phone,tablet

STEP 1: Download the Flydigi Game Center

Scan the QR code to download and install
Flydigi Game Center

- -

Or use the browser to access to down flydigi.com to download

STEP 2: Bluetooth connects to phone

Go to Flydigi Game Center-setting Management,Click-Connet the
controller as the game center guides

Disconnected

Turn on the device to connect
automatically after first connection

Rescan

If the phone is turned on and the Bluetooth is in commnuication
range,the Bluetooth will connect to the paired controller automati-
cally.
If changed to another phone to pair,it's required to turn off the
Bluetooth switch of the last device go to Flydigi game center App to
click the 'Connect controller'

Adjustment for lighting Mode

Vader 2 offers 16.8 million colors,adjustment multi-lighting colors.-
Press the pairing button and return button to switch among the
four default dazling modes.

Access to the Flydigi official site to downlaod the Flydigi space plat-
form to customize the dazzling light color.And more customized
configuration can be set up

FAQ

**Q: It's unable to use the wireless receiver to connect to the device,the in-
dicator keeps on flashing slowly?**
A: Press the + button and A button simulataneously for 3 seconds to
switch to the 2.4G wireless connection mode and press the paired button
for 5 seconds'long to keep the contrller in paired states,plug the wireless
receiver in the device's USB port and keep the contrller close to the re-
ceiver

Q: The aiming point drifts automatically while using the somatosensory?
A: If the somatosensory or flying mouse is out of control,keep the control-
ler staying still on table for 10 seconds.

Q:How to update the gamepad firmware
A: Download the Flydigi App in the phone,the firmware can be upgraded
according to the instructions in the App

Wireless version performance parameter

Supported Platforms	iOS	iphone 6 and above,ios system is above 7.1.2 below 13.4
	Android	Android phones and tablets with Bluetooth 4.0,while Android system is 4.4 and above
	PC	Windows XP and above operating system
Wireless Frequencies	2.4GHz–2.485GHz and Bluetooth 4.0BLE	
Transmission Distance	<10M	
Dimensions	155*104*64mm	
Battery Capacity	650mAh,charging time 3~4 hours	
Battery Life	For wireless:>40hrs,For wireless plus lighting:>32hrs	
Working Current	Operational current<15mA,standby current<15uA	
Storage Temperature	–20℃–+80℃	
Usage Temperature	–5℃–+50℃	

Wired version performance parameter

PC	Windows XP and above operating system
Dimensions	155*104*64mm
Operational	Operational current<15mA,standby current<15uA
Storage Temperature	–20℃–+80℃
Usage Temperature	–5℃–+50℃