BSP-D8



空白

Wireless gamepad

无线控制器说明书

功能键示意图：



适用说明：

1. 本产品采用人体工学设计，手感舒适。
2. 具有防滑橡胶手柄，可以轻松稳持游戏更为长久时间。
3. 采用蓝牙 5.0 EDR/BLE 连接，手柄通过蓝牙与手机顺畅连接。
4. 支持 ShootingPlus V3 APP，APP 可以通过连手机应用市场下载。
5. 支持安卓与苹果 HID 标准模式，可玩支持 HID 标准模式的游戏或应用程序。
6. 支持安卓 8.0 以上系统（即 ShootingPlus V3 安卓模式）。
7. 支持 iOS 10.1 至 13.3.1 系统（即 ShootingPlus V3 iOS 模式）多个制款，支持 iOS13.4及以上系统单点触控。
8. 支持 iOS 13.0 以上系统 HID 游戏、MFi 游戏可以连 ShanWan MFi app 下载。
9. 支持 PS3/PS4/SWITCH 系统主机蓝牙连接玩游戏，并具有陀螺仪功能。
10. 支持 Windows 10 系统笔记本电脑蓝牙连接，玩 X-Input 游戏。
11. 支持 USB 有线，可以在 PC/PS3/SWITCH 识别。

★ 蓝牙机系统问题，个别手机可能不支持此设备
★ 蓝牙连接用于在软件设置或进行玩家重新不可玩的游戏重连或部分游戏无法与本产品连接操作，确定软不是传统软件，对此确定可保留最终解释权。

产品特性参数：

1. 工作电压：DC3.7V
2. 工作电流：约 10mA
3. 待机使用时间：>20H
4. 休眠电流：<5uA
5. 充电电压/电流：DC5V/500mA
6. 蓝牙传输距离：>10M
7. 电池容量：350mAh
8. 待机时间：满电直至 40 天

使用本产品时，请保持设备摄像头位置，以确保设备保持在左边，并将游戏的屏幕设置更加大。

产品使用说明：

安装 ShootingPlus V3 模式(鸿蒙系统与安装 ShootingPlus V3 模式相同)：

同时按"+"+"Q"秒进入 V3 安卓模式，手柄灯跳动，连安装手机搜索到"BSP—D8"设备名时，选择连接，连接成功后，手柄指示灯常亮后合。
已成功连接过，可以直接使Q，指示灯常闪，自动回连。

iOS ShootingPlus V3 模式：

同时按"+"+"Q"秒进入 V3 iOS模式，手柄灯跳动，连苹果手机搜索到"BSP—D8"设备名时，选择连接，连接成功后，手柄指示灯常亮后合。
已成功连接过，可以直接使Q，指示灯常闪，自动回连。

安卓/鸿蒙/iOS 按键映射功能：

关注公众号"ShootingPlus"查看公众号内的默认操作说明，如需设置映射键位，请下载安装"ShootingPlus V3"APP，在 APP 内进行按键映射以及调整设置。
ShootingPlus V3 App，iOS 系统可以到 APP Store 下载，安卓与苹果系统可以到各手机应用市场下载。

ShootingPlus微信公众号

安卓标准模式：

1、同时按"Vol-"+"Q"秒进入标准安卓模式，手柄灯跳动，连安卓手机搜索到"BSP—D8"设备名时，选择连接，连接成功后，手柄指示灯常亮后合。
已成功连接过，可以直接使Q，指示灯常闪，自动回连。
2、安卓/鸿蒙标准模式下，可下载各种游戏，进入平台下载所需要的游戏。

iOS MFi 模式：

同时按"Vol-"+"Q"秒进入 iOS MFi 模式，手柄灯跳动，连苹果手机搜索到"DUALSHOCK 4 Wireless Controller"设备名时，选择连接，连接成功后，手柄指示灯常亮后合。
已成功连接过，可以直接使Q，指示灯常闪，自动回连。
MFi 游戏可以到 ShanWan MFi app 下载。

PC X-input 蓝牙模式：

同时按"Vol-"+"Q"秒进入电脑蓝牙模式，手柄指示灯快闪，打开电脑设置添加蓝牙设备，点击搜索，找到"Xbox Wireless Controller"设备名时，选择连接，连接成功后，手柄指示灯常亮后合。
已成功连接过，可以直接使Q，指示灯常闪，自动回连。

SWITCH 模式：

在 SWITCH 主机，选择 手柄 Controllers→更改握把/顺序 ChangeGrip/order，进入到 SWITCH 主机配对模式界面 Press L+R on the controller。同时按【RT+Q】2秒进入 SWITCH 模式配对，LED灯跳动，配对成功后手柄指示灯常亮或熄。
已成功连接过，可以直接使Q，指示灯常闪，自动回连。

PS3/PS4 模式：

将手柄用 TYPE-C USB 数据线连接与 PS3/PS4主机连接，按Q 进行配对，配对成功后，手柄指示灯常亮后。
已成功连接过，可以直接按Q，指示灯常闪，自动回连。

PC 2.4G电脑接收器模式：

同时按"Vol-"+"Q"秒进入电脑模式，手柄指示灯快闪，为PC端接模式，电脑接收器插电脑上，连接成功后，手柄指示灯常亮后合。
已成功连接过，可以直接使Q，指示灯常闪，自动回连。

电脑接收器【插电脑】

有线模式：

1. 有线模式下自动识别各个系统平台，可以支持的系统平台有安卓、PC端-input等X-input、PS3/Switch。
2. 在PC上，按"Q"键进行在XIDI的PC/PS3模式与XBOX360模式之间切换。
3. 在OTG不双工系统支持连接"Q"按键连接输入USB连接OTG手柄，iOS手柄，iOS手柄，为OTG连接模式。

马达震动及调节：

按住TURBO右摇杆上下可以增强或减马达震动力度

TURBO设置：



按下"A"再按"↑"，则为"A"键Turbo连发
第二次按下"A"再按"↑"，则为"A"键自动连发
第三次按下"A"再按"↑"，则为"A"键关闭连发(恢复原键)

当"A"键在AUTO自动连发的情况下，按住"TURBO+左摇杆上下"设置自动连发的速度，分别为一秒15下、一秒25下、一秒8下。（注：其他功能键设置方法同上）

触控板功能：



手柄不控制桌面，同时按住"三-Q"键，触控板切换到鼠标，切换完成后触控灯灭。

体感强开：

1. 按住"T"键几秒不放，马达震动，前后摇晃后松开时。
2. 再次按住"T"键几秒不放，马达震动，前后摇晃后松开时。
3. 再次按住"T"键几秒不放，马达震动，前后摇晃。

灯光调节功能：

同时按住"T+L3左摇杆按下"7秒钟进行切换。
切换灯效顺序为：
RGB灯呼吸 > RGB灯整呼 > 灯光关闭，三个循环。

手柄充电/休眠/唤醒功能：

1. 手柄充电功能：
A、超电时，指示灯每3秒闪烁；
B、充电时，指示灯常亮/熄灯；
C、充满时，手柄关机；
2. 手柄休眠/唤醒(关机功能)：
A、手柄在分钟内没有任何按键操作时自动关机休眠；
B、当需要重新使用时需按一次唤醒按可恢复；
C、在开机状态下，长按住键 8 秒，产品关闭，所有 LED 指示灯熄灭。

操作使用模式：

蓝牙模式：

蓝牙系统	Android/鸿蒙系统		iOS系统	
工作模式	ShootingPlus V3	安卓标准模式	iOS MFi模式	ShootingPlus V3
模式配对(长按2秒)	A+ Q	X+ Q	B+ Q	Y+ Q
指示灯	红	橙	紫	白
备注	需安卓系统下载的游戏	需安卓HID游戏的游戏	需MFi游戏ShanWan手机App可以下载	需App Store下载的游戏，iOS13.4以上为单点触控

*电脑接收器以及安卓模式：

工作模式	电脑 / PC	PC 2.4G	PS3 / PS4 / PS5	Switch
模式配对(长按2秒)	RB+Q	LB+Q	插USB数据线	RT+Q 或插USB
指示灯	青	青	蓝	绿
备注	支X-input游戏	支X-input以及D-input游戏	支PS3 / PS4游戏	支Switch游戏

*电脑需要选配电脑接收器

注意事项：

1. 请不要将本产品放在潮湿或高温地方存储；
2. 不要敲击、摔打、掉打，刮擦，或试图拆分解本产品，以免对产品造成不必要的损害；
3. 产品内置电池，请勿拆机进一步操作；
4. 不要在易燃不远距日信息的地方对产品进行充电；
5. 请安装人员请在拆装本产品，请拆卸本指南最新版本。

产品清单：



Wireless controller manual

Schematic diagram of function buttons:



Applicable instructions:

1. This product adopts ergonomic design and has a comfortable touch.
2. Equipped with stretching and shrinking function, it can stretch and store mobile phones with different lengths of 129-252mm.
3. Using Bluetooth 5.0 EDR/BLE connection, the handle is connected to various hosts such as mobile phones through Bluetooth.
4. Supports ShootingPlus V3 APP, which can be downloaded from various mobile application markets.
5. Supports Android and Harmony OS HID standard modes, and can play various game hall games that support HID standard modes.
6. Supports Android 8.0 or higher systems (i.e. ShootingPlus V3 Android mode).
7. Support multiple touch controls for iOS 10.1 to 13.3.1 systems (i.e. ShootingPlus V3 iOS mode). Supports single touch control for iOS 13.4 and above systems.
8. Supports MFi games for iOS 13.0 and above systems, and MFi games can be downloaded from the ShanWan MFi app.
9. Support PS3/PS4/SWITCH game console Bluetooth connection to play games, and have gyroscope function.
10. Supports Bluetooth connectivity for Windows 10 laptops and plays X-Input games.
11. Supports USB cable and can play PC/PS3/SWITCH games.

★ Due to phone system issues, some phones may not support this device.
★ Due to uncontrollable factors such as software upgrades or source code changes on the official game platform, some games cannot be connected and operated with this product. Our company is not responsible for any of the consequences. Our company reserves the final right of interpretation regarding this matter.

Product characteristic parameters:

1. Working voltage: DC3.7V
2. Working current: approximately 10mA
3. Continuous use time>20H
4. Sleep current<5uA
5. Charging voltage/current: DC5V/500mA
6. Bluetooth transmission distance>10M
7. Battery capacity: 350mAh
8. Standby time: till days when fully charged

When using this product, please keep the device horizontally placed and ensure that the camera is on the left, and restore the game's key positions to their default settings.

Product Instructions:

Android ShootingPlus V3 mode (Harmony OS system and Android ShootingPlus V3 mode are the same):

Press "A+Q" for 2 seconds to enter V3 Android mode, and the handle light will flash. When the Android phone searches for the device name "BSP-D8", select Connect. After successful connection, the indicator light on the handle will remain red.
Successfully connected, you can directly press Q, the indicator light flashes slowly, and automatically connect back.

iOS ShootingPlus V3 Mode:

Press "+"+"Q" for 2 seconds to enter V3 iOS mode, and the handle light will flash quickly. When the Apple phone searches for the device name "BSP-D8", select Connect. After successful connection, the indicator light on the handle will always be on white.Successfully connected, you can directly press Q, the indicator light flashes slowly, and automatically connect back.

Android/Harmony OS/iOS key mapping function:

Follow the official account "ShootingPlus" and check the default operating instructions in the official account. If you need to set the mapping keys, please download and install the "ShootingPlus V3" APP, adjust the keys and adjust the key positions in the APP.
ShootingPlus V3 App can be downloaded from the App Store for iOS systems, and from various mobile application markets for Android and Harmony systems.

ShootingPlus WeChat official account

Android Standard Mode:

1. Press "A+Q" for 2 seconds to enter the standard Android mode, and the handle light will flash quickly. When the Android/Hongmeng phone searches for the device name "BSP-D8", select Connect. After successful connection, the indicator light on the handle will remain red.
Successfully connected, you can directly press Q, the indicator light flashes slowly, and automatically connect back.
2. In Android/Harmony OS standard mode, you can download various game halls and enter the platform to download the required games.

iOS MFi Mode:

Press "B+Q" for 2 seconds to enter iOS MFi mode, and the handle light will flash quickly. When the Apple phone searches for the device name "DUALSHOCK 4 Wireless Controller", select Connect. After successful connection, the indicator light on the handle will always be on white.
Successfully connected, you can directly press Q, the indicator light flashes slowly, and automatically connect back.
MFi games can be downloaded from the ShanWan MFi app.

PC X-input Bluetooth mode:

Press "Vol-"+"Q" for 2 seconds to enter the computer Bluetooth mode. The handle indicator light flashes quickly, open the computer, find the Bluetooth device to add, click Search, and when the device name "Xbox Wireless Controller" is found, select Connect. After successful connection, the handle indicator light will remain on in cyan.
Successfully connected, you can directly press Q, the indicator light flashes slowly, and automatically connect back.

SWITCH mode:

On the SWITCH host, select Controller→Change Grip/Order to enter the SWITCH host pairing mode interface Press L+R on the controller. Simultaneously press [RT+Q] for 2 seconds to enter SWITCH mode for pairing, and the LED light will flash. If the pairing is successful, the handle indicator light will remain green.
Successfully connected, you can directly press Q, the indicator light flashes slowly, and automatically connect back.

PS3/PS4 mode:

Connect the handle directly to the PS3/PS4 host using a TYPE-C USB data cable, press Q to pair, and after successful pairing, the handle indicator light remain on in blue.
Successfully connected, you can directly press Q, the indicator light flashes slowly, and automatically connect back.



PC 2.4G computer receiver mode:

Simultaneously press "Vol-"+"Q" for 2 seconds to enter computer mode. The handle indicator light flashes quickly, indicating PC connection mode. The computer receiver is plugged into the computer. After successful connection, the handle indicator light will remain on in cyan.
Successfully connected, you can directly press Q, the indicator light flashes slowly, and automatically connect back.



Computer receiver【Insert computer】

Wired mode:

1. Automatic recognition of various system platforms in wired mode, supported by Android, PC-X-Input and X-Input, PS3, and Switch.
2. On the PC side, pressing the Q key for 2 seconds can switch between PC/PS3 mode and XBOX360 mode.
3. On iOS 16.0 and above systems, it is supported to hold down the "Q" button and insert an USB to connect to an OGS computer, OS phone, or iOS tablet. In iOS wired mode.

Motor vibration force adjustment:



Pressing and holding the TURBO+right joystick up and down can enhance and weaken the motor vibration force

TURBO settings:

Press "A" and then "T" to activate Turbo burst
Press "A" for the second time and then "T", the "A" button will automatically send consecutive messages
Press "A" for the third time and then "T" to turn off the burst (restore to original state)

When the "A" button is in AUTO mode, press and hold the "TURBO+left joystick up and down" button to set the speed of the automatic burst, which is 15 beats per second, 25 beats per second, and 8 beats per second, respectively. (Note: The setting method for other function keys is the same as above)

Axis calibration function:



Place the handle flat on the desktop, press and hold the "三-Q" button, wait for the indicator light to remain on, and then release. After calibration is completed, the indicator light will turn off.

Strong sense of body opening:



1. Press and hold the "T" button for eight seconds, and if the motor vibrates, switch to the simulated light joystick.
2. Press and hold the "T" button again for eight seconds, and if the motor vibrates, switch to the simulated left joystick.
3. Press and hold the "T" button again for eight seconds, and if the motor vibrates, it will be cancelled.

Light adjustment function:



Simultaneously press and hold "T+L3 left joystick pressed" to switch the light effect.
The order of switching light effects is:
RGB light breathing > RGB light pause > Light off, three cycles.

Handle charging/hibernation/wake-up function:

1. Handle charging function:
A. When the battery is low, the indicator light flashes quickly to prompt.
B. When charging, the indicator light flashes slowly to indicate.
C. When fully charged, the handle shuts down.
2. Handle sleep/wake up(shutdown function):
A. The handle automatically shuts down and sleeps when there are no button operations within 5 minutes.
B. When you need to use it again, you need to press the Q key to wake up and reconnect.
C. In the power-on state, press and hold the Q button for 8 seconds to shut down the product and turn off all LED indicators.

Operation and usage mode:

Bluetooth mode:

Applicable system	Android/Harmony OS		iOS system	
Working mode	ShootingPlus V3	Android Standard Mode	iOS MFi mode	ShootingPlus V3
Pairing (Pressing long)	A+ Q	X+ Q	B+ Q	Y+ Q
pilot lamp	Red	Orange	Purple	White
notes	Play games downloaded from the Android Market	Play Android HID Game Hall	Play the MFi game ShanWan MFi App for download	Play App Store downloaded games and play single and more with single touch

Computer receiver and data cable mode:

Applicable system	Computer / PC	PC 2.4G	PS3 / PS4 / PS5	Switch
Pairing (Pressing long)	RB+Q	LB+Q	Plug in USB data cable	RT+Q or Plug in USB
pilot lamp	Cyan	Cyan	Blue	Green
notes	Play X-input games	Play X-input and D-input game	Play PS3/PS4 games	Playing Switch Games

*Computers need an optional computer receiver

Precautions:

1. Do not store the product in wet or hot places;
2. Do not hit, hit, but, pierce or attempt to break down the product to avoid unnecessary damage to it;
3. The product has built-in batteries, do not throw them away with garbage;
4. Do not charge the handle near fire or other heat sources;
5. Non-professionals should not disassemble this product, otherwise it is not in the after-sale warranty service.

Product List:

ワイヤレスコントローラ説明書

機能ボタンの概略図：

適用説明：

1. 本製品は人体工学設計を採用し、手触りが快適である。
2. 伸縮機能を備えた、長さ 129 - 252 mmの携帯電話を収納収容することができる。
3. Bluetooth 5.0 EDR/BLE接続を採用し、ハンドルはBluetoothを通じて携帯電話などの様ホストと接続する。
4. ShootingPlus V3 APPをサポートし、APPは各携帯アプリ市場を通じてダウンロードすることができる。
5. アンドロイド上端末HID標準モードをサポートし、HID標準モードをサポートする各種ゲームセンターゲームをプレイすることができる。
6. Android 8.0以上のシステム（つまりShootingPlus V3 Androidモード）をサポートする。
7. iOS 10.1 - 13.3.1システムの複数のタッチをサポートする。iOS 13.4以上のシステムのシングルタッチをサポートする。
8. iOS 13.0以上のシステムのMFiゲームをサポートし、MFiゲームはShanWan MFi appでダウンロードできる。
9. PS3/PS4/SWITCHゲーム系統のBluetooth接続ゲームをサポートし、ジャイロエフェクト機能を有する。
10. Windows 10システムノートパソコンのBluetooth接続をサポートし、X-Inputゲームをプレイする。
11. USBケーブルに対応し、PC/PS3/SWITCHのゲームをプレイすることができる。

★携帯電話システムの問題で、要知の携帯電話はこの機器に対応していない可能性があります。
★公式ゲームプラットフォームのソフトウェアアップグレードやソーシャーコード変更などの不可抗力要因により、一部のゲームが本製品と接続操作できなくなり、当社はいかなる責任も負いません。これに対して当社は最終的な解釈権を留保しています。

製品特性パラメータ：

1. 動作電圧：DC3.7V
2. 動作電流：約 10mA
3. 待機使用時間：>20H
4. 休眠電流：<5uA
5. 充電電圧/電流：DC5V500 mA
6. ブルートゥース伝送距離：<10M
7. 電池容量：350 mAh
8. 待機時間：満電状態即使用

本製品を使用する場合は、デバイスを横方向に配置し、カメラが左にあることを確認し、ゲームのキーをデフォルト設定に戻してください。

製品使用説明：

アンドロイドShootingPlus V3モード（鴻蒙システムとアンドロイドShootingPlus V3モードは同じ）：

同時に"A+Q"秒、を2秒押してV3アンドロイドモードに入り、ハンドルランプが点滅し、アンドロイド携帯電話が"BSP-D8"デバイスを検索した場合、接続を選択する。接続が成功すると、ハンドルLEDは常に赤に点灯します。
接続に成功した状態で、ハンドルのQボタンを押すだけで、ランプがゆっくり点滅し、自動的に接続に戻ることができます。

iOS ShootingPlus V3:

同時に"+"+"Q"、を2秒押してV3 iOSモードに入り、ハンドルランプが急速に点滅し、アップルの携帯電話で"BSP-D8"、デバイス名を検索された場合、接続を選択する。接続に成功すると、ハンドルLEDは常に白に点灯します。
接続に成功した状態で、ハンドルのQボタンを押すだけで、ランプがゆっくり点滅し、自動的に接続に戻ることができます。

Android/鴻蒙/iOSキーマッピング機能：

公式番号"ShootingPlus"に注目して、公式番号内のデフォルト操作説明を見て、マッピングキーを設定する必要がある場合は、「ShootingPlus V3」APPをダウンロードしてインストールし、APPでセットマップを調整する。
ShootingPlus V3 App、iOS システムはAPP Storeでダウンロードでき、アンドロイドと鴻蒙システムは各携帯アプリ市場でダウンロードできる。

ShootingPlus公式番号

Android標準モデル：

1、同時に"Vol-Q"、2秒を押して標準アンドロイドモードに入り、ハンドルランプがすばやく点滅し、アンドロイド携帯電話が"BSP-D8"デバイスを検索した場、接続を選択する。接続が成功すると、ハンドルLEDは常に赤に点灯します。
接続に成功した状態で、ハンドルのQボタンを押すだけで、ランプがゆっくり点滅し、自動的に接続に戻ることができます。
2、アンドロイド/鴻蒙標準モードでは、各種ゲームセンターをダウンロードし、プラットフォームにログインと必要なゲームをダウンロードすることができる。

iOS MFiモード：

同時に"B+Q"、を2秒押して iOS MFiモードに入り、ハンドルランプがフラッシュし、アップルの携帯電話で"DUALSHOCK 4 Wireless Controller"、デバイス名が検索された場合、接続を選択します。接続に成功すると、ハンドルLEDは常に白に点灯します。
接続に成功した状態で、ハンドルのQボタンを押すだけで、ランプがゆっくり点滅し、自動的に接続に戻ることができます。
MFiゲームはShanWan MFiアプリをダウンロードできます。

PC X-input Bluetoothモード：

同時に"Vol-Q"、を2秒押してコンピュータBluetoothモードに入り、ハンドルランプがフラッシュし、コンピュータを開いてBluetoothデバイスを追加し、検索をクリックしてXbox Wireless Controller、デバイス名を見つけた場合、接続を選択します。接続が成功すると、ハンドルLEDは常にシアンに点灯します。
接続に成功しました、直接Qを押すことができ、ランプがゆっくり点滅し、自動的に接続に戻ることができます。

SWITCHモード：

SWITCHホストで、ハンドルControllers→グリップ/ニュータ選択ChangeGrip/order を開きPress L+R on the controller。同時に【RT+Q】を2秒押してSWITCHモードペアリングに入り、LEDランプは点滅始める。
接続に成功しました、直接Qを押すことができ、ランプがゆっくり点滅し、自動的に接続に戻ることができます。



PS 3/PS 4モード：

ハンドルをTYPE-C USBデータケーブルでPS 3/PS 4系統に直接接続し、Qでペアリングし、ペアリングが成功すると、ハンドルランプは青に常時に点灯します。
接続に成功しました、直接Qを押すだけでよいです、ランプがゆっくり点滅し、自動的に接続に戻ることができます。

PC 2.4 Gパソコン受信機モード：

同時に"Vol-Q"、を2秒押してコンピュータモードに入り、ハンドルランプがフラッシュし、PC接続モードです。コンピュータ受信機がコンピュータに差し込まれる。接続に成功すると、ハンドルLEDは常にシアンに点灯します。
接続に成功しました、直接Qを押すことができ、ランプがゆっくり点滅し、自動的に接続に戻ることができます。

コンピュータ受信機【パソコンを差し込む】

有線モード：

1、有線モードで各システムプラットフォームを自動的に識別し、サポートできるシステムプラットフォームはアンドロイド、PC (D-input,X-input) 、PS 3と Switch です。
2、PC では、Qを一定時間押すと PC/PS 3モードと XBOX 360モードを切り替えることができます。
3、iOS 16.0以上のシステムでは、【Q】ボタンを押したままUSB接続のiOSパソコン、iOS携帯電話、iOSタブレットを挿入することができます。iOS有線モードです。

モータ振動力調節：

TURBO+右ロッカーバーのどちら押すと、モーターの振動力を調あます

TURBO設定：

「A」を押して「T」を押すと、「A」キーTurbo連発
2回目に「A」を押して「T」を押すと、「A」キーの自動的に連続連射
3回目に「A」を押して「T」を押すと、「A」キーの自動的に連射解除

「A」キーがAUTOで自動的に連射する場合、「TURBO+右ロッカーどう」を押しながら自動連射の速度を設定します。それぞれ1秒15、1秒25、1秒8です。（注：その他のファンクションキーの設定方法は同上）

触覚正機能：

ハンドルをデスクトップに平らに置き、同時に「三-Q」ボタンを押し、ランプが点灯に戻すまで待ち、ランプが点灯、ランプが点灯、キャリブレーションが完了するとランプが消えます。

体感開：



1、「T」ボタンを3秒間押して放すと、モーターが揺れます。アナログ型スイングレバーが切り替わります。
2、再び「T」ボタンを3秒間押して放すと、モーターが揺れます。アナログ型スイングレバーが切り替わります。
3、再び「T」ボタンを3秒間押して放すと、モーターが揺れ、ミカもキャンセルします。

ライト調整機能：

同時に「T+L3（左レバー押下）」を押すとランプ効果が切り替わります。
ライトエフェクトの順番を切り替えるには：
RGBランプ呼吸 > RGBランプ一時停止 > ライトオフ三サイクル。

ハンドルの充電/スリープ/ウェイクアップ機能：

1、ハンドル充電機能：
A、低電力時、ランプがフラッシュ提示；
B、充電時、ランプがゆっくりと点滅することを表示する；
C、満タンの時、ハンドルは電源を切る。
2、ハンドルスリープ（ハイバネーション）/ウェイクアップ機能：
A、ハンドルは5分以内にボタンを操作がない場合、自動的に電源を切って休眠する。
B、再使用は必要な場合はQキーを押し、ハンドルを再接続できます。
C、電源を入れた状態で、Qボタンを8秒間長く押して、製品はシャットダウンして、すべてのLEDランプは消灯します。

操作使用モード：

Bluetoothモード：

システム	Android/鴻蒙システム		iOSシステム	
動作モード	ShootingPlus V3	本来標準モード	iOS MFIモード	ShootingPlus V3
ペアリング(長押し2秒)	A+ Q	X+ Q	B+ Q	Y+ Q
インジケーターライト	赤	オレンジ	パープル	白
コメント	アンドロイド市場でダウンロードしたゲームをプレイする	アンドロイドHIDゲームセンターをプレイする	MFIゲームShanWanMFIAppをプレイするとダウンロードできます	App Store下ダウンロードしたゲームをプレイする、iOS13.4以上のシングルタッチ

コンピュータ受信機およびデータケーブルモード：

Applicable system	Computer / PC	PC 2.4G	PS3 / PS4 / PS5	Switch
パラーペアリング(長押し2秒)	RB+Q	LB+Q	挿入USBデータケーブル	RT+Q or 挿入USB
インジケーターライト	シアン	シアン	青	グリーン
コメント	X-Inputゲームをする	X-InputおよびD-inputゲームをプレイする	PS 3/PS 4ゲームをプレイする	Switchゲームをする

*コンピュータにはオプションのコンピュータ受信機が必要

注意事項：

1. 本製品を高温や高湿の場所に保管しないでください。
2. 製品に不必要な損傷を与えないように、たたいたり、殴ったり、棒を打ったり、刮したり、擦ったりしたりしないでください。
3. 製品に安置カテ内ていいます、ゴミと一緒に捨てないでください。
4. 火や他の熱源に近い場所でハンドルを充電しないでください。
5. 専門外の人は本製品を分解しないでください、そうしないと、アフターサービスはおきません。

製品リスト：

FCC Caution:
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.