成品尺寸:50x70mm
材质:128g铜版纸 双面单色印刷

MAGIC JOHN



SPEAKER STAND

封面

English

Package List



1.Speaker Stand ×1
2.Data Cable ×1
3.User Manual ×1
4.Magnetic Mounting Pad×2

English

Appearance Description



1.Magnetic/Wireless Charging Module
2.Telescopic Rod + Rotation
3.Transparent Shell
4.Base Module
5.Bottom Foot Pads
6..Type-C Port / SD Card Slot
7.Operation Area

English

Operation Guide

Power on/off & Bluetooth Mode

Power On/Off	Long press the power button for 2S
SD Mode	Insert card to play
Mode Switch	Single-click power button
Volume +	Long press left button
Volume –	Long press right button
Previous Track	Press left button once
Next Track	Press right button once

Radio Mode

Power Button	Click to switch to radio mode
Light Button	In radio mode: Click light button to auto-scan
Volume +	Long press left button
Volume –	Long press right button
Previous Station	Press left button once
Next Station	Press right button once

English

Product Parameter

Model Number	X7
Product Name	Speaker Stand
Material	ABS+PC
Product Dimensions	80~80*108mm
Charging Port	Type-C
Bluetooth Range	20m
Bluetooth Version	5.3
Battery Life	150min
Frequency Response	140Hz-18Khz
Number of Drivers	1
Signal-to-Noise Ratio (SNR)	86dB
Built-in Battery Capacity	500mAh
Rated Power	5W
Rated Voltage	5V-0.5A

Deutsch

Packliste



1. Lautsprecherhalterung×1
2.das Datenkabel×1
3.das Handbuch×1
4.magnetisches Bleiblech ×2

Deutsch

Erscheinungsbild



"1. magnetisches/drahtloses Lademodul
2. teleskopische Stange + Drehung
3.transparente Schale
4.das Basismodul
5.unterer Fuß
6.Typ-C-Anschluss/SD-Anschluss
7.der Betriebsbereich"

Explore Technology, Witness Quality.

Deutsch

Leitfaden für den Betrieb

Umschalten und Bluetooth-Modus

Schalter Ein/Aus	Drücken Sie lange auf die Ein/Aus-Taste 2S
SD-Modus	Stecken Sie die Karte ein
Umschalten des Modus	Klicken Sie auf die Ein/Aus-Taste
Lautstärke aufwärts	Drücken Sie lange auf die linke Taste
Lautstärke runter	Drücken Sie lange auf die rechte Taste
Vorheriges Lied	Klicken Sie auf die linke Taste
Nächster Titel	Rechts klicken

Aufnahmemodus

Taste Schalter	Klicken Sie auf , um in den Radiomodus zu wechseln
Licht-Taste	Klicken Sie im Radiomodus auf die Lichttaste, um die automatische Suche zu starten.
Lauter	Drücken und halten Sie die linke Taste
Lautstärke leiser	Drücken und halten Sie die rechte Taste
Vorheriger Sender	Klicken Sie auf die linke Taste
Nächster Sender	Rechts klicken

Deutsch

Produkt-Parameter

Modell	X7
Bezeichnung	Audio-Ständer
Werkstoff	ABS+PC
Größe	80~80*108mm
Ladeschnittstelle	Type-C
Bluetooth-Abstand	20m
Bluetooth-Version	5.3
Dauer	150min
Frequenzbereich	140Hz-18Khz
Anzahl der Lautsprecher	1
Signal-Rausch-Verhältnis	86dB
Eingebaute Batteriekapazität	500mAh
Nennleistung	5W
Nennspannung	5V-0.5A

日本語

パッケージリスト



1.スタンドX1
2.USBケーブルX1
3.取扱説明書X1
4.磁石板X2

日本語

外観説明



1.磁吸/無線充電モジュール
2.伸縮棒と回転機能
3.透明なハウジング
4.底座モジュール
5.底部の防滑垫
6.Type-Cインターフェース/SDインターフェース
7.操作エリア

日本語

操作マニュアル

開閉とブルースピースモード

開機/關機	長押しスイッチボタン 2秒
SDモード	カードをスロットに挿入して遊ぶ
モード切換	オン/オフボタンをクリック
ボリューム+	左ボタン長押し
ボリューム-	右ボタン長押し
前曲へ	左クリック
次曲へ	右クリック

ラジオモード

電源ボタン	クリックしてラジオモードに切り替える
ライトボタン	ラジオモードでは、ライトボタンをクリックしてオートサーチを開始します
ボリューム+	左ボタンを長押し
ボリューム-	右ボタンを長押し
前チャンネル	左ボタンをクリック
次チャンネル	右ボタンをクリック

日本語

製品パラメータ

型番	X7
製品名	スピーカー スタンド
材質	ABS+PC
製品寸法	80~80*108mm
充電インターフェース	Type-C
ブルートゥース距離	20m
ブルートゥースバージョン	5.3
使用時間	150min
周波数応答範囲	140Hz-18Khz
スピーカー数	1
信雑比(SNR)	86dB
内蔵バッテリー容量	500mAh
定格電力	5W
定格電圧	5V-0.5A

FC

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

封底