# LTC

NIMBLEBACK

# USER MANUAL

Basic Information

Keyboard

Type-C Cable

Keycap&Switch Puller

User Manual

Wired Connection

System Requirements

- Computer with Available USB Ports
- PC: Windows 7 or Above
- Mac: macOS X 10.6 Snow Leopard or Above

Backlight Control

Fn + |	🔆 Backlight Switch	Fn + →	🌀 Backlight Speed +
Fn + ↑	🌀 Backlight Modes Switch	Fn + ←	🌀 Backlight Speed -
Fn + ↓	🔆 Backlight Colors Switch		

Multimedia Key For Windows

Windows System: Press **Fn+A**

Fn + **F1**	☀– Display Brightness -	**Fn** + **F5**	☀– Backlight Brightness -
Fn + **F2**	☀+ Display Brightness +	**Fn** + **F6**	☀+ Backlight Brightness +
Fn + **F3**	🖥 Back to Desktop	**Fn** + **F7**	⏮ Last Song
Fn + **F4**	☰ Mission control	**Fn** + **F8**	▶/❚❚ Play/Pause

Multimedia Key For Windows

Fn + **F9**	⏭ Next Song	
Fn + **F10**	🔇 Mute	
Fn + **F11**	🔉 Volume -	
Fn + **F12**	🔊 Volume +	
Fn + **ScrLK**	🎤 Voice Typeing	

Fn + **Pause**	😃 Emoji
Fn + **PrtSc**	🖥 Print Screen
Fn + **Win**	🪟 Win Lock
Fn + **Space**	Long Press to Restore Factory Mode

Multimedia Key For Mac

Mac System: Press Fn+S

F1	☀- Display Brightness -
F2	☀+ Display Brightness +
F3	🖥 Back to Desktop
F4	☰ Mission control

F5	☀- Backlight Brightness -
F6	☀+ Backlight Brightness +
F7	⏮ Last Song
F8	▶/⏸ Play/Pause

Multimedia Key For Mac

F9 ▶▶ Next Song	**Fn** + **Pause** 😀 Emoji
F10 🔇 Mute	**Fn** + **PrtSc** 🖥 Print Screen
F11 🔊- Volume -	**Fn** + **Win** ⊞ Win Lock
F12 🔊+ Volume +	**Fn** + **Space** Long Press to Restore Factory Mode
Fn + **ScrLK** 🎤 Voice Typeing (Only support Apple M1 chip)	

Services & Supports

LTC

THANK YOU FOR YOUR PURCHASE OF LTC.

We are looking forward to your feedback and hope you enjoy your LTC Product!

YOUR PRODUCT IS UNDER

60-DAYS GUARANTEE

60-DAY
money-back guarantee for any reason

18 MONTHS WARRANTY

18-MONTH
warranty for quality-related issues

If you have any questions, please feel free to contact us via **business@ltcofficial.com.**