PAXA FreeBuds 7
真无线耳机

使用说明书
使用前请阅读使用说明书

## 产品使用说明

1. 佩戴耳机时，请将耳机放入耳朵内，并轻轻按压耳机外侧的按钮。
2. 如需取下耳机，请将耳机从耳朵内轻轻取出。
3. 如需检查耳机的电量，请将耳机放入充电盒内，盖上盒子并查看耳机指示灯。
4. 如需配对蓝牙设备，请打开设备的蓝牙功能，并按照设备提示操作。
5. 请勿将产品置于高温环境或暴露在极端天气条件下。
6. 请勿将本产品拆解或改装，以免影响产品性能和安全性。

## 产品规格

型号/型号：PAXA
外观颜色：白色
单元直径：10mm
重量：耳机：4.5 g（每只耳机）
充电盒：45 g
耳机电池容量：30 mAh
充电盒电池容量：500 mAh
充电时间：耳机：1.5小时
充电盒：2小时
续航时间：单次：6小时（不含充电盒）
总计：24小时（含充电盒）
蓝牙版本：5.3
蓝牙协议：HFP、A2DP、AVRCP
蓝牙频率：2.402-2.480 GHz
蓝牙距离：10米（无障碍物）
防水等级：IPX4（防溅水）
工作温度：0°C-40°C
存储温度：-20°C-45°C
兼容性：iOS 10.0及以上版本，Android 5.0及以上版本

## 充电盒规格

充电接口：USB-C
充电时间：1.5小时
容量：500 mAh
电压：5V
尺寸：65 mm × 45 mm × 25 mm
重量：45 g
材质：塑料
颜色：白色
工作温度：0°C-40°C
存储温度：-20°C-45°C

## 产品操作说明

1. 开机
开机：将耳机从充电盒取出后自动开机。
关机：长按耳机触摸区域3秒，听到提示音后，耳机将关机。
2. 配对
方式一：长按耳机触摸区域3秒，耳机进入配对模式，在设备蓝牙设置中搜索并连接“PAXA FreeBuds 7”即可完成配对。
方式二：长按耳机触摸区域5秒，耳机进入配对模式，在设备蓝牙设置中搜索并连接“PAXA FreeBuds 7”即可完成配对。
3. 重置
方式一：将盒子放入充电盒，盖上盒子，等待5秒后重新开启耳机，即可恢复出厂设置。
方式二：长按耳机触摸区域10秒，耳机将进入恢复出厂设置模式，完成后耳机将自动关机。
4. 触摸控制
单击：暂停/播放音乐
双击：接听电话
三击：拒绝电话
长按：切换降噪模式（开启/关闭/透明模式）
5. 语音助手
长按耳机触摸区域2秒，唤醒语音助手（需设备支持）。
6. 降噪模式
开启：长按耳机触摸区域2秒，进入降噪模式。
关闭：长按耳机触摸区域2秒，关闭降噪模式。
透明模式：长按耳机触摸区域2秒，进入透明模式，以保持对外界声音的感知。
7. 充电
将耳机放入充电盒内，盖上盒子，即可开始充电。
充电时，耳机指示灯会显示充电状态，充电完成后，指示灯将熄灭。
8. 注意事项
请勿将耳机放入水中或长时间暴露在潮湿环境中。
请勿将耳机与其他设备共用一个充电盒，以免影响充电效果。
请勿拆解耳机，以免损坏内部电路。
请勿将耳机放置在儿童或宠物可接触的地方，以免误吞。
请勿在佩戴耳机时进行剧烈运动，以免耳机脱落。
请勿在佩戴耳机时长时间调高音量，以免损伤听力。
请勿在佩戴耳机时进行需要高度专注的工作，以免影响安全。
请勿在佩戴耳机时进行需要高度专注的工作，以免影响安全。
请勿在佩戴耳机时进行需要高度专注的工作，以免影响安全。

## 产品中有害物质名称及含量

产品中有害物质名称及含量

| 部件名称 | 有害物质 | | | | | |
|---|---|---|---|---|---|---|
| | 铅(Pb) | 汞(Hg) | 镉(Cd) | 六价铬(Cr(VI)) | 多溴联苯(PBB) | 多溴二苯醚(PBDE) |
| 印刷电路板 | ○ | ○ | ○ | ○ | ○ | ○ |
| 外壳及金属部件 | ○ | ○ | ○ | ○ | ○ | ○ |
| 电池 | ○ | ○ | ○ | ○ | ○ | ○ |
| 充电盒 | ○ | ○ | ○ | ○ | ○ | ○ |
| 线缆 | ○ | ○ | ○ | ○ | ○ | ○ |

## 保修卡

| | | | |
|---|---|---|---|
| 客户姓名 | | 电话/邮件 | |
| 购买日期 | | 经销商 | |
| 保修期 | | | |
| 产品名称 | | 产品型号 | |
| 产品序列号 | | | |
| 客户签名 | | | |
| 经销商盖章 | | | |

## FCC声明

根据FCC规则第15部分，本设备经测试，符合B类数字设备的限制。这些限制旨在为住宅安装提供合理保护，以防止有害干扰。本设备会产生、使用并可辐射无线电频率能量，如果不按照说明书安装和使用，可能会对无线电通信造成有害干扰。但是，不保证在特定安装中不会发生干扰。如果您的设备对无线电和电视接收造成有害干扰，可通过关闭设备来确定，并尝试以下措施：

- 重新定向或重新安装接收天线。
- 增加设备与接收器之间的距离。
- 将设备连接到与接收器不同的电路上的插座。
- 请经销商或有经验的无线电/电视技术人员以获得帮助。

此设备符合FCC规则第15部分。操作须满足下列两个条件：

1. 该设备不会产生有害干扰；
2. 该设备必须接受任何干扰，包括会导致意外操作的干扰。

未经负责方明确批准的变更或改装，可能会导致您对该设备的操作权限失效。

## 保修卷

| | | | |
|---|---|---|---|
| 客户姓名 | | 电话/邮件 | |
| 购买日期 | | 经销商 | |
| 保修期 | | | |
| 产品名称 | | 产品型号 | |
| 产品序列号 | | | |
| 客户签名 | | | |
| 经销商盖章 | | | |

PAXA

PAXA FreeBuds 7
True Wireless Earphones

Instruction manual
Please read the instruction manual before use

## Usage Instruction

1. Wearing the Earbuds: Place the earbud in your ear and lightly press the exterior earbud button.
2. Removing the Earbuds: Gently remove the earbud from your ear.
3. Checking Battery Status: Place the earbuds in the charging case, close the case and check the battery status indicator.
4. Connecting Bluetooth Devices: Turn on Bluetooth on your device and follow the prompts to connect.
5. Avoid Extreme Conditions: Do not expose the product to extreme temperatures or adverse weather conditions.
6. Do Not Disassemble: Do not attempt to disassemble or modify the product to ensure its performance and safety.

## Charging compartment

Charging case specification
Dimensions: 65mm × 45mm × 25mm
Weight: 45 g
Battery capacity: 500mAh
Charging time: approximately 1.5 hours (headphones)
Charging time: approximately 60 min (for headphones)
Rated input: 5V⎓1.5A
Charging case specification
Battery capacity: 500mAh
Charging time: Earbuds: approximately 1 hours
Charging case: 2 hours
(All technical information is subject to actual performance)
Charge the Charging case
Connect the Type-C cable to the TV power adapter, and overboard to the charging port of the Charging case.

## Product operating instructions

1. Wearing the Headphones: Insert the earbud into your ear and gently press the exterior earbud button.
2. Removing the Headphones: Gently remove the earbud from your ear.
3. Checking Battery Status: Place the earbuds in the charging case, close the case and check the battery status indicator.
4. Connecting Bluetooth Devices: Turn on Bluetooth on your device and follow the prompts to connect.
5. Avoid Extreme Conditions: Do not expose the product to extreme temperatures or adverse weather conditions.
6. Do Not Disassemble: Do not attempt to disassemble or modify the product to ensure its performance and safety.

## Name and content of hazardous substances in products

Name and content of hazardous substances in products

| Part Name | Hazardous substances | | | | | |
|---|---|---|---|---|---|---|
| | Pb | Hg | Cd | Cr(VI) | PBB | PBDE |
| Printed Circuit Boards | ○ | ○ | ○ | ○ | ○ | ○ |
| Metal structural parts and shell | ○ | ○ | ○ | ○ | ○ | ○ |
| Battery | ○ | ○ | ○ | ○ | ○ | ○ |
| Charging box | ○ | ○ | ○ | ○ | ○ | ○ |
| Cable | ○ | ○ | ○ | ○ | ○ | ○ |

## Warranty Service

Warranty Card

| | | | |
|---|---|---|---|
| Customer Name | | Phone/Email | |
| Purchase Date | | Dealer | |
| Contact number | | Postal code | |
| Mailing address | | | |
| Product name | | Product number | |
| Product serial number / Customer Signature | | | |
| Dealer stamp | | | |
| Name | | | |
| Address | | | |
| Contact number | | | |
| Date of sale | | Postal code | |
| Remark | | Invoice number | |

Manufacturer: Shanghai Weihongtang Culture Communication Co., Ltd.
Address: No. 1/F, Rooms Beiwach, Hengsha Township, Chongming District, Shanghai (Shanghai Hengsha Economic Development Zone)

## FCC Statement

According to Part 15 of the FCC Rules, this device has been tested to comply with the limits for Class B digital devices. These restrictions are designed to provide reasonable protection against harmful interference in residential facilities. The device generates and uses radio frequency energy, and if it is not installed and used in accordance with the instructions, it may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a specific installation. If this device causes harmful interference to radio or television reception, the device can be determined by turning it off and on. If the user can correct interference by the following one or several more measures below:

- Adjust or reposition the receiving antenna.
- Increase the distance between device and receiver.
- Sockets connected to devices on circuits different from the receiver are connected.
- Please consult a dealer or experienced radio/TV technician for assistance.

This device complies with Part 15 of the FCC Rules. The operation is met subject to the following two conditions:
(1) The device shall not cause harmful interference.
(2) The device must accept any interference received, including interference that may cause unexpected operation.
Changes or modifications that are not explicitly approved by the manufacturer responsible party may invalidate the user's permission to operate the device.
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.

PAXA

PAXA FreeBuds 7
Écouteurs sans fil vrais

Instructions d'utilisation
Lire le mode d'emploi avant utilisation

## Introduction à l'utilisation du produit

1. Porter les écouteurs : Mettez la ou les oreillettes dans votre oreille et appuyez légèrement sur le bouton extérieur.
2. Retirer les écouteurs : Retirez doucement les écouteurs hors de votre oreille.
3. Vérifier l'état de la batterie : Placez les écouteurs dans le boîtier de charge, fermez le boîtier et vérifiez l'état de la batterie.
4. Connecter des appareils Bluetooth : Activez le Bluetooth sur votre appareil et suivez les instructions pour connecter.
5. Éviter les conditions extrêmes : Ne pas exposer le produit à des températures extrêmes ou à des conditions météorologiques défavorables.
6. Ne pas démonter : Ne pas tenter de démonter ou de modifier le produit pour garantir sa performance et sa sécurité.

## Spécifications du produit

Version Bluetooth : V5.4
Distance de transmission : 10M
Capacité de la batterie : 30mAh
Durée d'utilisation : environ 5 heures (casque)
Temps de charge : environ 45 min (casque)
Entrée nominale : 5V⎓1.5A
Spécifications du boîtier de charge
Capacité de la batterie : 500mAh
Temps de charge : environ 2 heures
Entrée nominale : 5V⎓1.5A
(toutes les informations techniques sont soumises aux performances réelles)
Chargez le boîtier de charge
Connectez le câble de charge 3 à l'adaptateur vers la TV avec le câble de charge 3 pour ↔

## Instructions de fonctionnement du produit

1. Allumer
Méthode 1 : Les écouteurs s'allument automatiquement lorsque l'on sort le boîtier de charge.
Méthode 2 : Appuyez et maintenez la touche tactile des écouteurs pendant 3 secondes, les écouteurs s'allument.
2. Éteindre
Méthode 1 : Remettez les écouteurs à l'intérieur du chargeur et ils s'éteindront.
Méthode 2 : Maintenez enfoncé le capteur tactile de l'écouteur pendant 3 secondes pour l'éteindre.
3. Fonctions
Pause / Lecture : Appuyez sur le capteur tactile pendant 1 seconde.
Répondre / Raccrocher : Appuyez sur le capteur tactile pendant 1 seconde.
Rejeter un appel : Appuyez sur le capteur tactile pendant 2 secondes.
Activer/Désactiver Siri : Appuyez sur le capteur tactile pendant 2 secondes.
4. Réduction du bruit
Écouteurs droits : Appuyez sur le capteur tactile pendant 2 secondes pour activer/désactiver le mode de réduction du bruit.
Écouteurs gauches : Appuyez sur le capteur tactile pendant 2 secondes pour activer/désactiver le mode transparence.
5. Indicateur LED
Les écouteurs droits et gauches clignotent en rouge : Les écouteurs sont en cours de charge.
Les écouteurs droits et gauches clignotent en bleu : Les écouteurs sont en cours de jumelage