# DAREU

## User Manual

Transmitter x 1

**A710-WIRELESS**

Dongguan Tegran Electronics Technology Co., Ltd
Joint No.202 Shidun Rd, 3rd Industrial Park, Xuishe Area,
Shijie Town, Dongguan City, China 523490
Tel: +86 769 8630 8806   Fax:+86 769 8630 8836
Email: info@besno.com   CS@besno.com
Web: www.besno.com

User manual x1

Headphone x1

Cloth ear pad x 2

Detachable mic x 1

Type-c to USB adapter x1

3.5mm audio cable  x1

Type-c cable  x1

90mm

202mm

216mm

## ⬡ Product parameter

### Basic parameter

Battary: 1400mAh

Weight: 345g

Backlight: RGB

Microphone: detachable

Size: 202*216*90mm

3.5mm cable length: 1m(male to male)

Type-c cable length: 1.2m(male to male)

### Electronics parameter

Play mode: 5.8G/Type-c/3.5mm

Wireless standard: 5.8G

Frequency range: 5725-5850MHz

RF Range: 10M（unobstructed）

Charging Voltage: DC 5V 500mA

Charging Time: appr 4h

Working Time: appr 10h(lighting on)

appr 12h(lighting off)

Standby time: 3 months

### Speaker parameter

Drive unit : Φ50mm * 10 mm(H)

Sensitivity : 104dB±3dB

Impedance: 24±15% OHMS

Frequency response: 20~20KHz

Total harmonic distortion: ≦ 5%

Power rating: 10mW-15mW(max)

Buzz & Rating: sine wave 0.49V

Load test: normal 10mW 24 hours

### Microphone parameter

Drive unit: φ6mm * 2.7mm(H)

Sensitivity: -42±3 dB

Directivity: omnidirectional

Impedance: 2.2KOHMS

Frequency response: 100~10KHz

Total harmonic distortion: ≦ 5%

Operating voltage: DC 1.0V~10V

Current consumption: Max 0.5mA

## Function

① Lighting button      ② Power button      ③ Mic button

④ Volume button      ⑤ Indicator LED      ⑥ Type-c jack

⑦ Audio jack      ⑧ Mic jack

## 5.8G pairing

1.Insert 5.8G transmitter in device, headset and launcher will be paired automatically.

2.Long press the power button and the Mic button for 3s to enter mandatory pairing, the headset indicator LED flash blue quickly. After the pairing is successful, the indicator LED is always on.

## Audio cable

Use 3.5mm audio cable to connect headphone and playback devices directly, without turning on the power.

## Button function details

**1.Power button:** long press for 3s, turn on with one beep; long press for 3s, turn off with one beep.

**2.Lighting button:** flowing RGB light effect and four color (red, green, blue, purple) single breathing light effects.

**3.Mic button:** press once, turn on with two beeps, turn off with one beep.

**4.Volume button:** rolling the button to increase or decrease volume.

**5.Low power:** when the battery low power, the sound will beep three times every one minute.

**6.Indicator LED:**
①Power on-flashing blue color
②Low power-flashing red color
③Charging- flashing red color
④Full charge- LED turn off
⑤Fast flashing blue color-5.8G pairing

**7.Choose working mode which you want to play.**
①Type-c to type-c      ② Type-c to USB
③Audio output mode      ④ 5.8G wireless mode

## ⌒ How to replace ear pad



① Seam is at the bottom.　② Buckle on the gap.

③ Insert it into the gap.　④ Rotate gently.

# A710-WIRELESS