GUESS
EST. 1981

WIRELESS EARPHONES
STUDIO QUALITY SOUND

User Manual

*Please read this manual carefully before use
* Different models, different graphics, pictures for reference only

Usage Instruction:

1.Don't attempt to disassemble the unit and change any part, except there is operation method mentioned in the manual.
2.Do not expose the product to water, liquid, moisture or humidity, since it is not a waterproof product.
3. Disconnect the unit with your BT Version device and move it to a cool place if it gets too hot during charging.
4. Don't submerge or disassemble the unit to avoid injury, shock, if there is water on your hands.
5. Do not use the product near any heat sources, temperature or degree of the unit in fire or in a place with an explosion. Follow all local laws and regulations regarding electronic interference equipment in specific locations.

Description:

Content:

Earphones
Type-C USB Charging cable
User Guide

Product Specifications:

Model: GUESS TWS
BT Version: V5.0
Bluetooth Range: 10M
Headphone battery: 35mAh
Charging time: about 1.5 hour (earphone)
Charging time: about 1.5 hour (earphone)
Mode: Stereo

Case Specifications:

Case Battery: 300mAh
Charging time: about 1.5 hours
Type-C: Charging

Charging time information is subject to actual performance

To Charge the case:

Connect the Type-C cable to the 5V power adapter, and another end to the charging port of the Charging Case.

Made in China

LED Indicator Status:

- Low Battery: The LED indicator (red) flashes in white.
- Pairing Mode: The LED indicator (blue) flashes in white.
- Pairing Success: The LED indicator (blue) flashes in white.
- Charging: The LED indicator (red) is solid when charging, and turns off when the battery is fully charged.
- The Charge Time Exceeds Limits: LED indicator (red) flashes in 10 minutes that the battery is low.
- Power Off: The LED indicator (red) flashes 3 times, then turns off.

Product operating instructions:

1. Pairing:
Press and hold the the BTF button of the ear phone for 3s to turn on the earphone.

2. Turn off:
Put the earphones into the charging case and turn off the earphone switch.

3. Pairing to the BT Version device
Activate the BT function on your mobile device, search and select the "GUESS TWS" from the list of available BT devices. (Initial connection required only)

Control:

Touch during music

- Left/Right earphone operating:

Pause: Single press the left or right button of one Earphone to pause playing the music.
Play: Single press the left or right button of the other Earphone to play the music.
Volume Control: Double press the left or right button of one Earphone to adjust the volume.
Switch Music: Triple press the left or right button of one Earphone to switch the music.
Turn off: Press and hold the left or right button of one Earphone for 2 seconds to turn off the earphone.

Hands-free phone calls: Following left.

- Left/Right earphone operating:

Answer a call: Single press the left or right button of any earphone 2 times to answer the call.
End a call: Press and hold the button of the earphone for 2 seconds to end the call.
Reject a call: Press the BT button of any earphone for 2 seconds to reject the call.

Turn on the Voice Assistant function: Following Assistant.

- Voice Assistant: Press and hold the button of any earphone for 2 seconds to turn on the voice assistant.

Reset:

When you turn on the earphone, make sure it does not connect to the last paired device. Then turn off the earphone. Enter the pairing mode, then turn off the earphone.

Name and content of hazardous substances in products:

Part name	Hazardous substances					
	Pb	Hg	Cd	Cr6+	PBB	PBDE
Circuit board components	×	○	○	○	○	○
Charging cable and accessories	×	○	○	○	○	○

This form is prepared in accordance with SJ/T 11364.
○: Indicates that the content of the toxic and hazardous substance in all homogeneous materials of the parts is less than the limit specified in GB/T 26572 "Requirements for the Allowable Content of Toxic and Hazardous Substances in Electronic and Electrical Products".
×: Indicates that the content of the toxic and hazardous substance in at least one homogeneous material in the parts exceeds the limit specified in GB/T 26572 "Requirements for the Allowable Content of Toxic and Hazardous Substances in Electronic and Electrical Products".

Artwork is for illustration purposes only. Specifications are subject to change without notice.
Contact your local customer service center for information on the product's hazardous substances and their content, including a complete list of hazardous substances.

Warranty statement:

Dear ●●●●●,
The user manual does not have one-for-one warranty, and some operation methods may be different from the actual product. Please refer to the information and its reference only, and the content ●●●● is for updated on the website or on-line, without additional notification.
Thank you for your understanding.
The product attached to this document is guaranteed not ●●●● a thousand or ●●●● 20 months from the date of purchase. If the very product ●●●● is found to be defective within the ●●●● period, we will be responsible for the repair or replacement. The manufacturer reserves the right to decide ●●●● the repair or replacement of the product. If the product is not within the warranty, during the remaining warranty period (the period of ●●●● warranty minus the time ●●●● the product was in use), we will charge ●●●● the cost of repair or replacement. The warranty ●●●● does not ●●●● the following situations:
1. Damage caused by ●●●● use of the product in a manner inconsistent ●●●● its intended purpose or in a manner inconsistent ●●●● the instructions ●●●● the product.
2. Damage caused by ●●●● use of the product under ●●●● conditions ●●●● exceeding the specified ●●●● limits.
3. Damage caused by ●●●● use of the product ●●●● exceeds ●●●● specified limits.
4. Damage caused by misuse, abuse or improper transportation, use, storage or maintenance of the product.
5. Failure or damage caused by force majeure (such as earthquake, war, fire, etc.) or accident.
6. Damage caused by ●●●● use of non-●●●● accessories.
7. Disassembled or repaired ●●●● by ●●●● other than ●●●● or ●●●● authorized ●●●● service ●●●● center.
8. Products with signs of burning or ●●●●.
9. Products with signs of ●●●● or ●●●●.
10. Aging, deformation, deformation, corrosion and other ●●●● caused by ●●●● use ●●●● time.
11. The ●●●● of the ●●●● product ●●●● has ●●●● been ●●●● or damaged ●●●● due ●●●● to ●●●● the ●●●● product ●●●● being ●●●● used ●●●● in ●●●● the ●●●● process ●●●● of ●●●● disassembling ●●●● and ●●●● are ●●●● within ●●●● the ●●●● scope ●●●● of ●●●● the ●●●● guarantee. You ●●●● should ●●●● in ●●●● the ●●●● spot ●●●● and ●●●● obtain ●●●● a ●●●● receipt.
The above guarantee ●●●● is ●●●● an ●●●● overview ●●●● regarding ●●●● the ●●●● products, and ●●●● in ●●●● the ●●●● event ●●●● of ●●●● there ●●●● is ●●●● any ●●●● discrepancy ●●●● between ●●●● the ●●●● above ●●●● and ●●●● the ●●●● actual ●●●● product, ●●●● the ●●●● actual ●●●● product ●●●● shall ●●●● prevail.
Thank you for your understanding and cooperation!

FCC Warning:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.
This device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restrictions.

CE FC IC
FCC ID: 2AHJ4-GST
Model: GST-001

Designed in France, Made in China

Disposal information
Do not throw away this product with your other rubbish at the end of its useful life. Take it to a collection point for the recycling of electrical and electronic equipment.

GUESS
EST. 1981

SŁUCHAWKI BEZPRZEWODOWE
DŹWIĘK JAKOŚCI STUDYJNEJ

Instrukcja obsługi

*Przed użyciem należy uważnie przeczytać niniejszą instrukcję
* Różne modele, różne grafiki, zdjęcia wyłącznie w celach informacyjnych

Instrukcja użytkowania:

1. Nie próbuj rozbierać urządzenia ani wymieniać żadnej części, chyba że w instrukcji obsługi jest podana taka procedura.
2. Nie narażaj produktu na kontakt z wodą, płynami, wilgocią, ponieważ nie jest wodoodporny.
3. Jeśli do urządzenia dostanie się ciecz, odłącz je od urządzenia Bluetooth i przenieś je w chłodne miejsce.
4. Aby uniknąć ran lub obrażeń urządzenia, aby uniknąć zwarcia prądem, zwarciu lub pożarowi wokół ciebie.
5. Nie narażaj produktu na ogień, źródła ciepła, temperaturę lub stopień urządzenia w ogniu lub w miejscu z eksplozją. Przestrzegaj wszystkich lokalnych przepisów i regulacji dotyczących urządzeń elektronicznych w konkretnych miejscach.

Opis:

Zawartość:

Słuchawki TWS
Kabel ładujący USB Typ-C
Instrukcja obsługi

Specyfikacja produktu :

Model: GUESS TWS
Wersja Bluetooth: V5.0
Zasięg Bluetooth: 10M
Bateria słuchawek: 35 mAh
Czas ładowania: około 1,5 godziny (słuchawki)
Czas ładowania: około 1,5 godziny (słuchawki)
Tryb pracy: Stereo

Specyfikacja pouzdra :

Bateria etui: 300 mAh
Czas ładowania: około 1,5 godziny
Typ-C: Ładowanie

Wszystkie dane techniczne zależą od rzeczywistej wydajności

Aby naładować etui:

Podłącz kabel Type-C do zasilacza 5V, a drugi koniec do portu ładowania etui.

Made in China

Status wskaźnika LED:

- Niska bateria: wskaźnik LED miga na biało.
- Aby włączyć tryb parowania: wskaźnik LED miga powoli na biało podczas łączenia z urządzeniem Bluetooth.
- Sukces parowania: wskaźnik LED miga na biało.
- Po naładowaniu: wskaźnik LED świeci się na biało podczas ładowania, gdy bateria jest całkowicie naładowana, wskaźnik gaśnie.
- Przekroczenie limitu czasu ładowania: wskaźnik LED świeci się na biało przez 10 minut, gdy bateria jest całkowicie naładowana, wskaźnik gaśnie.
- Wyłączanie: wskaźnik LED miga 3 razy, a następnie wyłącza się.

Instrukcja obsługi produktu:

1. Włączanie:
Naciśnij i przytrzymaj przycisk BT na słuchawce przez 3 sekundy, aby je włączyć.

2. Wyłączanie
Włóż słuchawki do etui ładującego, aby je wyłączyć.

3. Parowanie z urządzeniem Bluetooth
Aktywuj funkcję Bluetooth na urządzeniu mobilnym i wybierz „GUESS TWS" z listy dostępnych urządzeń Bluetooth. (Wymagane jednorazowe połączenie)

Reset:

Po włączeniu słuchawek zamknij się, że nie są podłączone z ostatnio sparowanym Bluetooth. Następnie ponownie włącz tryb parowania, a następnie wyłącz słuchawki.

Sterowanie:

Dotykowe muzyki

- Obsługa lewego/prawego słuchawki:

Pauza: Pojedyńcze naciśnięcie przycisku prawego lub lewego słuchawki, aby wstrzymać odtwarzanie.
Odtwarzanie: Pojedyńcze naciśnięcie przycisku prawego lub lewego słuchawki, aby wznowić odtwarzanie.
Głośność: Dwukrotne naciśnięcie przycisku prawego lub lewego słuchawki, aby wybrać dostępną konfigurację.
Zmiana utworu: Potrójne naciśnięcie przycisku prawego lub lewego słuchawki, aby przełączyć się na inną ścieżkę.
Wyłącz: Naciśnij i przytrzymaj przycisk prawego lub lewego słuchawki przez 2 sekundy, aby wyłączyć słuchawkę.

Połączenia bez użycia rąk: Zgodnie z lewą stroną.

- Obsługa lewego/prawego słuchawki:

Odbierz połączenie: Naciśnij lewy lub prawy przycisk słuchawki 2 razy, aby odebrać połączenie.
Rozłącz się: Naciśnij i przytrzymaj przycisk słuchawki przez 2 sekundy, aby zakończyć połączenie.
Odrzuć połączenie: Naciśnij i przytrzymaj przycisk BT na dowolnej słuchawce przez 2 sekundy, aby odrzucić połączenie.

Włączanie asystenta głosowego: Zgodnie z asystentem.

- Asystent głosowy: Naciśnij i przytrzymaj przycisk na dowolnej słuchawce przez 2 sekundy, aby włączyć asystenta głosowego.

Reset:

Po włączeniu słuchawek upewnij się, że nie są połączone z ostatnio sparowanym urządzeniem Bluetooth. Następnie wyłącz słuchawki. Wejdź w tryb parowania, a następnie wyłącz słuchawki.

Nazwa i zawartość substancji niebezpiecznych w produktach:

Nazwa części	Substancje niebezpieczne					
	Pb	Hg	Cd	Cr6+	PBB	PBDE
Komponenty obwodu drukowanego	×	○	○	○	○	○
Ładowarka i akcesoria	×	○	○	○	○	○

Tabela jest przygotowana zgodnie z SJ/T 11364.
○: Oznacza, że zawartość toksycznej i niebezpiecznej substancji w wszystkich jednorodnych materiałach części jest niższa niż limit określony w GB/T 26572 „Wymagania dotyczące dopuszczalnej zawartości toksycznej i niebezpiecznej substancji w produktach elektronicznych i elektrycznych".
×: Oznacza, że zawartość toksycznej i niebezpiecznej substancji w co najmniej jednorodnym materiale w częściach przekracza limit określony w GB/T 26572 „Wymagania dotyczące dopuszczalnej zawartości toksycznej i niebezpiecznej substancji w produktach elektronicznych i elektrycznych".

Grafika jest tylko ilustracją. Specyfikacje mogą ulegać zmianie bez wcześniejszego powiadomienia.
Skontaktuj się z lokalnym centrum obsługi klienta, aby uzyskać informacje o produkcie, w tym o substancjach niebezpiecznych i ich zawartości, w tym pełną listę substancji niebezpiecznych.

Oświadczenie gwarancyjne:

Szanowne ●●●●●,
Niniejsza instrukcja obsługi nie posiada gwarancji, obowiązującej jeden ●●●●●, a niektóre ●●●●●