Original Instructions

Safety Instructions

Read all instructions before using.

How To Use

Setting Your Combination

Changing Your Combination

Resetting Your Combination

Opening Your Lock

Care

Cleaning Your Lock

Storage

Troubleshooting

Problem	Possible Cause	Solution
Lock does not open.	Incorrect combination.	Reset combination.
	Lock is jammed.	Contact Customer Service.
Lock does not open with correct combination.