Contents [hide]

1 Ollny HG-29V202WC 210 LEDs Net Lights
2 INTRODUCTION
3 SPECIFICATIONS
4 WHAT'S IN THE BOX
5 FEATURES
6 SETUP GUIDE
7 CARE & MAINTENANCE
8 TROUBLESHOOTING
9 PROS & CONS
10 WARRANTY
11 FREQUENTLY ASKED QUESTIONS
12 VIDEO – PRODUCT OVERVIEW
13 References

Ollny HG-29V202WC 210 LEDs Net Lights



INTRODUCTION

The Ollny HG-29V202WC 210 LEDs Net Lights, which are reasonably priced at **$23.99,** will add flair to your holiday décor. With their warm white glow that creates a pleasant and festive atmosphere, these 10×7-foot mesh lights are ideal for adorning trees, shrubs, walls, ceilings, or any other large area. Because the net lights are end-to-end connectable, up to three sets (630 LEDs) can easily cover bigger places, which makes them perfect for celebrations of Thanksgiving, Halloween, Christmas, and birthdays. You can adjust the illumination to fit your mood or event theme with these lights' eight lighting modes and four brightness settings. While the memory feature and three timers (4H, 6H, and 8H) allow automatic illumination without requiring a daily reset, the IP67 waterproof design guarantees longevity and dependability in all weather circumstances. These energy-efficient, kid-safe lights have a low output of 29V, making them appropriate for both indoor and outdoor use. The Ollny HG-29V202WC net lights are a flexible complement to any holiday décor arrangement and are simple to install and operate with the accompanying remote.

SPECIFICATIONS

Brand	Ollny
Price	$23.99
Color	Warm White
LED Quantity	210 LEDs
Size	10×7 ft

Indoor/Outdoor Usage	Indoor, Outdoor
Power Source	Corded Electric
Voltage	29 Volts
Wattage	6 watts
Material	Copper, Plastic
Special Features	Connectable up to 3 sets (630 LEDs), IP67 Waterproof, 8 Lighting Modes, 4 Brightness Levels, Memory Function, 3 Timer Settings
Controller Type	Remote Control
Control Method	Remote
Bulb Shape	B10
Bulb Base	GX5.3
Number of Items	1
Batteries Included	1 × CR2032 (for remote)
Water Resistance Level	IP67
Style	Modern
Occasion	Birthday, Christmas, Halloween, Thanksgiving

WHAT’S IN THE BOX

- 1 × 210LED Net Lights (10x7ft)
- 1 × Plug
- 1 × Remote Control (with 1 CR2032 battery included)
- 1 × User Manual

FEATURES

- **Large Coverage:** Measures 10x7ft, ideal for decorating bushes, walls, ceilings, or trees, providing extensive coverage for festive setups.
- **210 LED Bulbs:** Equipped with warm white LEDs that deliver bright, even, and cheerful illumination for holiday or event décor.

- **Connectable Sets:** Multiple net lights can be linked together—up to 3 sets—for a total of 630 LEDs, perfect for large-scale decoration projects.

- **8 Lighting Modes:** Offers versatile lighting patterns including steady on, wave, sequential, slo-glo, chasing flash, fade, twinkling, and combination effects.

- **4 Brightness Levels:** Dimmable settings allow you to adjust light intensity to create a subtle or vibrant festive ambiance.

- **Remote Control Operation:** Easily adjust lighting modes, brightness, and timers from a distance for convenient control.
- **3 Timer Functions:** Set lights to automatically turn off after 4H, 6H, or 8H daily, saving energy and reducing manual effort.

- **IP67 Waterproof Rating:** Fully weatherproof and durable, able to withstand rain, snow, and outdoor conditions without damage.

- **Safe Low Voltage:** Operates at 29V to prevent overheating, ensuring safe usage indoors and outdoors.
- **Memory Function:** Remembers the last mode and timer settings, eliminating the need to reset every day.
- **Copper Wire Construction:** Flexible and long-lasting wiring allows easy shaping around trees, walls, or ceilings while maintaining durability.
- **Energy Efficient:** Total power consumption is only 6 watts, making it cost-effective for extended use.
- **B10 Bulb Shape:** Stylish and bright bulb design adds a decorative and modern touch to any holiday or event décor.
- **Indoor/Outdoor Use:** Suitable for both interior spaces and outdoor landscapes, offering versatile decoration options.
- **Lightweight Design:** Easy to hang, drape, or secure on walls, bushes, ceilings, or fences without hassle.

SETUP GUIDE

- **Unpack the Lights:** Remove the 210 LED net, power plug, and remote from packaging.
- **Check Remote Battery:** Insert a CR2032 battery to ensure the remote works properly.
- **Select Installation Area:** Choose your target location, such as a bush, wall, ceiling, or tree.
- **Spread Out Net Lights:** Carefully unfold the net to avoid tangling or twisting the wires.
- **Connect Sets if Needed:** Link up to 3 sets end-to-end for larger coverage areas.
- **Plug In:** Insert the power plug into a 29V AC outlet for electricity.
- **Power On Lights:** Use the remote or manual switch to turn the lights on.
- **Select Lighting Mode:** Choose from 8 lighting modes to create your desired festive effect.
- **Adjust Brightness:** Set the dim level from 4 available options to match the ambiance.
- **Set Timer:** Activate the 4H, 6H, or 8H timer for automated daily operation.
- **Secure Lights:** Use hooks, zip ties, or fasteners to hold the net firmly on walls, bushes, or ceilings.
- **Check LED Functionality:** Ensure every bulb is working and glowing evenly.
- **Avoid Sharp Bends:** Handle the wires carefully to prevent kinks or breaks.
- **Test Timer Function:** Verify that the automatic on/off timer works correctly.
- **Enjoy Decoration:** Admire a beautifully lit space that enhances your festive or party environment.

CARE & MAINTENANCE

- **Clean LEDs Gently:** Wipe bulbs with a soft cloth to remove dust and maintain brightness.
- **Protect Remote from Moisture:** Keep the remote dry to prevent battery or circuit damage.
- **Inspect Wires Regularly:** Check for frayed wires or damage to ensure safety and performance.
- **Replace Burned-Out LEDs:** Swap out any defective bulbs immediately for consistent lighting.
- **Store Properly:** Use the original packaging or a storage reel to prevent tangling and

damage.

- **Avoid Overstretching:** Maintain natural wire tension to preserve wire integrity.
- **Keep Away from Sharp Edges:** Prevent cuts or damage to the copper wires during installation.
- **Check Timer Settings:** Ensure timers are correctly set for automated operation.
- **Test Before Each Use:** Verify all modes, bulbs, and brightness levels are functioning.
- **Remove Snow or Debris:** Clear accumulated debris to maintain illumination and avoid damage.
- **Avoid High Heat Exposure:** Keep lights away from direct heat or flames to prevent melting or damage.
- **Check Waterproof Coating:** Inspect silicone or glue-filled bulbs to ensure weather resistance.
- **Handle Carefully During Hanging:** Prevent dislodging or breaking bulbs while positioning the net.

- **Replace Remote Battery as Needed:** Maintain proper control functionality by

swapping batteries when required.

- **Rotate Installation Spots:** Occasionally change locations to avoid prolonged UV exposure and wire fading.

TROUBLESHOOTING

Issue	Possible Cause	Solution
Lights not turning on	Power not connected	Check plug and outlet
Some LEDs not lighting	Burned out bulb	Replace defective LED
Remote not working	Battery low	Replace CR2032 battery
Timer not functioning	Incorrect setting	Reset timer and reprogram
Flickering lights	Loose connection	Reconnect plugs
Low brightness	Dim mode active	Adjust brightness level
Uneven lighting	LED spacing	Reposition net lights
Overheating	Prolonged power	Turn off periodically
Broken wire	Sharp bend or stress	Repair or replace wire
Tangled net	Improper storage	Rewrap properly
Water ingress	Damaged seals	Inspect and dry lights
Mode not changing	Remote interference	Ensure line of sight
Short circuit	Exposed wire	Repair insulation
Timer not saving	Memory chip issue	Reset remote and lights
Remote malfunction	Interference	Move away from electronic devices

PROS & CONS

Pros

- **Connectable Net** – Expandable up to 3 sets for large displays.
- **IP67 Waterproof** – Durable for outdoor weather conditions.
- **8 Modes & 4 Brightness Levels** – Customizable lighting options.
- **Memory & Timer Functions** – Convenient automatic operation.
- **Safe Low Voltage** – Suitable for indoor and outdoor use.

Cons

- **Corded Electric** – Requires a 29V AC outlet.
- **Fixed Size** – Net dimensions are 10x7ft; cannot be resized.
- **Remote Battery Replacement Needed** – CR2032 battery must be maintained.
- **Limited Connectable Sets** – Maximum of 3 sets.
- **Manual Hanging Required** – Installation may be time-consuming.

WARRANTY

The **Ollny HG-29V202WC 210 LED Net Lights** come with a **manufacturer warranty** covering defects in materials and workmanship. Ollny provides support for any issues with bulbs, wires, or remote control. If any defect occurs under normal use, the company offers repair guidance or replacement, ensuring long-lasting festive lighting for your home or yard.

FREQUENTLY ASKED QUESTIONS

What is the size of Ollny HG-29V202WC 210 LEDs Net Lights?

The Ollny HG-29V202WC net lights measure 10x7 ft and contain 210 LED bulbs, perfect for decorating trees, walls, ceilings, or bushes.

Can Ollny HG-29V202WC lights be connected together?

These net lights are end-to-end connectable up to 3 sets (total 630 LEDs) to cover larger areas.

How many lighting modes does Ollny HG-29V202WC have?

The Ollny HG-29V202WC features 8 lighting modes that can be controlled with the included remote to create different festive atmospheres.

How does the timer function work on Ollny HG-29V202WC?

The remote allows 3 timer settings 4H, 6H, or 8H so the lights automatically turn on at the set time every day without resetting.

What should I do if some bulbs on Ollny HG-29V202WC are not lighting?

Check for loose or damaged bulbs, ensure the plug is connected properly, and confirm the power source is functional. Replace any defective bulbs if necessary.

Why are my Ollny HG-29V202WC lights not responding to the remote?

Ensure the CR2032 battery in the remote is installed correctly and has power. Also, verify there are no obstructions between the remote and the lights.

How do I install Ollny HG-29V202WC net lights outdoors?

These lights are indoor/outdoor compatible, perfect for walls, ceilings, windows, trees, or holiday displays.

VIDEO – PRODUCT OVERVIEW

https://manuals.plus/wp-content/uploads/2025/09/Ollny-HG-29V202WC-210-LEDs-Net-Lights-User-Manual.mp4

References

- User Manual

Ollny

210 LEDs Net Lights, B01J3OD77Q, HG-29V202WC, Ollny, Ollny HG-29V202WC, user manual

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos

are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.