pai TECHNOLOGY 83122 Botzee Mini Screen-Free Coding Robot Instruction Manual

pai

Instruction Manual
Botzee mini
Screen-free Coding Robot

Contents

Product Information

Product Name: Botzees Mini
Product Number: 83122
Product Material: ABS plastic
Suitable Age: 3 years old and above
Manufacturer: Pai Technology Ltd.
Address: Building 10, Block 3, No.1016 Tianlin
Road, Minhang District, Shanghai, CHINA
Website: **www.paibloks.com**
Service Number: 400 920 6161

Product List:

Main Control

USB Cable

nstruction Card

Map

Features

LED lattice
display

Speaker

Switch
Status indicator

USB charging port

Track

Fill light
Camera

Power On/Power Off/Charging

Power On:
 Long press the power button for 2 seconds
Power Off:
Long press the power button for 2 seconds

lug the cable into the Micro USB
connector to charge the device.

Status Indicator:
Red: Charging
Green: charging completed

Line-tracking/Command Recognition

Identify the instruction card placed on the line.

Identify the instruction on the map.

Place the device on a black line and the device will start its line-tracking.

How to use the Instruction Card:

Notes:

1	2	3	4	5	6	7
Do	Re	Mi	Fa	Sol	La	Ti

Note: The device will play the corresponding note sound effect immediately after it recognizes the command during line tracking.

Movement & other commands

	Turn right: The device will turn right at the front intersection after recognizing this command during line-tracking
	Stop (Endpoint): The device will stop and play a victory sound as soon as it recognizes this command during line tracking.
	Turn left: The device will turn left at the front intersection after recognizing this command during line-tracking.
	Start: The device will play the Start sound as soon as it recognizes this command during line-tracking.
	Temporary stop: The device will stop for 2 seconds as soon as it recognizes this command during line-tracking.
	Treasure: The device will record a treasure and play corresponding sound effects after it recognizes this command during line tracking.

Paired with an RF device

The device is paired with other RF –supported hardware via a USB cable.

The motor turns clockwise for 2 seconds	The motor turns counterclockwise for 2 seconds	The steering gear rotates 90° clockwise	The steering gear rotates 90° counterclockwise	The recording module plays sound.	The light module lights up/goes out.

Please take attention that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.

1. The battery is not replaceable.

2. It shall be regularly examined for damage to the cord, plug, enclosure and other parts, and in the event of such damage, they must not be used until the damage has been repaired.

3. The toy is not to be connected to more than the recommended number of power supplies.

4. Rechargeable batteries are only to be charged under adult supervision.

Documents / Resources

	pai TECHNOLOGY 83122 Botzee Mini Screen-Free Coding Robot [pdf] Instruction Manual 83004, 2APRA83004, 83122 Botzee Mini Screen-Free Coding Robot, Botzee Mini Screen-Free Coding Robot

Manuals+,