PowerA XBX Enhanced Wired Controller User Manual

ENHANCED WIRED CONTROLLER

Xbox Button
Menu Button
A/B/X/Y Buttons
Program Button
Detachable 10ft USB Cable
Y
X B
A
AGR
AGL
D-Pad
Headset Dial
Headset Jack
View Button
Anti-friction Rings
Share Button
Advanced Gaming Buttons

TAP OR HOLD TO ADJUST WIRED HEADSETVOLUME (LEFT-DOWN, RIGHT-UP)

PRESS TO MUTE (RED) OR UNMUTE CHAT IN WIRED HEADSET.

CONTENTS

- PowerA Enhanced Wired Controller for Xbox
- Detachable 10ft USB Cable
- User Manual

Contents

SET UP

1. If your Xbox is off, connect the USB cable between an available USB port on your console and the Micro-USB port on your controller.
   Press the Xbox Button on the controller until the console powers on. The small white LED will illuminate to indicate a successful connection.
2. If your Xbox console is already on, simply connect the USB cable into any available USB port on the console and connect the Micro USB to your controller. The small white LED light should illuminate, indicating a successful connection.

NOTE: For player and controller assignment, reference your official Xbox users manual.

ASSIGNING THE ADVANCED GAMING BUTTONS

1. Press the Program Button on the back of the controller. The LED Connection Indicator will flash, signaling the

controller is in Assign Mode.

2. Press one of the following buttons (A/B/X/Y/ LB/RB/LT/RT/Left Stick Press/Right Stick Press/D-pad) to re-assign. Then press the Advanced Gaming Button (AGR or AGL) that you wish to assign. The LED connection indicator will stop flashing, signaling the Advanced Gaming Button has been set.

3. Repeat for the remaining Advanced Gaming Button.

NOTE: Advanced Gaming Button assignments will remain in memory even after disconnected.
RESETTING THE ADVANCED GAMING BUTTONS

1. Hold the Program Button down for 2 seconds.

The LED Connection Indicator will slowly flash, signaling the controller is in assign mode.

2. Press the previously assigned button, and the function will be cleared.

USING THE SHARE BUTTON
Refer to Xbox documentation for details on functions and features related to the Share button.
USING THE HEADSET DIAL
Plug your wired headset into the controller's 3.5mm stereo jack. The Volume Dial will light up red, indicating that your microphone is muted.
Depress the dial to unmute your mic. Press again to mute. To adjust your headset volume tap the dial left or right, or press and hold to adjust volume to minimum or maximum volume.
NOTE: Audio controls within Xbox settings will take first priority, followed by the Headset Dial, and finally any audio or mute controls on your headset. Refer to your Xbox and headset documentation for additional details.

TROUBLESHOOTING

For current FAQs, visit PowerA.com/support.
Q: Controller will not connect to Xbox console?
A: Confirm your Xbox console is powered "ON".
A: Confirm your TV is set to the proper video input and that you can see the Xbox console interface on your TV screen.
A: Confirm cable is properly connected to you Xbox console.
A: Confirm cable is properly connected to your
PowerA Enhanced Wired Controller.
Q: Controller is connected but has no function?
A: Confirm you are using the Player #1 controlleFor more troubleshooting refer to your Xbox console User Guide.

MOTION WARNING
Playing video games can make your muscles, joints, skin or eyes hurt. Follow these instructions to avoid problems such as tendinitis, carpal tunnel syndrome, skin irritation or eyestrain:

- Avoid excessive play. Take a 10 to 15 minute break every hour, even if you don't think you need it. Parents should monitor their children for appropriate play.

- If your hands, wrists, arms or eyes become tired or sore while playing, or if you feel symptoms such as tingling, numbness, burning or stiffness, stop and rest for several hours before playing again.

- If you continue to have any of the above symptoms or other discomfort during or after play, stop playing and see a doctor.

FCC STATEMENT
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Warning:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Note: This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to Part 15 of the FCC Rules.

CAN ICES-003(B)/NMB-003(B)
This device complies with Industry Canada license exempt RSS standard(s).Operation is subject to the following two conditions: (1) This device may not cause interference,and (2) this device must accept any interference, including interference that may cause undesired operation of the device.
MANUFACTURED BY
ACCO Brands USA LLC
4 Corporate Way, Lake Zurich, IL 60047
ACCOBRANDS.COM | POWERA.COM
MADE IN CHINA
AUSTRALIAN WARRANTY STATEMENT
This product comes with guarantees that cannot be excluded under the Australian Consumer Law.
You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage.
You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. If purchased within Australia or
New Zealand, this product comes with a One-year warranty from date of purchase. Defects in the product must have appeared within One year from date of purchase, in order to claim the warranty.
All warranty claims must be facilitated back through the retailer of purchase in accordance with the retailer's return policies and procedures.
Any expenses incurred, as a result of returning the product to the retailer of purchase are the full responsibility of the consumer.
AU WHOLESALE DISTRIBUTOR:
Level 2, 2 Darling Street South Yarra,
Australia VIC 3141
bluemouth.com.au
Email: **support@bluemouth.com.au**
+61 3 9867 2666

ADDITIONAL LEGAL

© 2021 ACCO Brands USA LLC. PowerA and PowerA Logo are trademarks of ACCO Brands Corporation. Microsoft, Xbox, Xbox "Sphere"
Design, Xbox Series X|S, Xbox One, and Windows are trademarks of the Microsoft group of companies. All other trademarks are the property of their respective owners.

REGIONAL COMPLIANCE SYMBOLS

More information available via web-search of eachsymbol name.
The WEEE (Waste of electrical and electronic equipment) symbol requires battery disposal outside of other household waste per local regulations.
Contact your city office, waste disposal service, or retailer for guidance.

The CE (Conformité Européene aka European Conformity) mark is a declaration from the manufacturer that the product meets applicable European
Directives and Regulations for health, safety, and environmental protection.

The UKCA (UK Conformity Assessment) mark is a declaration from the manufacturer that the product meets applicable UK Regulations for health, safety, and environmental protection.

The Regulatory Compliance Mark is a visible indication of a product's compliance with all applicable ACMA (Australian Communications and Media Authority) regulatory arrangements, including all technical and recordkeeping requirements regarding the electrical safety and/or electromagnetic compatibility (EMC).

DECLARATION OF CONFORMITY
Hereby, ACCO Brands USA LLC at 4 Corporate Way, Lake Zurich, IL 60047 USA, declares that this wired controller is in compliance with Directive 2014/30/EU. The full text of the EU Declaration of Conformity is available at the following internet address: **PowerA.com/compliance**

TWO YEAR LIMITED WARRANTY

For warranty details or support with your authentic PowerA accessories, please visit **PowerA.com/Support**.

PowerA.com/Support

Documents / Resources

	PowerA XBX Enhanced Wired Controller [pdf] User Manual XBX Enhanced Wired Controller, XBX, Enhanced Wired Controller, Wired Controller, Controller

References

- **ACCO Brands**
- **BDA - The Modern Merchandise Agency for Iconic Brands**
- **PowerA | PowerA**
- **PowerA | PowerA**
- **Declaration of Conformity | PowerA**
- **Support | PowerA**
- **User Manual**