QIACHIP KR2201WZ-Y ZigBee Cacle Gateway User Manual

QIACHIP

Zigbee Cacle Gateway manual

Contents

1 Lostevay connection method:
2 Login gateway method:
3 Adding ZigBee devices:
4 Equipment grouping:
5 Scenario:
6 Defense Area Management:
7 Record of events:
8 Gateway restore factory settings:
9 Matter function (in testing – Home Pod support only):
10 Documents / Resources
10.1 References

Lostevay connection method:

Connect he gty 105V pwe suly, and connec the LAN pr.
of the gateuay o he LAN port of e auer it anetwork bl ond he gateuay indestor tums green

Status	Indicator Color
Power on	White
Not connected to LAN	Red
Connected to LAN	Blue
Connected to WAN	Green
Gateway Reset	White Flashing

Login gateway method:

1.web settings:
A. Computer login
Make sure the computer is on the same LAN as the gateway. We recommend using Google Chrome to log in to the following URL (**http://foeegateway.local/**)

The following screen appears:
The following screen appears with the option to find a gateway Select

Gateway 1 to log in:

Or select the login gateway to login at:



Enter the gateway account and password to log in (available under the QR code on the back of the gateway) The gateway account and password are shown in the following example;



2. Mobile APP settings:

A Android:

Please scan the following QR code

APP for Android

Or visit the following website to download the APP: http://fbee.qiachip.com

1. After downloading the app. please enter the following registration page to register your account, After registration, please go to the login screen to lag in in order to enter the system interface:



B. IOS system:

Smart Home Link

Or visit the following website to download the APP https://apps.apple.com/us/app/smart-home-link/id644761440

1. After downloading the APP, the home page is shown below, select open



2. Please go to the following page to register your account.

   After registering, please go to the login screen and log in to the system interface:



3. Select ” + ” to add the gateway:



4. Choose to add scenes:



5. Defense zone management



1. Select “+ ” to add the gateway:



2. Choose to add scenes:



3. Defense zone management



Adding ZigBee devices:

Click Allow to enter the network in the gateway WEB gateway management page, the gateway indicator flashes alternately in red, blue, green, purple and cyan 5 colors, representing to allow other devices to join the ZigBee network, and at the same time to perform the corresponding network operation for other sub-devices, the device to add network successfully will prompt “the device has joined the gateway”:



Equipment grouping:

Grouping of one or more devices in a group division \ New group \ Group control: all devices in the group with switch attributes View modify and delete groups



Scenario:

Automatic control of devices, scenarios containing conditions (one or more) and actions (one or more)
A. New scenes
Conditions are divided into manual conditions, timing conditions and device conditions. Used to realize manual one-touch scenes, timed scenes and equipment linkage scenes

Action is divided into delayed action and device action. Used to realize delayed control or instant control of the device



B. To the scene:
Trigger manual scenes \ turn on and off scenes \ view scenes modify scenes \ delete scenes:



Defense Area Management:

There are two states of alarm mechanism for arming and disarming:In the arming state, the device is turned on to put the gateway into alarm state



Record of events:

Mainly for the gateway management of the device operation records , and then you can export the document to the PC terminal or cell phone terminal:



Gateway restore factory settings:

Press and hold the REST key at the bottom of the gateway for 5seconds, the gateway indicator light will flash white and then restart to restore the factory successfully (need to clear the gateway data when operating).
Caution: 1:

1. this product is a wireless communication equipment, please place flat about 0.5m from the ground, do not place in the meta! box to prevent the signal is shielded;
2. the ambient temperature range is -25°C to +50°C;
3. avoid using in chemical or combustible gas, saturated salt spray, long time high humidity or other abnormal environment;

4. the installation location is ventilated, protected from sunlight, moisture, and away from other sources of heat and electromagnetic interference;
5. to achieve better communication effect, it is recommended to install the gateway in the center of the area where the intelligent devices are located.

Matter function (in testing – Home Pod support only):

1. Follow the operating instructions of IOS devices to add devices with network (ISO/IpadOS HomePod Apple TV)

   For example, HomePod: Open the IOS phone “Home” APP→ “+” in the upper right corner → “Add or scan accessories” → the phone is close to HomePod, you can scan the device. Add the device and follow the APP instructions to add the network.
2. Matter Gateway Bridge: (Note: the gateway and HomePod are on the same LAN, and the network should be enabled with IPV6)

   Steps: Open IOS phone “Home” APP → top right corner “+” → “Add or scan accessories” → Matter QR code, according to the prompts to assign the gateway in the (The zigbee device added in the first step), enter each room can be assigned to control the device (note that the Matter gateway has bridged IOS devices, after unbinding the gateway needs to restore the factory settings before bridging |OS devices again)

As shown in the figure below


My home
Speakers & TVs
None Playing
Office
HomePod
Paused
1


Home Settings
Edit Home View
Reorder Sections
2
My home
HomeBoy
home
Office







Documents / Resources

	[QIACHIP KR2201WZ-Y ZigBee Cacle Gateway] [pdf] User Manual KR2201WZ-Y ZigBee Cacle Gateway, KR2201WZ-Y, ZigBee Cacle Gateway, Cacle Gateway, Gateway

References

- QIACHIP Remote control switch 433.92 MHz RF transmitter receiver
- User Manual

Manuals+, Privacy Policy