Manuals+ — User Manuals Simplified.

**QuWireless XR60
Wireless QuMax
for Sierra
Semtech**

QuWireless XR60 Wireless QuMax for Sierra Semtech Installation Guide

Contents

QuWireless XR60 Wireless QuMax for Sierra Semtech

What's inside

|	
1	front cover
2	sealing gasket
3	back cover
4	WiMount
5	M8 nuts
6	M8 u-bolt
7	ethernet cable
8	power cable
9	M6 x 18 screw
10	M6 pads
11	M4 x 40 screw
12	grounding cable
13	QuRJ45 socket
14	QuPoE PAS-FP

Installation

CHECK LABEL
Mobile

10a MAST - Standard

Min. and Max.
mast diameter
40-60 mm
1.57-2.36 inch

10b WALL

10mm

Not Included!

POE Power Supply – STANDARD

LAN AC

Please note that Semtech XR60 router does NOT support Passive PoE on the ETH port

Before connecting P☐E to your router, please check specificotion of your model. Connecting P☐E to model that's not supporting P☐E con damage your router.
For power supply, you con use any Gigabit Passive PoE power supply with a voltage of 9-3DV.
You con use, for example, a power supply from our offer: QuPSU GP241
Please note that the Passive PoE power supply is not included.

QuPSU-GP241E

Documents / Resources

QuWireless XR60 Wireless QuMax for Sierra Semtech [pdf] Installation Guide
XR60, XR60 Wireless QuMax for Sierra Semtech, Wireless QuMax for Sierra Semtech, QuMax for Sierra Semtech, Sierra Semtech, Semtech

References

- **User Manual**