Manuals+ — User Manuals Simplified.

Wired R Go Numpad Break

R-Go Wired R Go Numpad Break User Guide

Contents

R-Go Wired R Go Numpad Break

Specifications

- Product Name: R-Go Numpad Break
- Type: Ergonomic Numpad
- Connectivity: Wired | Wireless

Product Overview
The R-Go Numpad Break is an ergonomic numpad available in wired and wireless versions. It is designed to enhance your computing experience by providing a comfortable and efficient numeric input solution.

R-Go Break Software
Download the R-Go Break software from the provided link to gain insights into your work behavior and customize keyboard buttons for enhanced productivity

Congratulations with your purchase!

- Our ergonomic R-Go Numpad Break numeric keypad offers all the ergonomic features you need to type in a healthy way. Thanks to the light keystroke, minimal muscle tension is needed while typing. Its thin design ensures
  a relaxed, flat position of hands and wrists while typing.
- You can operate this numeric keyboard with your left or right hand and decide yourself where to place it on your desktop. By operating the numpad with the hand that is not using the mouse, both hands remain within shoulder width as you work. The load will be equally divided between both hands.
- The R-Go Numpad Break keyboard also has an integrated break indicator, which indicates with colour signals when it is time to take a break. Green means you are working healthy, orange means it is time to take a break and red means you have been working too long. #stayfit
- System requirements/Compatibility: Windows XP/Vista/10/11

For more information about this product, scan the QR code! **https://r-go.tools/numpad-web-en**

Product overview

1. R-Go Break indicator
2. Wired version: Cable to connect numpad to PC Wireless version: Charging cable
3. Cable to connect numpad to R-Go Split Break keyboard or R-Go Compact Break keyboard
4. USB-C to USB-A converter

Setup Wired

- Connect the numpad to your computer by plugging the USB-C end of cable 02 into your computer and the micro USB end into the numpad. If you have a USB-A port in your computer, use the USB-C to USB-A converter 04 .

- (Optional) Connect the numpad another keyboard (for example the R-Go Split Break) by using cable 03 .


Setup Wireless

1. Turn your Break numpad on. At the back of this numeric keyboard you will find the on/off switch. Turn the switch to 'on' or, depending on the version, to green.
2. To connect the numpad to a device, for example your laptop, press and hold the Tab-key for at least 3 seconds. It will search for a device to connect with. You will see the Bluetooth light on the numpad blinking.
3. Go to Bluetooth & other devices menu on your computer. To find this you can typ "Bluetooth" in the left corner of your Windows bar.

4. Check if bluetooth is on. If not, turn on bluetooth or check if your PC has got Bluetooth.

5. Click on "Add device" and then "Bluetooth". Select your Break numpad. The numpad will then connect to your chosen device.


- **I can't find my Break numpad. What to do?**
  If you can't find your Break numpad, please check if the battery is full (connect the charging cable with USB-C). When the battery is low the LED light on the keyboard will turn red to indicate that the numpad is charging. When charged for minimal 5 minutes, you can try to connect again.
- **How do I know if my device had got Bluetooth?**
  To check if your PC has got Bluetooth, type at the bottom in the Windows bar "device manager''.

- You will see the following screen (see picture). When your PC hasn't got bluetooth, you won't find 'bluetooth' in the list. You won't be able to use Bluetooth devices'.

6. To charge this numpad, connect it to your computer using cable 01 .

Mac

1. Turn your Break numpad on. At the back of this numeric keyboard you will find the on/off switch. Turn the switch to 'on' or, depending on the version, to green.
2. To connect the numpad to a device, for example your laptop, press and hold the Tab-key for at least 3 seconds.

It will search for a device to connect with. You will see the Bluetooth light on the numpad blinking.

3. Go to Bluetooth on your screen. To find this you click on the Mac icon in the upper left and go to System settings.

4. Check if Bluetooth is on. If not, turn on Bluetooth or check if your PC has Bluetooth.

5. Scroll down to 'Nearby Devices' and click Connect.

R-Go Break

- Download the R-Go Break software at **https://r-go.tools/bs**

- The R-Go Break software is compatible with all R-Go Break keyboards and mice. It gives you insight into your work behaviour and gives you the possibility to customize your keyboard buttons.
- The R-Go Break is a software tool that helps you to remember to take breaks from your work. As you work, the R-Go Break software controls the LED light on your Break mouse or keyboard. This break indicator changes color, like a traffic light. When the light turns green, it means you are working healthily. Orange indicates that it is time for a short break and red indicates that you have been working too long. This way you receive feedback on your break behavior in a positive way.

For more information about the R-Go Break software, scan the QR code! **https://r-go.tools/break-web-en**

Troubleshooting

Is your numpad not working properly, or do you experience problems while using it? Please follow the steps mentioned below.

- Check if the numpad is connected using the correct connector and cable
- Connect the numpad to another USB port of your computer
- Connect the numpad directly to your computer if you are using an USB hub
- Restart your computer
- Test the numpad on another computer, if it is still not working contact us via **info@r-go-tools.com**.

FAQs

I can't find my Break numpad. What should I do?
If you can't locate your Break numpad, ensure that the battery is fully charged by using the provided charging cable. The LED light on the numpad will turn red when charging. After charging for at least 5 minutes, attempt to connect again.

How do I know if my device has Bluetooth?
To check if your PC has Bluetooth capability, type 'device manager' in the search bar at the bottom of your Windows screen. If Bluetooth is not listed, your device does not support Bluetooth connectivity.

Documents / Resources

R-Go Wired R Go Numpad Break [pdf] User Guide
Wired R Go Numpad Break, R Go Numpad Break, Numpad Break, Break

References

- ⟳ **Tools.com – tools.com International LLC**
- **User Manual**