Manuals+ — User Manuals Simplified.

ROLL-A-SHADE RAS Plus Shade Open Roll Instruction Manual

ROLL-A-SHADE RAS Plus Shade Open Roll

Contents

HARDWARE INCLUDED

- Shade + Motor

- Brackets



- Bracket Covers

- Wall Switch

- Switch Box

- #14 Screw

- Screws

- Zip Ties

- Wire Tie Pads

TOOLS REQUIRED

- 3/8" Hex Head

- Phillips Head

- 1/8" Drill Bit

- Drill

CHECK TO PRINT

INSIDE OR OUTSIDE APPLICATION

- **NOTE**: ALL SHADES MAY BE PRE-PROGRAMMED TO SENSORS, REMOTES, AND/OR WALL SWITCHES UPON ARRIVAL**

MOUNTING LOCATION

- Place your first bracket in its mounting location and mark the screw holes. Place your second bracket in its mounting location and repeat the process.

## SCREW INSTALLATION

- Next, pre-drill your screw holes using a 1/8" drill bit. Install the brackets with the provided screws using the 1/4" hex head driver.

ALIGNMENT

- Check to make sure your brackets are level and aligned.

SHADE PIN END INSTALLATION

- Depress pin end and slide onto bracket until pin engages in center hole. Press idler shaft all the way to the bracket.

MOTOR END INSTALLATION

- Lineup to motor bracket. Push motor into motor bracket.

PLUG IN MOTOR

- Run motor power cord to nearest power outlet.
- Install wire tie pads and secure with zip ties to hold wire down.
- The path of the wire should be parallel with mullions and/or drop ceiling tiles ensuring the cable is neatly organized.
- Any modifications to the power cable should be done by a certified electrician to meet your city/state code requirements.

SHADE ADJUSTING (IF NECESSARY)

- Roll shade up and down to confirm hembar is level and material rolls up straight on center tube.
- If the hembar is not level, lower shade until you see the metal tube.
- Add layers of masking tape to the metal tube to the end that is too low until hembar is straight.
- If the material tracks to one side, lower shade until you see the metal tube.
- Add layers of masking tape to the metal tube to the end that is opposite the direction of tracking, until shade rolls up straight.

ADJUSTING LIMITS (IF NECESSARY)

See programming instructions based on the motor used for your application.

CUSTOMER SUPPORT

RASPSORMVER.3 5 OF 5 | © Copyright Roll A Shade®
Inc. All Rights Reserved.

Rollashade.com
info@rollashade.com
951.245.5077

© Copyright Roll A Shade®
Inc. All Rights Reserved.

Documents / Resources

ROLL-A-SHADE RAS Plus Shade Open Roll [pdf] Instruction Manual
RAS Plus Shade Open Roll, RAS Plus, Shade Open Roll, Open Roll

References

- **Roll A Shade - Commercial Window Shade Solutions**
- **User Manual**