Manuals+ — User Manuals Simplified.

Wireless Door
Window Sensor

ShieldPro Wireless Door Window Sensor User Guide

Contents

ShieldPro Wireless Door Window Sensor

The ShieldPro Door/Window Sensor fits alongside door frames and windowsills.

Sensor   Magnet

What comes in the box?

- Sensor x 1
- Magnet x 1
- Wall screws x 4
- Wall anchors x 4

Sensor figures

- **Figure 1**: Placement for door sensors
- **Figure 2:** Placement for window sensors
- **Figure 3:** Grooves for positioning
- **Figure 4:** Distance between magnet and sensor

Figure 1: Placement for door sensors

Figure 2: Placement for window sensors

Opens

Opens

Figure 3: Grooves for positioning

Grooves

Figure 4: Distance between magnet and sensor

The distance between closed sensors should be 0.25 inches or less

Placement tips

- Indoor use only.
- Pair with the panel before mounting your sensor.
- Place on the opening side of doors and windows (see Figure 1 and Figure 2).
- The grooves must face each other (see Figure 3).
- Sensor and magnet must be 0.25 inches apart or less (see Figure 4).

Mount your Door/Window sensor with adhesive

- **Step 1** Clean and dry the sensor location.
- **Step 2** Remove all battery tabs from the sensor.
- **Step 3** Pair with the panel.
  Settings (☰ button) > Devices > + > Door or Window >
  Follow the prompts to pair the sensor.

- **Step 4** Peel the protective backing off the sensor and press firmly against the surface.

  Repeat with the magnet.

Questions?

Contact us at 1-**800-574-7798** or **CST@shieldpro.com**

Documents / Resources

	ShieldPro Wireless Door Window Sensor [pdf] User Guide Wireless Door Window Sensor, Door Window Sensor, Window Sensor, Sensor

References

- **User Manual**