Manuals+ — User Manuals Simplified.

EVER350 Front Back Shelf

Smart Media EVER350 Front Back Shelf User Guide

Contents

SMART MEDIA SOLUTIONS

Smart Media EVER350 Front Back Shelf

Product Specifications

- **Product Name:** EVER350 FRONT/BACK SHELF
- **Max Weight Capacity:** 10 kg
- **Dimensions:** 600 x 300 mm
- **Material:** 16 mm MDF with paint and clear coating
- **Compatibility:** For EVER 350 & 350 Air*

Product Usage Instructions

Installation:

The shelf can be placed on the front or back side of the stand.
Follow these steps for installation:

1. Locate the exterior mounting slots in the pillars of the stand.
2. Place the shelf in the desired position.
3. Secure the shelf using the provided knobs.

Height Adjustment:

The shelf's height can be adjusted to accommodate your equipment. Here's how to adjust the height:

1. Loosen the knobs.
2. Move the shelf to the desired height.
3. Tighten the knobs to secure the shelf in place.

### Usage Limitation for EVER 350 Air:

- For EVER 350 Air, the shelf placement is limited to the bottom part of the stand.

Models

16-102-x / EVER 350 Front/Back shelf

16-103-x / EVER 620 Front/Back shelf

Safety

Warning

A correct mounting is extremely important and this is not the responsibility of SMS Evoko Group AB.
Faulty mounting may result in injury to persons or damage to equipment. SMS will not be responsible in any way if the product has been mounted incorrectly. Mounting fittings are not included with the product for reasons of safety, since the properties and bearing strength of walls/ceilings are specific for each case.

Suitable mounting fittings must be selected based on the material of the wall/ceiling. Obtain advice from a specialist in the field or from a specialist shop concerning the choice of mounting fittings. It is the responsibility of the installer to ensure that the wall/ceiling can support at least four times the combined weight of the screen/projector and bracket.
The maximum load for this product is given in the table in these installation instructions. The instructions for installation and use of the screen/projector must also be followed with respect to the location and attachment of the screen/projector.

Warranty

Warranty terms and conditions

1. SMS guarantees that a product that SMS has determined to be defective as a result of deficient manufacture or material will be repaired or – if necessary – replaced, without cost, on condition that a claim is made within the period of warranty, which is 5 years. The guarantee does not apply for normal wear and tear.
2. In the event of a claim being made under the terms of the warranty, the product and the original purchase receipt are to be returned to SMS. The name of the supplier and the date of purchase must be clearly legible on the receipt. The owner is to pay the cost of returning the product to SMS, while SMS is to pay the cost of returning the product subsequently to the owner.

3. The warranty provided by SMS does not apply under the following conditions:
   - If the product has been drilled, mounted and/or used in any way that is not in accordance with the instructions for use, or if it has been mounted using inappropriate mounting fittings.
   - If the product has been modified or repaired by anyone other than SMS.
   - If the defect has arisen as a result of external factors (that are not associated with the product), such as lightning strike, water damage, fire, mechanical scratching, storage at extreme temperatures, weather conditions, solvents or corrosive agents, faulty use, or carelessness.
   - If the product has been used for equipment other than that specified on the packaging.

Product Information

YOU WILL NEED

Allen key
No.5

NOT INCLUDED

EVER stand
& display

**NUMBER OF PERSONS REQUIRED**

**LIST OF PARTS**

A1 (1x)

B1 (1x)   B2 (1x)

C1 (2x)

S1 (4x)
ISO 7380
[M6x10]

S2 (2x)
DIN 934
ISO 4032 [M8]

Assembly Instructions

1

C1 (1x)

S2 (1x)

5mm min.

S2 (1x)

C1 (1x)

B2 (1x)

B1 (1x)

S2 ⬡ (2x)

2

A1 (1x)

S1 (2x)

S1 (2x)

S1 ⬤ (4x)

3a

OPTION 1: Shelf above stand handle

Front
Installation

Back
Installation

4a

OPTION 1: Shelf above stand handle

*Front Installation

Tighten

Tighten

Back Installation

*Front shelf position above display only

3b

OPTION 2: Shelf below stand handle

*Front Installation

*Front shelf installation must be done before installing display and display bracket.

Back Installation

4b

OPTION 2: Shelf below stand handle

Tighten

*Front Installation

Back Installation

Tighten

*Front shelf installation must be done before installing display and display bracket.

Front Shelf

Back Shelf

Dimensions

16-102-x / EVER 350 Front/Back shelf

[18,88]
479,5

[16,18]
411

[11,81]
300

[23,62]
600

[2,36]
Φ60

[15,43]
392

[3,62]
92

[21,08]
535,5

[0,63]
16

[4,84]
123

All dimensions in mm.
Dimensions in brackets [ ] are in inches

16-103-x / EVER 620 Front/Back shelf

All dimensions in mm.
Dimensions in brackets [ ] are in inches

FAQs

- **Can I use this shelf with other stands?**
  - The shelf is specifically designed for use with EVER 350 & 350 Air stands. It may not be compatible with other stands.
- **What is the maximum weight capacity of the shelf?**
  - The shelf can support a maximum weight of 10 kg.

For the most recent information and updates, visit **www.smartmediasolutions.com**

Contact

- SMS Smart Media Solutions AB
- Högbergsgatan 26B, 116 20 Stockholm, Sweden
- **www.smartmediasolutions.com**
- **mailto: info@smartmediasolutions.com**

We reserve the right to introduce changes in the product specifications after the publishing of this document.

Documents / Resources

Smart Media EVER350 Front Back Shelf [pdf] User Guide
EVER350 Front Back Shelf, EVER350, Front Back Shelf, Back Shelf, Shelf

References

- **Smart Media Solutions | Wherever you need your image**
- **User Manual**