SONY CFI-ZAC1 Access Controller

SONY CFI-ZAC1 Access Controller Instructions

Contents

SONY

SONY CFI-ZAC1 Access Controller

Product Information

Specifications

- **Model Number:** 5-054-743-11
- **Manufacturer:** Sony Interactive Entertainment Inc.
- **Trademark:** PlayStation
- **Compatibility:** Sony Group Corporation products

Product Usage Instructions

Setting Up the Product

1. Connect the product to a power source using the provided cable.
2. Turn on the product by pressing the power button.
3. Follow the on-screen instructions to complete the initial setup process.

Using the Product
Once the product is set up, you can use it for various activities such as gaming, streaming, and more. Simply navigate through the menu using the controller or remote to access different features.

Troubleshooting
If you encounter any issues with the product, refer to the user manual or visit **playstation.com/access-help** for troubleshooting tips and support.

Frequently Asked Questions (FAQ)

- **Q: What should I do if the product does not turn on?**

  A: Check the power connection and ensure that the power source is working. If the issue persists, contact customer support for assistance.
- **Q: Can I use this product with other non-Sony devices?**

  A: The product is primarily designed for use with Sony Group Corporation products; compatibility with other devices may vary.

What's In The Box

(1)	(1)	(8)	(4)
(4)	(2)	(1)	(3)
(23)	(1)	(1)	5-054-743-11 (1)

Installation And Using Instruction

1

2

3

playstation.com/access-help

© 2023 Sony Interactive Entertainment LLC. Printed in China.

Documents / Resources

SONY CFI-ZAC1 Access Controller [pdf] Instructions
CFI-ZAC1 Access Controller, CFI-ZAC1, Access Controller, Controller

References

- [**User Manual**](#)