Soundcore A3125 Select 2 Portable Bluetooth Speaker User Manual

Soundcore Select 2
USER MANUAL

Contents

At a Glance

|	
1. Power LED 2. Power button 3. Volume down button 4. Multi-function button 5. Volume up button	6. Bluetooth/PartyCast button 7.Bluetooth LED 8. NFC tag 9. USB-C charging port

Charging

- Use the provided USB-C cable to prevent any damage.
- Fully charge this speaker before the first use to prolong the lifespan of the built-in battery.
- Disconnect this speaker from the charger when fully charged. Do not charge for extended periods.

	Flashing red		Low battery
	Steady red		Being charged
	Steady white		Fully charged

Powering On/Off

|			
Power on			Press
Power off			Press and hold 2 seconds

• This speaker will power off automatically 30 minutes after no audio input or button inactivity.

Using your Soundcore Select 2

Bluetooth Mode
With this speaker, you can enjoy music through your Bluetooth-enabled devices.

|		
ﾟ	Press	Enter Bluetooth pairing mode
ﾟ	Flashing blue	Bluetooth pairing
●	Steady blue	Bluetooth connected

- **Dual Bluetooth Connection:** This speaker can pair up to 2 mobile devices via Bluetooth. To pair with another device, press the Bluetooth button to re-enter Bluetooth pairing mode.
- This speaker can only play music on one mobile device at a time. To play from another connected device, pause the currently active device first.
- Each time you power on your Soundcore speaker, it will automatically connect to your last connected device is available within the Bluetooth range. If not, press the Bluetooth button to enter Bluetooth pairing mode.

NFC Mode
If your Bluetooth device supports NFC, you can connect it with this speaker easily.

1. Enable the NFC feature on your Bluetooth device.
2. Touch the NFC tag on the speaker with the back of your Bluetooth device.
3. On your Bluetooth device, accept the pairing request with "Soundcore Select 2".

PartyCast Mode

You can wirelessly connect up to 100 identical Soundcore Select 2 speakers together.

1. Connect one Soundcore Select 2 speaker with your smartphone or tablet as the primary speaker.
2. Press and hold the Bluetooth button on the primary speaker and all desired speakers to enter pairing mode.
   >>> When successfully connected, the Bluetooth LED on the primary speaker will continue flashing white, while on the secondary speakers will turn white.

When PartyCast mode is successfully entered:

- Any secondary speaker can be switched to become the primary speaker by pressing the Bluetooth button twice and connecting to your smartphone. Any primary speaker can be switched to become the secondary speaker by pressing the Bluetooth button twice and searching for an available primary speaker.
- To exit the PartyCast mode, press and hold the Bluetooth button on any speaker for 2 seconds.

Button Controls

♫	Press
♫	Press twice
♫	Press thrice
-/+	

♫	Press	
♫	Press	
♫	Press and hold for 2 seconds	
♫	Press and hold for 2 seconds	

♫	Press and hold for 2 s

Soundcore App

Download the Soundcore App for an enhanced product experience.

- Update firmware
- Indicate battery status
- Remotely control the volume and play/pause
- Customize EQ settings
- Set Auto-power off time

Specifications

Specifications are subject to change without notice

DC power input	
Battery capacity	
Audio output power	
Charging time	
Playtime (varies by volume level and music content)	
Waterproof level	
Bluetooth version	
Bluetooth range	

Documents / Resources

Soundcore A3125 Select 2 Portable Bluetooth Speaker [pdf] User Manual
A3125, Select 2, Portable Bluetooth Speaker