SUNSKY MT-6057 Multi Functional Axe and Hammer User Manual

Model:MT-6057
USER MANUAL
MULTI- FUNCTIONAL
AXE & HAMMER

Before using this product, please read this User Manual carefully and keep it for future reference.

Contents

PRODUCT DESCRIPTION

Regular Plier

Flat Jaw Plier

Wire Cutter

Axe

Hammer

Plier Handle

Bottle Opener

Fish Descaler

Slotted Screwdriver

File

Spring

RoverTac

Assorted Hex Wrench

Large Slotted Screwdriver

Tail Lock

Saw

Philips Screwdriver

Knife

PARAMETERS

Ltem	Multi-functional Axe Hammer
Part Number	MT-6057
Close Size	417g/14.7 oz
Net Weight	Stainless Steel & Aluminum
Materials	175*89*28mm/6.9*3.5*1.1 Inches

USE INSTRUCTIONS

To use the Pliers, squeeze the handle firmly to release the tail lock.
Always make sure the tail lock is fully engaged before using the other tools.

Axe blade cover for safety. Carefully remove blade guard before use, replace when done to protect the blade.

SAFETY GUIDES

1. Store in the sheath to prevent damage to the tool.
2. Always make sure the Axe blade is well covered with the sheath when It's not in use.
3. When finished, make sure to fold tools back entirely into the handle. Do not leave sharp edges out.
4. Lock the handle securely with the tail ring to ensure a safer experience when using the Hammer and Axe.
5. If using a sawing or cutting motion, always direct the cut away from yourself and keep your free hand away from the area.
6. When unfolding blades or other sharp tools, do so pointed away from you, do not unfold a tool "Half way" make sure it is either completely stored or out.
7. To avoid personal injury, please use tools only for the intended purpose. Improper use can lead to personal injury. Always keep sharp objects away from children.

Documents / Resources

SUNSKY MT-6057 Multi Functional Axe and Hammer [pdf] User Manual
MT-6057, MT-6057 Multi Functional Axe and Hammer, Multi Functional Axe and Hammer, Functional Axe and Hammer, Axe and Hammer, Hammer