SwitchBot E27 Color Bulb User Manual

**SwitchBot Color Bulb
User Manual**

Contents

In the Box

- Bulb
- User Manual

Note: The graphics used in this manual are for reference only. Due to future updates and improvements of the product, the actual product images may differ.

Preparation

A smartphone or tablet with Bluetooth 4.2 or above
System Requirements: Android 5.0 or above, iOS 10 or above
Download the SwitchBot app
Create a SwitchBot account and sign in

Getting Started

1. Power on the Bulb.
2. Open the SwitchBot app and sign in.
3. Tap the "+" icon on the top right of the Home page.
4. Tap the "Bulb" icon and follow the instruction to complete the setup.

Attention:

- Before you install the Smart Bulb, please confirm you have switched off the bulb that you need to replace. Then remove the old one to replace the smart bulb.
- Avoid using metal lampshades, this will damage Smart Bulb's wifi signal strength.
- Avoid using original dimmer switches to control Smart Bulb, it may cause failure in control.
- Avoid using the original wall switch to power off Smart Bulb, it will cut off Bulb's network connection.
- Do not disassemble or transform. The LED components cannot be replaced.
- Never wash with water.
- There is a deviation in LED components, even for the same type of products, the light color and brightness may vary.
- Do not use in places where condensation occurs.
- Maintenance method: please wipe it with dry cloth.

Safety Information

- To avoid the risk of electric shock and burn, please turn off the power supply and wait for the bulb to cool down when installing, removing or cleaning.
- Do not install the Smart Bulb with wet hands or when standing on wet or damp surfaces.
- Compatible with regular light switches. Not suitable for use with standard in-wall dimmers.
- Not compatible with photosensors, motion sensors, or timers.
- Dimmable using the app only.
- Compatible with regular light switches. Not

suitable for use with standard in-wall dimmers.Not compatible with photosensors, motion sensors, or timers. Dimmable via the app only.

- NOT for use in totally enclosed or recessed luminaires.
- Do not look directly at the bulb when it's on, as this may cause visual damage.
- NOT FOR EMERGENCY LIGHTING.
- Operating Temperature: -15°C~40°C(5°F~104°F)
- Storage Temperature: -20°C~70°C(-4°F-158°F)
- Operating Humidity: 10%~90%RH,Non-condensing
- Storage Humidity: 10%~90% RH, Non-condensing

Firmware, and Factory Reset

Firmware
Make sure you have the up-to-date firmware by upgrading in time.
Factory Reset
Turn the bulb on and off 8 times continually, until the Bulb is in breathing mode and then turn white.
Note: After resetting the device, all settings will resume back to default values.

Specification

Model: W1401400
Product Dimension: 60 x 60 x 116 mm
Weight: 93g
Luminous Flux: 800 lumens
Color: 2700K-6500K+RGB
Shape: E26/E27
Wattage: 10W
Voltage: 100-240VAC
Operation Life: Around 25000 hours
Operating Temperature: -15 °C~ 40 °C (5 °F ~ 104 °F)
Operating Humidity: 10%~90% RH,
Non-condensing

Q&A
Q: Why can't my bulb connect the network successfully?
A: Color Bulb supports most of dual-band Wi-Fi routers, if the Color Bulb fails to connect network, please log in to your Wi-Fi router's setting page, edit the name of the 5.0GHz band to differ it from the 2.4GHz band.
Q: Why couldn't I turn on my bulb by wall switch?
A: 1) Please make sure your wall switch has a power supply.
2) Find the setting of Power Loss Recovery on the SwitchBot App, choose the behavior of your bulb when it loses power. Select turn on.

https://support.switch-bot.com/hc/en-us/sections/4403398743703

Return and Refund Policy

This product has a one-year warranty (begins from the date of purchase). The situations below do not fit the Return and Refund
Policy.

- Intended damage or abuse.
- Inappropriate storage (drop-down or soaking in water).
- Modify or repair of the product.
- The natural wearing of product.
- Natural disasters.

Contact and Support

Setup and Troubleshooting: **support.switch-bot.com**
Support Email: **support@wondertechlabs.com**
Feedback: If you have any concerns or problems when using our product, please kindly send feedback from the Profile> Feedback page in the SwitchBot app.

CE Warning

Manufacturer's Name: Woan Technology (Shenzhen) Co., Ltd.
This product is a fixed location. To comply with RF exposure requirements, a minimum separation distance of 20cm must be maintained between the user's body and the device, including the antenna.
Use only the supplied or an approved antenna.
This device in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. All essential radio test suites have been carried out.

1. CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS
2. The device complies with RF specifications when the device used at 20cm from your body

FCC Warning

This device complies with part 15 of the FCC Rules.
Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received,

including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

FCC RF exposure statement:
The equipment complies with FCC radiation exposure limits set forth for uncontrolled environments. This equipment should be installed and operated with a minimum distance 20cm between the radiator and your body.

www.switch-bot.com

Documents / Resources

	SwitchBot E27 Color Bulb [pdf] User Manual W1401400, 2AKXB-W1401400, 2AKXBW1401400, E27 Color Bulb, E27, Color Bulb

References

- **S** **SwitchBot Official Website - Your Simple Switch to a Smart Home – SwitchBot International**