Manuals+ — User Manuals Simplified.

TEKVOX

Drop-in AV®

VRHS Instructor Operation Guide

TEKVOX VRHS Instructor Operation Guide User Guide

Contents

TEKVOX
Drop-in AV®

TEKVOX VRHS Instructor Operation Guide

Specifications

- Product Name: VRHS Instructor Operation Guide
- Features: Display controls, volume controls, camera controls, source selection, help options
- Compatibility: Designed for VRHS systems

Instruction

Turning System On

Step 1: Wake Screen (Optional)
If screen is dark, touch to wake

Step 2: Open *System On* Menu
Touch anywhere on screen

Step 3: Select Option
Turn System On
Press "Yes"
**Turn Digital Signage On**
Press "Digital Signage Only"
Keep System Off (Cancel)
Press "Cancel"
OR
Press ⊗

Selecting a Source

Select a Source

Press a source's name to select it

OR

Press "Student Pods" then press a pod's name to select it

The selected source will be shown on the main video wall

Volume Controls

Step 1: Open *Volume* Menu

Press "Volume" tab on left

Step 2: Choose Operation

Adjust Audio Volume*

A: Press ⊖ or ⊕

OR

B: Drag slider to desired volume

OR

C: Touch desired level on volume bar

Mute Audio

Press 🔊 or 🎤

Press again to resume playing audio

* Volume *controls the volume of the selected source*

Mic Volume *controls the volume of the room's microphones*

Display Controls

Turn Video Wall On

Press 🖥️ Video Wall Off

### Turn Video Wall Off

Press 🖥️ Video Wall On


Send to Student Pods

Send to Student Pods

With a source selected, press "Send to Student Pods"

The selected source will be shown on all student pods' displays

Switch Back to Local Operation

Press "End Send to Students Pods"

Camera Controls

** Press **Dual View** to view both cameras side-by-side*

Step 1: Open *Camera Controls*

Press "Camera" tab on left

Step 2: Select Camera to Control

Press "Instructor Camera" or "Student Camera"*

Step 3: Choose Operation

Pan or Tilt Camera
Press directional buttons

Zoom In or Out
Press ⊕ or ⊖

Set Camera to Preset Position
Press name of desired preset

Requesting Help

Step 1: Open *Help* Menu

Press ⑦ in top-right corner

Step 2: Choose Option

Download User Guide
Scan QR Code

**Get Help Via Phone**
Press "Give us a call"

Get Help Via Email
Press "Send us an email"

Turning System Off

Step 1: Open *System Off* Menu

Press ⏻ in bottom-left corner

Step 2: Choose Digital Signage to Leave On

Press "Video Wall" and/or "Pods"
The selected displays will show digital signage when the system is off

Step 3: Confirm System Off

Press "Turn System Off"

FAQs

Q: How do I adjust the microphone volume?
A: Mic Volume controls can be adjusted by opening the Volume Menu and selecting the Mic Volume option to adjust the room's microphone levels.

Q: Can I view both cameras simultaneously?
A: Press Dual View in the Camera Controls menu to view both cameras side-by-side.

Documents / Resources

	TEKVOX VRHS Instructor Operation Guide [pdf] User Guide 2024, 08, VRHS Instructor Operation Guide, VRHS, Instructor Operation Guide, Operation Guide, Guide

References

- **User Manual**