Manuals+ — User Manuals Simplified.

THIKYA
Y19 Portable
**CD Player**

THIKNYA Y19 Portable CD Player User Manual

Contents

THINKYA

THIKNYA Y19 Portable CD Player

Product Specifications

Product name	CD Player
Input power	DC 5V/2A
Bluetooth version	5.0
BT protocol support	ADP/AVRCP
BT receiving distance	10M
Battery capacity	3.6V/2600mAh
Output Power	speaker(4Ω)2X2W; earphone(16Ω)2X20mW
USB playback format	MP3/WMA/WAV/APE/FLAC
CD playback format	CD-DA/MP3/CD-R
Audio In	3.5mm Audio In
Analog audio output	3.5mm stereo headphone output
Charging cable length	80CM
Product Size	160x200x46.5mm
Product weight	about 490g
Product accessories	(charging cable audio cable manual remote)×1

Product Usage Instructions

WHAT'S IN THE BOX?

1. CD Player

2. Type-C Charging Cable


3. Remote Control

4. 3.5mm Aux Cable


5. Instruction Manual

Button Panel Controls

1. UPPER COVER

2. LEFT CHANNEL SPEAKER

3. STANDBY/ON

4. SHORT PRESS:INPUT SOURCE SELECTION(CD,USB,AUX,BT) LONG PRESS:BT TRANSMITTER SWITCH

5. STOP

6. LED DISPLAY

7. SHORT PRESS: PLAY/PAUSE LONG PRESS: CYCLE MODE SELECTION

8. SHORT PRESS: PREVIOUS LONG PRESS: VOLUME

9. SHORT PRESS: NEXT LONG PRESS: VOLUME

10. RIGHT CHANNEL SPEAKER

Rear PPanelConnections

1. OPTICAL FIBER OUTPUT
2. HEHEADPHONEUDIO OUTPUT TERMINAL
3. AUXAUXILIARYPUT
4. USB SLOT
5. TYPE-C POWER TERMINAL
6. SWITCH

REMOTE CONTROLLER

1. STANDBY/ON

2. VOLUME

3. PREVIOUS

4. VOLUME

5. REPEAT/SHUFFLE

6. BASS /

7. BT TRANSMITTING SIGNAL

8. MUTE

9. NEXT

10. PLAY/PLAUSE

11. STOP

12. INPUT SOURCE SELECTION (BT/AUX/CD/USB)

13. TREBLE / EQ

Power ON/Stand BY

1. Turn the switch to ONthe state button 6 on the rear panel

2. To turn on the unit, click the STANDBY button 3 on the button panel

3. To put the unit into standby mode ,click the STANDBY button once again

BlueTooth Mode

1. Select the Bluetooth mode. Click the SOURCE(button 4) on the button panel until the BT option appears on the screen. The light will start flashing, which means the unit is ready to pai.r

2. Search for the pairing name THINKYA CD in the list of Bluetooth devices

Stay close.The effective range of Bluetooth devices is 10 meters

USB – MP3

1. Plug the desired USB in the USB input slot of the rear panel

2. Devices compatible with USB 2.0 Size 32Gb

3. Select the USB mode. Using the button panel (SOURCE button 4)

Playing CDs

1. Select the CD mode. Using the button panel (SOURCE button 4)

2. Insert the CD into the tray

3. Click Play(button 7) on the button panel. You can play your CD-DA, CD-, , R and CD with files in MP3 form.at

4. Press the STOP(button 5) on the button panel to stop playback

5. To search for a section on a Ctrackck, long press the NEXT (button 9) or PREVIOUS(button 8) during playback, then release it at the point you want to listen.

6. Long pressing the PLAY (button 7) on the button panel for the first time will enter the single loop, the second time will enter all loops, the third time will enter the random play, and the fourth time will turn off loop playback.

Using Bluetooth and USB Playback

1. Search for the pairing name "THINKYA CD" in the list of Bluetooth devices.
2. Select the USB mode using the SOURCE button on the button panel.
3. Click Play on the button panel to play your CD-DA, CD-R, and MP3 format files.
4. Press STOP on the button panel to stop playback.
5. Long-pressing PLAY on the button panel allows you to toggle between different loop playback modes.

FFC STATEMENT

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, under part 15 of the FCC Rules. These limits are designed to protect reasonably against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used according to the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. Suppose this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. In that case, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

RF Exposure Statement
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

About US

Follow us!Thinkya

[**www.gzbluelight.com**](http://www.gzbluelight.com)

FAQs

Q: What is the effective range of Bluetooth devices?
The effective range of Bluetooth devices is 10 meters.

Q: What devices are compatible with USB playback?
Devices compatible with USB playback are those supporting USB 2.0 with a size up to 32 GB.

Documents / Resources

	[**THIKNYA Y19 Portable CD Player**](#) [pdf] User Manual 2BKTR-Y19, 2BKTRY19, Y19 Portable CD Player, Y19, Portable CD Player, CD Player, Player

References

- ◎ [**Guangzhou Blue Light Electronics Technology Co., Ltd. - Blu-ray Players/DVD Players/Mini Combo/CD Players&Boombox/Home Theater Systems/Clock Radio/Bluetooth Speaker**](#)
- [**User Manual**](#)