A2004NS Samba server instal

Contents

1 A2004NS Samba server instal
2 Diagram
3 DOWNLOAD
4 Related Posts

A2004NS Samba server instal

It is suitable for: **A2004NS** / **A5004NS** / **A6004NS**

How to access A2004NS USB shared U disk video, pictures?

Application introduction: A2004NS support file sharing function, the mobile storage devices (such as U disk, mobile hard disk, etc.) connected to the router's USB interface, LAN terminal equipment can access the resources of mobile storage devices, easy file sharing.

Diagram

Set up steps

STEP-1: Check if the hard disk has a successful access router



STEP-2: Samba server build

2-1. Go to the router interface and select **Basic App–Service Setup — Windows File Sharing (SAMBA).**



2-2. Start the server, select **Read** / **Write**, enter the **user ID** and **Password**. click **Apply**. The Samba server has been built.



STEP-3: Access the Samba server from the client.

3-1. Open This PC and type \\ **192.168.1.1** in the input box. And press the Enter key



3-2. On this page, you will see the attached hard disk information. Click on this hard drive.



3-3. In this page will pop up a certification box, you need to enter the samba server set up, **user ID** and **Password**. At this point, you can and good friends to share the resources inside the hard disk.



DOWNLOAD

A2004NS Samba server instal -[Download PDF]

Manuals+,