Manuals+ — User Manuals Simplified.

typecase 6th Generation Touch Keyboard for iPad Pro 12.9 User Manual

Contents

typecase 6th Generation Touch Keyboard for iPad Pro 12.9

USER MANUAL

- Compatible With
  - iPad Pro 12.9

For warranty registration and product support:

- **typecase.co/resources**
- +1{832) 303-5080
- **support@typecase.co**

TECHNICAL SUPPORT

- If you encounter any difficulties or have inquiries, please do not hesitate to reach out to us at your earliest convenience.
- For the quickest and most efficient support experience, please contact us directly through one of the following channels, rather than through Amazon.

1. **Email: support@typecase.co**
2. **Phone:** 832 – 303 – 5080
3. **Chat: https://typecase.co/support**

COMPATIBILITY

Compatible with iPadOS 13 or newer. Update to the latest version of iPadOS for best performance.
To check your iPad system version:

1. Go to Settings ⊚ > General > About > Software Version

2. Upgrade your version to iPadOS 16 or above to use the touch pad function correctly.

iPad 🤍	12:01 PM	11% 🔋
Settings	**< General**	**About**
⊚ General	Version	13.2
AA Display and Brightness	Model	A1980

To upgrade your iPadOS to the lastest version:

1. Open your device's Settings ⊚ > General > Software Update

| iPad 🤍	12:01 PM	11% 🔋
Settings	**General**	**< General Software Update**
⊚ General	About >	16 iPadOS 16.3.1 Apple Inc. 2.76 GB
AA Display and Brightness	Software Update >	Download and Install

2. Tap Download and Install.

   Tap "Resume Download" if available.

SETUP

To pair with your iPad:

1. Turn ON/OFF switch to ON.

2. Bluetooth indicator blinks. Press and hold 'Pair' button for 2 seconds if it doesn't.

3. Toggle Bluetooth ON in Settings app ⊚ Connection established when indicator stops blinking

On/Off Switch

Bluetooth Indicator

4. In the Bluetooth section of the Settings app, select 'Typecase Flexbox' under 'MY
   DEVICES'.

5. Tap 'Pair' in the pop-up window as shown.

   Note: To pair with new devices, repeat steps 1-5.

   Pairing complete when "Connected" indicator appears.

6. If your system is 13.3.1, please follow the steps to enable touchpad function:

   1. Go to Settings > Accessibility > Touch .

   2. Make sure Assistive Touch option is turned On.

SHORTCUT MAP

Notice: Long Hold ⌘ cmd **in any app to view available shortcuts.**

Charging Voltage

Flashes Red
Needs charge

Press once Home / Press twice App Switcher / Long Press Siri	App Switcher	Brightness Decrease	Brightness Increase	Back	Media Play/Pause	Forward	Mute	Volume Decrease	Volume Increase	Change color	Change brightness	See steps on User Manual

Brightness   Media   Volume   Backlight

□ | 80 | ☀ | ☀ | ◀◀ | ▶II | ▶▶ | ◀ | ◀» | ◀») | color | light | pair | del/🔒

~ ` | ! 1 | @ 2 € | # 3 £ | $ 4 | % 5 | ^ 6 | & 7 | * 8 | (9 |) 0 | — - | + = | ←

tab | Q | W | E | R | T | Y | U | I | O | P | { [| }] | | \

caps lock | A | S | D | F | G | H | J | K | L | : ; | " ' | enter

shift | Z | X | C | V | B | N | M | < , | > . | ? / | shift

🌐 | control | alt option | ⌘ cmd | Q | ⌘ cmd | option | ◀ home | ▲ pgup / ▼ pgdn | ► end

+Control
Touchpad ON/OFF

Switch Keyboard Language

Keyboard

⌥ option + del🔒 =Lock Screen

C + R + L =Reset the keyboard

Long Press – App specific shortcut shows up (e.g. when you are in an App, hold this key and you will see all the shortcuts that can be used in this App).

Long Press -App specific shortcut shows up (e.g. when you are in an App, hold this key and you will see all the shortcuts that can be used ln this App).

System

🌐 + H =Go to Home Screen

⌘ cmd + H =Go to Home Screen

🌐 + Q =Quick Note

🌐 + A =Show Dock

🌐 + C =Control Center

🌐 + N =Notification Center

🌐 + M =Show Keyboard Shortcuts

🌐 + S =Siri

🌐 + shift + A =Show App Library

⌘ cmd + shift + # 3 £ =Screenshots

⌘ cmd + shift + $ 4 =Screenshots and Markup

⌘ cmd + alt option + D =Show Dock

⌘ cmd + [Q] =Search

⌘ cmd + tab =Switch App

Format

⌘ cmd + B =Bold

⌘ cmd + I =Italic

⌘ cmd + U =Underline

Multitasking

🌐 + pgup =App Switcher

🌐 + pgdn =Show All Windows

🌐 + home ◄ =Previous App

🌐 + end ► =Next App

Split View

🌐 + control + home ◄ =Tile Window Left

🌐 + control + end ► =Tile Window Right

🌐 + F =Enter Fullscreen

Slide Over

⊕ + [alt / option] + [◄ home] = Move to Left Slide Over

⊕ + [alt / option] + [► end] = Move to Right Slide Over

⊕ + [| \] = Show Slide Over

[⌘ cmd] + ⊕ + [| \] = Next Slide Over Window

Symbol

[alt / option] + [R] = ®   [alt / option] + [> .] = ≥   [alt / option] + [J] = Δ   [alt / option] + [Z] = Ω   [alt / option] + [S] = ß

[alt / option] + [G] = ©   [alt / option] + [< ,] = ≤   [alt / option] + [P] = π   [alt / option] + [X] = ≈   [alt / option] + [W] = Σ

[alt / option] + [+ =] = ≠   [alt / option] + [? /] = ÷   [alt / option] + [V] = √   [alt / option] + [M] = µ   [alt / option] + [% 5] = ∞

Edit

[alt / option] + [◄ home] = Jump to last word

[alt / option] + [► end] = Jump to next word

[control] + [▲ pgup] = Jump to top of the page

[control] + [pgdn ▼] = Jump to bottom of the page

[control] + [◄ home] = Jump to begin of the line

[control] + [► end] = Jump to end of the line

control + [search box 🔍]	=Switch language and typewritingspace	
⌘ cmd + **A**	=Select All	
⌘ cmd + **X**	=Cut	
⌘ cmd + **C**	=Copy	
⌘ cmd + **V**	=Paste	
⌘ cmd + **Z**	=Undo Typing	
⌘ cmd + **F**	=Find	
🌐 + **D**	=Dictation	
🌐 + **E**	=Emoji	

TOUCHPAD FUNCTION

Notice: Make sure bluetooth connected and touchpad function turned on!

- **Tap**

  Tap with a single finger until it feels a little touch feeling.

- **Drag**

  Tap and hold an item, then swipe your finger across the trackpad to move it.

- **Open Program**

  Expansion Dock

Swipe the pointer across the bottom of the screen with one finger.

- **Open Notification Center**

  Use one finger to move the pointer to select the status icons at the top left, then click.

  Or, use one finger to move the pointer past the top of the screen near the middle.

  Move Left Or Right

  Swipe left or right with two fingers.

  Open Searching

  From Home Screen

  Swipe down with two fingers.

- **View Slide Over**

  Use one finger to swipe the pointer past the right edge of the screen. To hide Slide Over, swipe right again.

  Open Control Center

  Use one finger to move the pointer to select the status icons at the top right, then click.

  Or, select the status icons at the top right, then swipe up with one finger.

  Move Up Or Down

  Swipe up or down with two fingers.

- **Tap and Hold**

  Tap and hold with a single finger.

- **Awake**

  Click the touchpad or press any key on the keyboard.

  Go To Home Screen

  Swipe the pointer across the bottom of the screen with one finger, and when the Dock appears, swipe the pointer across the bottom of the screen again.

- **Zoom**

  Place two finger's close together, open to enlarge, or pinch to zoom out.

  Open "Today" View

  When the Home or Lock screen is visible, swipe right with two fingers.

  Open APP Switcher

  Swipe up with three fingers, pause and lift your finger.

- **Secondary click**

  Click with two fingers to show the quick actions menu for items like icons on the Home Screen, messages in a mailbox, and the Camera button in Control Center.

  Or, you can press the Control key while you click the trackpad.

- **Go To Home Screen**

  Swipe up with three fingers.

- **Shift Between**

  The Open APP

  Swipe left or right with three fingers.

INSTALLATION AND REMOVAL

Installation:

1. Align iPad's bottom with the keyboard case.
2. Press and hold the middle of the upper edge of the iPad.
3. Press the top corners of the iPad to securely fit into the case.

4. Press and hold the middle of the upper edge of the iPad.

5. Push the top corners to detach the case.

6. Pull up to remove iPad.

ROTATION AND USAGE

- Rotate 360° by twisting
- Rotate 360° by twisting

WARNING

BATTERY AND CHARGING

To Check The Battery Status Of The Keyboard

Press [alt / option] + [⎵ 🔍] on the keyboard. The battery level will be indicated by the number of lit indicators.

1. battery level is between 100% and 70%

2. battery level is between 70% and 40%

3. battery level is between 40% and 10%

4. battery level is less than 10%

Note: If the keyboard has been connected to an iPad, you can also check the battery status through the iPad's battery widget.

TO CHARGE THE KEYBOARD

iPad adapters

1. Turn on the keyboard (if battery indicator is flashing, please charge the keyboard).
2. Plug the charging cable (included) into the keyboard and power adapter (not included, iPad or iPhone power adapter recommended);
    1. Battery indicator turns red when keyboard is charging;
    2. Battery indicator turns blue when charging is complete.]

TROUBLESHOOTING

If your keyboard is not functioning properly, please follow these steps to resolve the issue:

1. Ensure Bluetooth is enabled on your iPad or other Bluetooth device.
2. Verify that the keyboard is within 33 feet range.
3. Confirm that the keyboard is charged.
4. Turn on the keyboard, press [alt option] + [🔍] to check the battery level by indicator.
5. Press the 'Pair' key and check the Bluetooth connection status.
6. Ensure the keyboard has successfully paired via Bluetooth.

If you are encountering unwanted auto-correction or punctuation, follow these steps:

1. Open the Settings app > General > Keyboard > Hardware Keyboard.
2. Turn OFF the options for Auto-Capitalization, Auto-Correction, and "." shortcut (refer to the accompanying picture for reference).

If you experience difficulty pairing your keyboard via Bluetooth, please follow these steps:

1. Delete any previously paired Bluetooth devices on your iPad.
2. Turn off Bluetooth on your iPad.
3. Restart your iPad.
4. Turn on Bluetooth on your iPad.
5. Turn off and on the keyboard.
6. Repeat the pairing steps as described on page 2 and 3 of the manual.

If you're still having problems troubleshooting your keyboard, try doing a hard reset:
Hold down C+R+L on the keyboard, until the keyboard indicators begin to flash. The keyboard will be reset.

If you are encountering unwanted cursor move when typing, or some keys like 7,8,9,U,O,J,K,L cannot be entered, please Turn OFF AssistiveTouch> Mouse Keys as follows:

1. On your iPad, go to Settings > Accessibility and select Touch.
2. Select AssistiveTouch, then select Mouse Keys.
3. Turn Off Mouse Keys

PRODUCT SPECS

- **Operating distance:** 10 meters (33 feet) Modulation System: GFSK
- **Working voltage:** 3 0-4 2V
- **Working current:** 0.88-3.85mA Sleeping current:< 125µA
- **Charging current:** 500-B00mA
- **Continuous working time without backlight:** 60 hours
- **Charging time:<** 2 hours Charging voltage: 5V
- **Key's life span:** > 5 million strokes
- **Operating temperature:** -10 ±55°C

- **Maintenance:** Please preserve the keyboard under normal temperature and recharge under normal voltage.

IC CAUTION
This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions

1. This device may not cause interference, and
2. This device must accept any interference, including interference that may cause undesired operation of the device.

FCC CAUTION

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

- If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
  - Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technician for help.

RF warning for Portable devices:
The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure condition without restriction

Documents / Resources

typecase 6th Generation Touch Keyboard for iPad Pro 12.9 [pdf] User Manual
6th Generation Touch Keyboard for iPad Pro 12.9, 6th Generation Touch, Keyboard for iPad Pro 12.9, iPad Pro 12.9, Pro 12.9

References

- **User Manual**