Manuals+ — User Manuals Simplified.

velleman MONCOLHA5PN6 Monitor LCD TFT 5.6 with Remote Control User Manual

Contents

velleman MONCOLHA5PN6 Monitor LCD TFT 5.6 with Remote Control

OVERVIEW

5.6"
14cm

Introduction

To all residents of the European Union Important environmental information about this product This symbol on the device or the package indicates that disposal of the device after its lifecycle could harm the environment. Do not dispose of the unit (or batteries) as unsorted municipal waste; it should be taken to a specialized company for recycling. This device should be returned to your distributor or to a local recycling service. Respect the local environmental rules. If in doubt, contact your local waste disposal authorities. Thank you for choosing Velleman! Please read the manual thoroughly before bringing this device into service. If the device was damaged in transit, do not install or use it and contact your dealer. The MONCOLHA5PN6 features contrast, brightness, colour and volume controls. Do not forget to remove the protective foil from the display when bringing this device into service. The warranty automatically becomes void if the user personally tries to repair or modify the device. The warranty also becomes void in case of damage caused by inappropriate use or the disregard of standard safety prescriptions in general and those in this manual in particular. Velleman Group nv does not accept responsibility for personal injury caused by the disregard of the safety instructions in this manual. This also goes for all types of

consequential loss.

Safety Instructions

- This device can be used by children aged from 8 years and above, and persons withreduced physical, sensory or mental capabilities or lack of experience andknowledge if they have been given supervision or instruction concerning the use ofthe device in a safe way and understand the hazards involved. Children shall notplay with the device. Cleaning and user maintenance shall not be made by childrenwithout supervision.
- Risk of electroshock during installation. A qualified technician should install andservice this device.
- There are no user-serviceable parts inside the device. Refer to an authorized dealerfor service and/or spare parts.
- To ensure security, please do not watch the monitor while driving.

General Guidelines

- Refer to the Velleman® Service and Quality Warranty on the last pages of this manual.
- All modifications of the device are forbidden for safety reasons. Damage caused by user modifications to the device is not covered by the warranty.
- Only use the device for its intended purpose. Using the device in an unauthorised way will void the warranty.
- Damage caused by disregard of certain guidelines in this manual is not covered by the warranty and the dealer will not accept responsibility for any ensuing defects or problems.
- Nor Velleman Group nv nor its dealers can be held responsible for any damage (extraordinary, incidental or indirect) – of any nature (financial, physical…) arising from the possession, use or failure of this product.
- Keep this manual for future reference.

Overview

Refer to the illustrations on page 2 of this manual.

1	"+" button	to increase the entered values
2	menu button	to select the various adjustments
3	"-" button	to reduce the entered values
4	power button	to activate/deactivate the device
5	remote control sensor	
6	headphones connection	

Remote control

1	on/off
2	mute
3	horizontal mirror/normal
4	vertical mirror/normal
5	volume down
6	volume up
7	menu
8	analogue increase

9	analogue decrease
10	mode
11	reversing benchmark
12	screen 16:9/4:3
13	timer 0-240 min.
14	AV switchover
15	reset

Wiring

Connect the supplied cable with the monitor's mini-DIN plug:

- yellow RCA = video 1
- red RCA = video 2
- white RCA = audio (only for video 1 channel)
- black = power (pin = + ; ring = -)

Operation

Make sure the video and audio input connections are properly executed. Press 'MENU' to display the adjustments in this order: Enter the values with and The power button activates/deactivates the LCD monitor. It is not necessary to disconnect the power adapter. The speaker is switched off when headphones are connected

Cleaning and Maintenance

Before starting any cleaning or maintenance activities:

1. Unplug the device's power cord from the outlet.
2. Let the device cool down.

Cleaning

- Use normal glass cleaner and a soft cloth to wipe off the outside casing.
- Always be sure to dry all parts completely before plugging the device back in.
- Do not immerse the device in any liquid.

Technical Specifications

- display mode TFT Active Matrix System (4:3)
- screen size 5.6″
- active area 113 x 84.7 mm
- resolution   960 (H) x 234 (V)
- number of pixels 225000
- backlight cold cathode filament tube
- video input signal 1.0Vpp / 75 Ω (composite video signal)
- audio input signal 1Vpp @ 10k Ω
- audio output signal 0.5 W / 16 Ω
- power supply monitor   12 VDC ± 10 %
- power supply remote control 1 x 1.5 V CR2025 battery (incl.)
- power consumption 7 W
- built-in speaker 0.1 W / 8 Ω
- operating temperature -10 °C to +40 °C
- storage temperature -25 °C to +80 °C
- dimension 146 x 110 x 26 mm
- weight 345 g

Use this device with original accessories only. Velleman Group nv cannot be held responsible in the event of damage or injury resulting from (incorrect) use of this device. For more info concerning this product and the latest version of this manual, please visit our website **www.velleman.eu**. The information in this manual is subject to change without prior notice

Documents / Resources

MONCOLHA5PN6	**velleman MONCOLHA5PN6 Monitor LCD TFT 5.6 with Remote Control** [pdf] User Manual MONCOLHA5PN6, Monitor LCD TFT 5.6 with Remote Control, MONCOLHA5PN6 Monitor LCD TFT 5.6 with Remote Control

References

- **Velleman â€" Wholesaler and developer of electronics**