Manuals+ — User Manuals Simplified.

VIMAI EP033AH2C Wireless Microphone

VIMAI EP033AH2C Wireless Microphone User Manual

Contents

VIMAI

VIMAI EP033AH2C Wireless Microphone

Product Information

Specifications

- Compliance: Part 15 of FCC Rules
- Conditions: Must not cause harmful interference, must accept any received interference

Product Usage Instructions

Compliance Information
This device complies with part 15 of the FCC Rules. It is important to ensure that the device is operated in a manner that does not cause harmful interference to other devices. Additionally, the device must accept any interference it receives, even if it leads to undesired operation.

Modifications
Any changes or modifications to the device that are not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. It is crucial to adhere to this guideline to maintain the device's compliance and proper functioning.

FAQ

- **Q: What should I do if I encounter interference issues with the device?**

  A: If you experience interference with the device, try adjusting its placement or orientation. Additionally, ensure that there are no other electronic devices nearby causing interference. If the issue persists, contact customer support for further assistance.

- **Q: Can I make modifications to the device on my own?**

  A: No, any changes or modifications to the device should only be made if expressly approved by the party responsible for compliance. Unauthorized modifications may lead to voiding the user's authority to operate the equipment.

Product introduction

**Thank you for choosing our products.**
This product is a wireless lavalier microphone, which can provide professional-level recording output. Plug-and-play, no APP. Dual 48KH, sampling rate, support chatting together PK, reverb singing songs (stereo). Compatible with singing APP for recording songs; small but powerful.
Multiple uses:can be used for live steaming, video vlog shooting, program Interview, interview recording, video teaching and other occasions

Packing list

1. Transmitter
2. Receiver
3. Charging case (For charging case model
4. Type-C charging cable
5. user manual
6. windproof wool
7. TR5 to TRR5 adapter cable (3.5mm only)

The wireless microphone consists of two parts, the microphone transmitter, and the receiver. (As shown in the picture below)

(Type-c receiver)

(Lightning receiver)

(Microphone transmitter)

(3.5mm receiver)

Product Structure Diagram

1. Charging case indicator
2. Type-C charging port on the case
3. Microphone Indicator
4. Microphone power button
5. Microphonedip
6. Microphone metal contact
7. Microphone Type-C charging/ headphone monitoring port

Charging case   Microphone transmitter

Note

1. Please pay attention to the indicator light facing outward when putting the microphone into the charging case, otherwise it will not charge properly.
2. When putting the receiver into the charging case, please note that the indicator faces outward, otherwise it cannot be magnetized (built-in magnet) and cause the box to shake.

If the mobile phone has OTG function, please manually turn on OTG

Step 1: Open the phone "Settings" Step 2: Enter "OTG" to search Step 3: Open "OTG Connection"

Some models of OPPO may need to set up manually as below: Settings>Sound & vibration>Other settings>Default recorder>Add on

How to use the Android version

Step 1: First open the charging case, the microphone is powered on and green light flashing slowly, T ype,-C receiver no light effect

microphone green light flashing slowly

No light effect at the receiver

Step 2: Connect the Type-C receiver to the Type-C port of the phone, both the green light of the receiver and microphone are always on . Pairing Is successful. Open the camera, live video and other APP on the phone, and use the microphone to pick up sound

Microphone green
light is always on

Receiver green
light is always on

Product UI features

Charging case functions and Indicators (For charging case modal)

Function/Status	Indicator status
Charge the case	Charging: red light on, fully charged: red light off
Storage case to charge the microphone	Charging: green light flashing slowly, fully charged: green light off

Charging case power indicator	Green light on: 100%-75% Blue light on: 74%-36% Red light flashing: 35%-0%

Microphone transmitter

| Function/Status	Operation	Light effects
Power on	a.Open the top cover of the charging case b.Press the power button briefly	Green light flashes slowly
Power off	a.Close the top cover of the charging case b.Press and hold the power button for 3s	Red light on for one sec
Search for a pair	Power on	Green light flashes slowly
Paired	Search for a pair	Green light always on
Restore factory settings	Press the microphone power button 5 times in quick succession	Green light flashing fast Continuously
Turn noise reduction on/off (default noise reduction mode)	Short press the microphone power button 1 time	Off: Blue light always on On:Green light always on
Turn on mute/record	Press the microphone power button twice in succession	Mute: Blue light flashes continuously and slowly Recording: Green light is always on.
Reverb mode on/off	Three-click microphone power button to turn reverb on/off (Enter reverb with noise reduction turned off by default)	/
Charging	Place in the charging case and close the top cover (For charging case model) Plug into the Type-c charging port of the microphone	Charging: Red light always on Fully charged: Red light off

Type-c receiver

1.

| Function/Status	Operation	Light effects
Power on	Plug the device in and turn it on	Green light flashes slowly
Power off	Unplug the device and switch it off	/
Search for a pair	Automatic pairing search once power on	Green light flashes slowly
Paired	Successful pairing after power on	Green light always on
Clear pairing	Quick double click on the side pinhole button twice	Green light flashing fast Continuously

    Type-C connector

2. Receiver light indicator

3. Receiver reset key

4. Type-C charging port

How to use 105 version with Lightning head

1. **Step 1**: First open the charging case, the microphone is powered on and green light flashing slowly, Lightning receiver no light effect.

microphone green light flashing slowly

No light effect at the receiver

2. **Step 2**: Connect the Lightning receiver to the Lightning port of the phone, both the green light of the receiver and microphone are always on . Pairing is successful. Open the camera, live video and other APP on the phone, and use the microphone to pickup sound

Microphone green light is always on

Receiver green light is always on

Product UI features

Charging case functions and indicators (For charging case model)

Function/Status	Indicator status
Charge the case	Charging: red light on, fully charged: red light off
Storage case to charge the microphone	Charging: green light flashing slowly, fully charged: green light off

| Charging case power indicator	Green light on: 100%-75% Blue light on: 74%-36% Red light flashing: 35%-0%

Microphone transmitter

Function/Status	Operation	Light effects
Power on	a.Open the top cover of the charging case b.Press the power button briefly	Green light flashes slowly
Power off	a.Close the top cover of the charging case b.Press and hold the power button for 3s	Red light on for one sec
Search for a pair	Power on	Green light flashes slowly
Paired	Search for a pair	Green light always on
Restore factory settings	Press the microphone power button 5 times in quick succession	Green light flashing fast Continuously
Turn noise reduction on/off (default noise reduction mode)	Short press the microphone power button 1 time	Off: Blue light always on On:Green light always on
Turn on mute/record	Press the microphone power button twice in succession	Mute: Blue light flashes continuously and slowly Recording: Green light is always on.
Reverb mode on/off	Three-click microphone power button to turn reverb on/off (Enter reverb with noise reduction turned off by default)	/
Charging	Place in the charging case and close the top cover (For charging case model) Plug into the Type-c charging port of the microphone	Charging: Red light always on Fully charged: Red light off

Lightning receiver

Function/Status	Operation	Light effects
Power on	Plug the device in and turn it on	Green light flashes slowly
Power off	Unplug the device and switch it off	/
Search for a pair	Automatic pairing search once power on	Green light flashes slowly
Paired	Successful pairing after power on	Green light always on
Clear pairing	Quick double click on the side pinhole button twice	Green light flashing fast Continuously

1. Lightning connector
2. Receiver light indicator
3. Receiver reset key
4. Lightning charging port

How to use 3.5mm camera version

1. **Step 1**: First of all, open the charging case, the microphone and 3.5mm receiver is powered on, the microphone is always green, 3.5mm receiver is always green.

Microphone green light is always on

Receiver green light is always on

2. **Step 2**: Connect the 3.5mm receiver to the 3.5mm connector of the device, the green light of the receiver is always on, and the green light of the microphone is always on, the pairing is successful. That is, you can use the microphone .

Receiver green light is always on

Microphone green light is always on

Product UI features
Charging case functions and indicators (For charging case model)

Function/Status	Indicator status
Charge the case	Charging: red light on, Fully charged: red light off
Charge the transmitter	Charging: green light flashes slowly, Fully charged: green light off
Charge the receiver	Charging: blue light flashes slowly, Fully charged: blue light off
Simultaneously charge the transmitter and receiver	Charging: blue and green lights flash alternately, Fully charged: light off

|	
Charging case power indicator	Green light on: 100%-75% Blue light on: 74%-36% Red light flashing: 35%-0%

Microphone transmitter

Function/Status	Operation	Light effects
Power on	a.Open the top cover of the charging case b.Press the power button briefly	Green light flashes slowly
Power off	a.Close the top cover of the charging case b.Press and hold the power button for 3s	Red light on for one sec
Search for a pair	Power on	Green light flashes slowly
Paired	Search for a pair	Green light always on
Restore factory settings	Press the microphone power button 5 times in quick succession	Green light flashing fast Continuously
Turn noise reduction on/off (default noise reduction mode)	Short press the microphone power button 1 time	Off: Blue light always on On:Green light always on
Turn on mute/record	Press the microphone power button twice in succession	Mute: Blue light flashes continuously and slowly Recording: Green light is always on.
Reverb mode on/off	Three-click microphone power button to turn reverb on/off (Enter reverb with noise reduction turned off by default)	/
Charging	Place in the charging case and close the top cover (For charging case model) Plug into the Type-c charging port of the microphone	Charging: Red light always on Fully charged: Red light off

3.5mm receiver

Function/Status	Operation	Light effects
Power on	Open the charging case and power on	Green light always on
Power off	Place in the charging case and close the cover	/
Low battery alarm	Battery below 20%	Blue light flashing slowly
Search for a pair	Automatic pairing search once power on	Green light flashing slowly
Paired	Automatic pairing	Green light always on
Clear pairing	Press the reset pinhole key twice quickly	Green light flashing

1. 3.5mm connector
2. Receiver indicator light
3. Receiver reset key
4. Receiver metal contact

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Documents / Resources

	VIMAI EP033AH2C Wireless Microphone [pdf] User Manual EP033AH2C Wireless Microphone, EP033AH2C, Wireless Microphone, Microphone

References

- **User Manual**