# Manuals+

☰

**Contents** [ hide ]

# VULKK△NO

## VULKKANO A6 ARC Bookshelf Speaker

## Box Content



| | | |
|---|---|---|
| Bookshelf Speaker | Remote control | User manual |
| Audio cable | 2RCA to 2RCA cable | Stereo RCA to 3.5mm audio cable |
| Digital Optical cable | Power adapter | |

*For reasons beyond the control of the brand, the accessories may vary.

## LED Indicators and Button Introduction



| | | |
|---|---|---|
| Bookshelf Speaker | Remote control | User manual |
| Audio cable | 2RCA to 2RCA cable | Stereo RCA to 3.5mm audio cable |
| Digital Optical cable | Power adapter | |

Infrared receiver
LED indicators

**Active Speaker**

| | | |
|---|---|---|
| Standby | Bluetooth | Optical |
| Line in | ARC | USB |

1. Power switch
2. Input selection

Press in to navigate between audio sources: Bluetooth -> Optical -> Line in -> ARC -> USB

3. Sound effects

   Press in to navigate between audio sources: Music -> Dialogue -> Movie

4. Volume control

5. Treble control

6. Bass control

7. Optical input port

8. Connect a subwoofer

9. Line in input port

10. ARC input port

11. USB input port

12. Left speaker audio output

13. Power port

14. Left speaker audio in

# Know your remote



| | | | |
|---|---|---|---|
| ⏻ | Power button | MUTE | Mute/Unmute |
| VOL + | Volume up | VOL - | Volume down |
| ‹ | Previous track | › | Next track |
| ▶/‖ | Play/Pause | OPT | Optical mode |
| ARC | ARC mode | USB | USB mode |
| BT | Bluetooth mode | | |
| LINE | Line in    mode | MOVIE | Movie mode |
| MUSIC | Music mode | DIALOG | Dialogue mode |
| VB ON | Virtual bass on | VB OFF | Virtual bass off |

# Connection Diagram



- Bluetooth
- Audio cable
- Digital Optical cable

- High speed ARC cable
- Stereo RCA to 3.5mm audio cable
- USB
- Audio cable
- Power Adapter

## Connecting with a TV



1. Method 1. Connecting using an Optical cable.

   Select Optical mode and set the TV's audio output to "PCM".  (More information on PCM page)

2. Method 2. Connecting using a RCA to 3.5mm audio cable.  Select RCA mode.

3. Method 3. Connecting using an ARC cable. Select ARC mode and set the TV's audio output to "PCM". (More information on PCM page)

## Setting "PCM" on your TV

When all cables are connected properly, and LED indicator lights properly, if there is no sound from tv or Soundbar, please setting your tv as below:

1. Press "Menu" on the TV's remote control.

2. Press the arrow keys on the remote to scroll to "Audio Settings".

3. Press "OK" on the remote control.

4. Scroll to "Advanced Audio" and press "OK". Some televisions may not have an "Advanced Audio" menu and may list various audio settings instead.

5. Scroll to "Audio Output Mode" or "Digital Audio Output Mode" and press "OK".

6. Scroll until "PCM" is displayed as the current audio output.

7. Press "OK" to save the settings.

### Connecting a Bluetooth Device



- Press the "BT" button on the remote or press the  button on back panel of the active speaker, the LED indicator blinks blue.
- Turn on Bluetooth on the Bluetooth device.
- Select "VULKKANO A6 ARC" and connect it. When your Bluetooth device is connected, the LED indicator blinks blue slowly.
- Play music files from the device, connected via Bluetooth, through the bookshelf speaker.

## Specifications

| Power output: | L/R: 60W + 60W |
|---|---|
| Signal to noise ratio dB(A): | L/R: ≥80dB (A) |
| Input sensitivity: | LINE IN: R/L: 650±50mV |
| | OPT: R/L: 500±50mFFS |
| | Bluetooth: R/L: 700±50mFFS |
| Frequency response: | 30HZ-30KHZ |

| Bass unit: | 6.5 inch |
|---|---|
| Tweeter unit: | 1 inch silk dome tweeter |

## Troubleshooting

### No sound

- Check if the power indicator light is ON.
- Try to turn up the volume using either the master volume control or remote control.
- Ensure the audio cables are firmly connected and the input is set correctly on the speakers.
- Check if there is signal output from the audio source.

### Cannot connect via Bluetooth

- Make sure the speaker is switched to Bluetooth input, in other audio input mode Bluetooth can not be paired or connected. Disconnect from any Bluetooth device by press and hold the volume dial in Bluetooth mode, then try again.
- Effective Bluetooth transmission range is 10 meters, please make sure operation is within the range.
- Try another Bluetooth device for connection.

### The VULKKANO A6 ARC Bookshelf Speaker does not turn on
Check if mains power is connected or if the wall outlet is switched on.

## FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

**Warning**: Changes or modifications not expressly approved by the party responsible for

compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**FCC Radiation Exposure Statement:**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

# Documents / Resources

| | |
|---|---|
| User manual<br>VULKKANO A6 ARC | [VULKKANO A6 ARC Bookshelf Speaker](#) [[pdf](#)] User Manual<br>A6ARC, A6 ARC Bookshelf Speaker, A6 ARC, Bookshelf Speaker, Speaker |

## References

- [User Manual](#)

---

# Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

**Post Comment**

## Search:

e.g. whirlpool wrf535swhz

**Search**