Manuals+ — User Manuals Simplified.

Walmart C28 Wireless Transmitter Receiver User Manual

C28 Wireless Transmitter Receiver
User Manual

Contents

C28 Wireless Transmitter Receiver

Please read this manual carefully before use.

Package contents:

- 1 C28.
- 1 Charge Cable.
- 1 3.5mm audio head.
- User manual.

Specifications:

Life time: 4 h
Battery capacity: 140 mA
*Working range: open area up to 10 meters, without any obstacles
**"Product size:** 59.5mm (L) x 22mm (W) x 12mm (H)

RX ⇌ TX
Receiver   Transmitter

One Button Control
Easily switch between transmitter (TX) & receiver (RX) mode

Interface diagram:

1. Multifunction Botton (Power/Play/Pause).
2. Aux in/out.
3. Transmitter and Receiver Switches.
4. microphone
5. Indicator Light.
6. 5V/1A Charging port.

How To Use:

Receiver Mode

1. Use the micro USS cable to charge before use;
2. Connect the C28 to your audio device using the AUX cable;
3. Change the switch button to position RX;
4. Turn on the device(Long press in the multifunction button) then the blue light will flash quickly, indicating that is ready for pairing;
5. Find C28 in the wireless search of your phone and chose to pair.

Transmitter Mode

1. Use the micro USS cable to charge before use;
2. Connect the C28 to your audio device using the AUX cable;
3. Change the switch button to position TX;
4. Turn on the device(Long press in the multifunction button) then the red light will flash quickly, indicating that is ready for pairing;

5. Turn on the device you want to connect and the C28 will automatically connect.When the connection is successful the wireless indicator will illuminate red.

Walmart ⁑

Documents / Resources

	Walmart C28 Wireless Transmitter Receiver [pdf] User Manual C28 Wireless Transmitter Receiver, C28, Wireless Transmitter Receiver, Transmitter Receiver, Receiver

References

- **User Manual**