

ANATOMIC ELEMENTS Rechargeable Bug Zapper Racket User Manual

Home » ANATOMIC ELEMENTS » ANATOMIC ELEMENTS Rechargeable Bug Zapper Racket User Manual

Contents

- 1 ANATOMIC ELEMENTS Rechargeable Bug Zapper Racket
- **2 PRODUCT SPECIFICATIONS**
- **3 INCLUDED IN PACKAGING**
- **4 CHARGING INSTRUCTIONS**
- 5 Documents / Resources
- **6 Related Posts**



ANATOMIC ELEMENTS Rechargeable Bug Zapper Racket



Before using this product for the first time, please read through these instructions and keep them for future reference.

CAUTION

- Do not touch the metal net surface with hand or hanheld metal objects. Do not use it as a toy for children.
- Do not use near flammable gas or liquids, do not use metal and other conductive materials in the metal mesh it may cause a spark.
- Do not use in barns, cabins, or similar places with animals or electric sensitive structures.
- When not in use, turn the power switch to the "OFF" position.
- Do Not Rinse with water or wipe with a wet towel. Keep electric mosquitoes dry so as not to damage the electronic component.
- Please charge the battery when it runs out, don't use it when the product is not charged. If not used
 consistently, make sure to at least recharge the battery for about 4 hours every three months to preserve the
 battery life.
- Please do not beat other hard objects, so as not to damage the metal mesh surface.

PRODUCT SPECIFICATIONS

• Size of the product itself: 530x220x 85mm

• Net weight of the product itself: 350g x 2pcs=700g

• Single package size: 521x223x64mm

• Net weight of the product including package: 950g

Material: ABS

• Specification Rating: 2W Light Power (0.1W)

• Operating Temperature: -10°C -45°C

• Rated charging voltage: AC 220V / 50Hz

• Net Shooting Output Voltage: 3000V

• Broadcasting seat rating input: DC5V 1A

- Can Kill Mosquitoes or other flying insects in a single swing.
- Circuit board new technology IC double protection function can help prevent transition charge and transition discharge, protecting the lithium battery.
- **High-quality Environmental Protection Material:** The whole body of the racket is made of high-quality ABS plastics.
- Three-Layer Mesh Protection: Using high-quality nickel-plated iron and aluminum mesh, this provides a safety net in case one accidentally touches the top zapping portion of the racket.
- Battery: Built in as a lithium-ion battery. Compact size with a capacity up to 1200mAh.
- Safety Switch: Activate or deactivates the power for high security and safe storage.
- **Mosquito Lamp Mode:** When Power switches to "", The Purple Light will always on, and the light will release 395-400mm wavelengths which will attract mosquitos. When you sleep, you can put the bug zapper on the holder, it will attract mosquitoes and kill it.

INCLUDED IN PACKAGING

- 2x Rechargeable Bug Zapper Rackets
- 1x USB Charging Cable
- 1x Electric Mosquito Swatter Stand & Holder 1x User
- Manual

CHARGING INSTRUCTIONS

There are three different charging methods:

- 1. Connect the USB charging cord to your device and then to a mobile phone adapter, then plug into socket.
- 2. Connect the USB charging cord to your device and then to a battery/power bank.
- 3. Connect the USB charging cord to your device and then to a power strip with USB outlets.

NOTE: When charging your device, make sure to first switch the power to OFF (the charging indicator light will illuminate). Full charging time is approximately 10 hours.

HOW TO USE

- Chare the device for 6-8 hours prior to first use (see charging instructions above).
- 2. There are two usage methods for this device:
 - Manual Mosquito Elimination: Turn the power switch to "ON1". Press and hold the zap activation button
 located above the power switch. The working light will illuminate to indicate that the device is active. Aim
 and swing the racket towards mosquitos to eliminate them. Take caution when handling, as the voltage of

the net may be active. Switch the power back to OFF once finished using. (Total Usage Time with a Fully Charged Battery: Approx. 45-60 Days [using the device 2-3 times a day])

- Mosquito Lamp Mode: Place the product on its stand/base. Turn the power switch to "bulb icon".
- The built-in purple LED light will illuminate and remain lit in this mode, releasing 395-400mm
 wavelengths that will help attract mosquitos, eliminating them upon contact with the net. Switch the
 power back to OFF once finished using. (Total Usage Time with a Fully Charged Battery: Approx. 10
 hours)

LIMITED LIFETIME WARRANTY

Your Anatomic Elements product is backed by a limited lifetime manufacturer's warranty. Anatomic Elements will repair or replace your device at any time should it fail due to a defect in material or workmanship, subject to the certain limitations. This limited warranty does not cover any damage that results fromunauthorized or improper use, service, or repair. Further, it does not cover damage caused by accident, impact, negligence, or normal wear and tear. Should you discover your Anatomic Elements product is not functioning properly, please send your device to our repair center for evaluation. If your product cannot be repaired or serviced, we will reserve the right to change it for a similar or newer model. Please note that a flat rate of \$11.00 will be charged to cover a service evaluation fee and return shipping of your device. All warranty claims must be accompanied by a copy of your proof of purchase from an authorized retailer. Please send your device, proof of purchase, and a check or money order in the amount of \$11.00 made out to Anatomic Elements to:

Address:

Anatomic Elements Service Center 3069 Taft Street Hollywood, FL 33021

Contact:

warranty@anatomicelements.com

Documents / Resources



ANATOMIC ELEMENTS Rechargeable Bug Zapper Racket [pdf] User Manual Rechargeable Bug Zapper Racket, Rechargeable Bug, Zapper Racket

Manuals+,