



# Androidex JG-PL5000 Atomizing Sterilizer Instructions

[Home](#) » [Androidex](#) » Androidex JG-PL5000 Atomizing Sterilizer Instructions 

## Androidex Atomizing sterilizer instructions

Thank you for buying our products Please read the product instruction carefully before use Please use correctly and safely

### Contents

- [1 Specific operation](#)
- [2 Cleaning and maintenance](#)
- [3 Documents / Resources](#)
- [4 Related Posts](#)

### Specific operation

1. Please open the package to confirm the product and its accessories
2. Match the lower shell with the base, and rotate clockwise to lock it
3. Turn the handle screw into position
4. Match the upper shell with the lower shell, and lock it by clockwise rotation
5. Put the product in a flat position and power it on
6. Open the lid and add 5L water from the top
7. After adding water, use tweezers to add special tablets for disinfection from above
8. Connect the power adapter and power it on
9. The voltage shall be 100V~240V(50Hz/ 60Hz)
10. Touch the power switch to turn on the product

### Cleaning and maintenance

1. Before cleaning, be sure to cut off the power and unplug the power plug

- FCC ID: 2AXMKJG-PL5000