

[Manuals.plus](#) /

> [Homedics](#) /

> HoMedics BMAT-5 Bubble Spa Bath Mat Massager User Manual

Homedics BMAT-5

HoMedics BMAT-5 Bubble Spa Bath Mat Massager User Manual

Model: BMAT-5

INTRODUCTION

The HoMedics BMAT-5 Bubble Spa Bath Mat Massager is designed to transform any standard bathtub into a relaxing bubble massage spa. This unit provides a soothing experience with adjustable settings for massage duration, strength, and bubble patterns. Its soft, air-filled mat adheres securely to your tub, delivering invigorating bubbles for a truly spa-like experience at home.

Key features include:

- Converts any bathtub quickly into a bubble-massage spa.
- Operates with both touch-pad controls and a cordless remote control.
- Offers 15-, 30-, or 60-minute timer options.
- Features 3 bubble speeds and 3 massage strengths.
- Soft mat fills with air to cushion the body and adheres with suction cups.
- Mat measures approximately 47 by 14 inches.



Figure 1: HoMedics BMAT-5 Bubble Spa Bath Mat Massager packaging, illustrating the product in use and its key components.

SAFETY INFORMATION

Please read all instructions carefully before using this product. Failure to do so may result in injury or damage to the unit.

- Do not immerse the control unit in water. It is designed to be placed outside the bathtub.
- Ensure the power cord is not pinched or placed in a position where it could be tripped over.
- Always unplug the unit from the electrical outlet immediately after using and before cleaning.
- Do not operate if the cord or plug is damaged, if it is not working properly, or if it has been dropped or damaged.
- Keep the unit away from heated surfaces.
- This product is for household use only. Do not use outdoors.

- Consult your doctor before using if you have any medical conditions, especially if you are pregnant, have a pacemaker, or have any concerns regarding your health.
- Do not stand on the mat. Use only while seated or lying in the bathtub.

SETUP INSTRUCTIONS

Follow these steps to set up your HoMedics Bubble Spa Bath Mat Massager:

1. **Position the Control Unit:** Place the main control unit on a flat, stable surface outside the bathtub, ensuring it is not in a position where it could fall into the water. The power cord is approximately 14 feet long, allowing for flexible placement.
2. **Place the Bath Mat:** Unroll the PVC bath mat and place it inside your bathtub. The mat features suction cups on the underside. Press firmly on the mat to ensure all suction cups adhere securely to the tub surface.
3. **Connect the Air Hose:** Attach one end of the flexible air hose to the air outlet on the control unit. Attach the other end of the air hose to the inlet on the bath mat. Ensure both connections are secure. The hose is approximately 14 feet long and includes a suction cup to help secure it to the tub wall if desired.
4. **Install Remote Control Batteries:** The cordless remote control operates with two 3-volt batteries, which are included. Open the battery compartment on the remote and insert the batteries, observing the correct polarity. Close the compartment securely. The remote can be stored in its holder, which adheres to a wall or tub with a suction cup.
5. **Plug In:** Once the mat and hose are securely in place and the control unit is safely positioned, plug the control unit's power cord into a standard electrical outlet.



Figure 2: Main components of the Bubble Spa Elite, showing the remote, control unit, and mat.

OPERATING INSTRUCTIONS

Your HoMedics Bubble Spa can be operated using either the LED-illuminated touch pad on the control unit or the cordless remote control.



Figure 3: The control unit's touchpad with various settings.

Using the Touch Pad or Remote Control:

- **Power On/Off:** Press the 'POWER' button to turn the unit on or off.
- **Set Duration:** Select your desired massage duration by pressing the 'TIMER' button. Options typically include 15, 30, or 60 minutes. The unit will automatically shut off after the selected time.
- **Adjust Massage Strength:** Use the 'STRENGTH' button to cycle through low, medium, or high massage intensity settings.
- **Control Bubble Speed:** Press the 'SPEED' button to choose between low, medium, or high bubble output.
- **Select Bubble Pattern:** The unit may offer different bubble patterns (e.g., steady bubbles or three variable patterns). Use the 'PROGRAM' button to cycle through these options for varied massage sensations.



Figure 4: The remote control provides convenient access to all functions.

For optimal performance, ensure the air hose is free from kinks and the mat is fully submerged in water during operation.

MAINTENANCE

Proper maintenance will ensure the longevity and optimal performance of your HoMedics Bubble Spa.

- **Cleaning the Mat:** After each use, rinse the bath mat thoroughly with clean water. You may use a mild soap if necessary. Ensure all soap residue is removed.
- **Drying the Mat:** Allow the mat to air dry completely before storing. Hang it or lay it flat in a well-ventilated area. Do not store the mat while it is damp.
- **Cleaning the Control Unit:** Wipe the control unit with a soft, damp cloth. Do not use abrasive cleaners or immerse the unit in water.
- **Storage:** When not in use, store the unit in a cool, dry place. The mat can be rolled up for easy storage.
- **Hose Care:** Periodically check the air hose for any kinks, cracks, or blockages. Ensure it is clean and clear for unrestricted airflow.

TROUBLESHOOTING

If you experience issues with your HoMedics Bubble Spa, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Unit does not turn on.	Not plugged in; power outlet issue; unit malfunction.	Ensure power cord is securely plugged into a working outlet. Try a different outlet. If problem persists, contact customer support.
No bubbles or weak bubbles.	Air hose kinked or disconnected; mat not properly submerged; air intake blocked.	Check that the air hose is securely connected and free of kinks. Ensure the mat is fully submerged in water. Check for any obstructions at the air intake on the control unit.
Remote control not working.	Dead batteries; remote out of range; interference.	Replace batteries in the remote control. Ensure you are within close proximity to the control unit. Remove any potential sources of interference.
Water temperature cools quickly.	Air being pumped into the tub is ambient temperature.	This unit does not heat the air. To maintain water temperature, you may need to add warmer water periodically or use the unit for shorter durations.

If you encounter a problem not listed here, or if the suggested solutions do not resolve the issue, please contact HoMedics customer support.

SPECIFICATIONS

- **Model:** BMAT-5
- **Brand:** HoMedics
- **Material:** Polyvinyl Chloride (PVC)
- **Mat Dimensions:** Approximately 47 x 14 inches
- **Power:** 600 watts (for bubble delivery)
- **Control Unit Power Cord Length:** Approximately 14 feet
- **Air Hose Length:** Approximately 14 feet

- **Remote Control Batteries:** 2 x 3-volt batteries (included)
- **UPC:** 031262006356
- **ASIN:** B000063TL2

WARRANTY AND SUPPORT

Warranty: The HoMedics BMAT-5 Bubble Spa Bath Mat Massager carries a two-year limited warranty against defects from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use. It does not cover damage caused by misuse, abuse, accident, attachment of any unauthorized accessory, alteration to the product, or any other conditions whatsoever that are beyond the control of HoMedics.

Customer Support: For warranty claims, technical assistance, or any questions regarding your product, please contact HoMedics Customer Service. Refer to the contact information provided in your product packaging or visit the official HoMedics website for the most current support details.

