

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Honda](#) /
- › [Honda EU3000 2-Wheel Kit & Telescoping Handle Instruction Manual](#)

Honda 06425-ZS9-020AH

Honda EU3000 2-Wheel Kit & Telescoping Handle Instruction Manual

INTRODUCTION

This manual provides instructions for the proper assembly, installation, and use of the Honda EU3000 2-Wheel Kit & Telescoping Handle. This kit is designed to enhance the portability of your Honda EU3000 generator, featuring lightweight, durable construction, easy-opening telescoping stainless steel handles, and rubber-dampened pre-assembled base with 8-inch industrial-rated rubber wheels.

SETUP AND INSTALLATION

Before beginning installation, ensure your Honda EU3000 generator is turned off, cooled, and disconnected from any power sources. For safety, it is recommended to have assistance when lifting or maneuvering the generator.

Kit Components Overview

Familiarize yourself with all components included in the wheel kit before assembly.



Figure 1: All components of the Honda EU3000 2-Wheel Kit and Telescoping Handle laid out for assembly. This includes the main frame with wheels, the telescoping handle assembly, and various fasteners.

Assembly Steps

1. **Prepare the Generator:** Place the Honda EU3000 generator on a stable, elevated surface or on its side to access the underside for wheel kit attachment. Ensure the fuel tank cap is securely closed to prevent spills.
2. **Attach the Wheel Frame:** Align the pre-assembled wheel frame with the designated mounting points on the bottom of the generator. Secure the frame using the provided bolts and washers. Ensure all fasteners are tightened securely according to the torque specifications in your generator's main manual, if available.
3. **Install the Telescoping Handles:** Attach the telescoping handle assembly to the upper rear section of the generator frame. These handles typically slide into existing slots or attach with bolts. Ensure they are firmly secured and can extend and retract smoothly.
4. **Verify Installation:** Once all components are attached, gently test the stability of the generator with the new wheel kit. Ensure all wheels rotate freely and the handles extend and retract without obstruction.



Figure 2: A Honda EU3000 generator with the 2-wheel kit and telescoping handle fully installed, ready for transport.

OPERATING INSTRUCTIONS

The 2-wheel kit and telescoping handle are designed to make moving your EU3000 generator easier and safer.

1. **Extend Handles:** To move the generator, grasp the telescoping handles and pull them outwards until they lock into their extended position.
2. **Tilt and Roll:** Gently tilt the generator backward using the extended handles until the weight rests on the two wheels. This allows you to roll the generator to your desired location.
3. **Retract Handles:** Once the generator is in place, push the handles back into their retracted position for compact storage and to prevent accidental snagging.
4. **Secure Placement:** Always ensure the generator is placed on a flat, stable surface before operation.

MAINTENANCE

Regular maintenance ensures the longevity and proper function of your wheel kit.

- **Inspect Wheels:** Periodically check the 8-inch rubber wheels for wear, damage, or debris accumulation. Clean as necessary.
- **Check Fasteners:** Ensure all bolts and screws securing the wheel frame and handles remain tight. Re-tighten if any looseness is detected.
- **Lubricate Handles:** If the telescoping handles become stiff, apply a small amount of silicone-based lubricant to the sliding mechanisms.
- **Clean Components:** Wipe down the metal and rubber components with a damp cloth to remove dirt and grime. Avoid harsh chemicals that could damage finishes.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Wheels do not roll smoothly.	Debris in wheel bearings; damaged wheel.	Clean wheels and axles. Inspect for damage and replace if necessary.
Handles are difficult to extend/retract.	Dirt or corrosion in telescoping mechanism; lack of lubrication.	Clean handles and apply silicone lubricant.
Kit feels unstable or loose.	Loose mounting bolts.	Check and tighten all mounting bolts securely.

SPECIFICATIONS

- **Model Numbers:** 06425-ZS9-020AH, 06425-ZS9-010AH
- **Compatibility:** Honda EU3000iS Generator
- **Wheel Size:** 8-inch industrial-rated rubber wheels
- **Handle Type:** Telescoping stainless steel
- **Construction:** Durable, lightweight materials with rubber dampening
- **Item Weight:** 25.2 pounds
- **Package Dimensions:** 31 x 23.25 x 10 inches
- **Manufacturer:** Honda

WARRANTY INFORMATION

This product is covered by Honda's standard accessory warranty. For specific details regarding warranty coverage, duration, and claims procedures, please refer to the warranty documentation included with your purchase or visit the official Honda Power Equipment website. Keep your proof of purchase for warranty validation.

SUPPORT AND CONTACT

For technical assistance, replacement parts, or further inquiries regarding your Honda EU3000 2-Wheel Kit & Telescoping Handle, please contact Honda Power Equipment customer support. You can find contact information, including phone numbers and online support resources, on the official Honda Power Equipment website or in your generator's main owner's manual.

Official Honda Power Equipment Website: powerequipment.honda.com

