



[Manuals.plus](#) /

› [NoCry](#) /

› NoCry OverSpecs+ Safety Glasses Instruction Manual

NoCry OverSpecs+

NoCry OverSpecs+ Safety Glasses Instruction Manual

Model: OverSpecs+

1. INTRODUCTION

Thank you for choosing NoCry OverSpecs+ Safety Glasses. These glasses are designed to provide superior eye protection while comfortably fitting over most prescription eyeglasses. They feature anti-scratch lenses, integrated side shields, adjustable temples, and 100% UV protection, meeting ANSI Z87.1 certification standards.



Image 1.1: NoCry OverSpecs+ Safety Glasses, designed to fit over prescription glasses.

2. SAFETY INFORMATION

Your safety is paramount. These NoCry OverSpecs+ Safety Glasses are engineered to provide robust protection in various work environments.

- **ANSI Z87.1 Certified:** These safety glasses meet the American National Standards Institute (ANSI) Z87.1 standard for impact protection, ensuring they can withstand significant impact. They are also OSHA approved.
- **UV400 Protection:** The lenses block up to 100% of harmful UVA and UVB radiation, protecting your eyes from sun exposure.
- **Wraparound Design:** The wraparound lens design provides comprehensive protection against impacts from the front and sides.
- **Integrated Side Shields:** Additional side shields offer enhanced lateral protection.



Image 2.1: Demonstrating impact protection with ANSI Z87.1 and OSHA certification.

Always ensure your safety glasses are clean and free from damage before use. Replace immediately if any damage is observed.

3. SETUP AND FITTING

Proper fitting ensures maximum comfort and protection. The NoCry OverSpecs+ are designed to fit over most standard prescription glasses.

3.1 Checking Compatibility with Prescription Glasses

These safety glasses are designed to fit comfortably over standard frames up to:

- **Width:** 5.7 inches (14.5 cm)
- **Height (sides):** 1.37 inches (3.5 cm)
- **Height (center):** 1.77 inches (4.5 cm)

OVERSPECS+ DIMENSIONS



Suitable for all types of prescription glasses



**OVER RECTANGLE
GLASSES**



**OVER SQUARE
GLASSES**



**OVER ROUND
GLASSES**

Image 3.1: Dimensions and compatibility guide for fitting over prescription glasses.

3.2 Adjusting the Temples

The temples (arms) of the safety glasses are adjustable to achieve a secure and comfortable fit.

1. Gently extend or retract the temple arms to match the length required for your head size.
2. The soft tips on the temples are designed to reduce pressure behind your ears, enhancing comfort during prolonged use.



Image 3.2: Adjustable arms and soft tips for a comfortable fit.

4. OPERATING INSTRUCTIONS

To use your NoCry OverSpecs+ Safety Glasses:

1. Ensure your prescription glasses are clean and properly positioned on your face.
2. Place the NoCry OverSpecs+ Safety Glasses over your prescription glasses, ensuring they sit comfortably and securely.
3. Adjust the temples as needed to prevent slipping or discomfort. The safety glasses should not obstruct your vision or cause pressure points.
4. Verify that the side shields fully cover the sides of your eyes for complete protection.



Image 4.1: Proper wearing of safety glasses over prescription eyewear.

5. MAINTENANCE AND CARE

Proper maintenance extends the life and effectiveness of your safety glasses.

5.1 Cleaning

- Clean lenses regularly with mild soap and water.
- Use a soft, lint-free cloth to dry the lenses. Avoid abrasive materials or harsh chemicals, as these can damage the anti-scratch coating.
- Do not use paper towels or clothing, as they can scratch the lenses.

5.2 Storage

- Store the safety glasses in a clean, dry place away from direct sunlight and extreme temperatures.
- Consider using a protective case to prevent scratches when not in use.



Image 5.1: Highlighting the scratch-resistant and UV protective lens technology.

6. TROUBLESHOOTING

If you encounter issues with your NoCry OverSpecs+ Safety Glasses, consider the following:

- **Discomfort or Pressure:** Adjust the extendable temple arms to find a more comfortable fit. Ensure the soft tips are positioned correctly behind your ears.
- **Poor Fit Over Prescription Glasses:** Double-check the dimensions of your prescription glasses against the compatibility guidelines in Section 3.1. If your prescription glasses exceed these dimensions, the safety glasses may not fit properly.
- **Obstructed Vision:** Ensure the safety glasses are seated correctly and not pressing against your prescription lenses. Clean both sets of lenses if vision remains unclear.
- **Fogging:** While these glasses are designed to minimize fogging, in certain conditions, it may occur. Ensure there is adequate airflow around the glasses.

If problems persist, please contact NoCry customer support.

7. SPECIFICATIONS

Feature	Detail
Manufacturer	NoCry
Part Number	NCSOG-5X7-BO
Item Weight	1.28 ounces
Product Dimensions	10.2 x 6.1 x 2.16 inches
Model Number	OverSpecs+
Material	Polycarbonate
Color	Black & Orange
Style	Over-glasses Safety Glasses
Finish	Scratch-resistant, UV-protection
UV Protection	Yes
Special Features	Flexible, Lightweight, Abrasion Resistant, Anti-Fog, Adjustable
Certifications	ANSI Z87.1, OSHA approved

8. WARRANTY AND SUPPORT

NoCry stands behind the quality of its products.

8.1 Limited Lifetime Warranty

Each NoCry non-electric product is warranted to be free of defects in material and workmanship for as long as the consumer owns the product. This warranty does not cover normal wear and tear, environmental factors, accidental damage, or misuse. At NoCry’s discretion, a defective product will be repaired or replaced.

This warranty gives you specific legal rights, but may be superseded by any other rights or warranties in effect, which may vary from state to state.

8.2 Customer Support

If you are not satisfied with your NoCry product or believe it may be defective, please contact us within 30 days of receiving it to arrange a return for a replacement or alternative resolution.

- **Email:** wecare@nocry.com
- **Website for more information:** <https://nocry.com/warranty>