

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [FiiO](#) /

› [FiiO F9 In-Ear Monitors User Manual](#)

FiiO F9

FiiO F9 In-Ear Monitors User Manual

Model: F9

1. IMPORTANT SAFETY INFORMATION

Please read and understand all safety instructions before using this product. Keep this manual for future reference.

- **Hearing Protection:** Avoid listening at high volume levels for extended periods to prevent hearing damage.
- **Traffic Safety:** Do not use earphones while driving, cycling, or operating machinery where the inability to hear ambient sounds could be dangerous.
- **Water and Moisture:** While the FiiO F9 has some water resistance, it is not fully waterproof. Do not immerse the earphones in water or expose them to excessive moisture.
- **Cleaning:** Clean the earphones with a soft, dry cloth. Do not use liquid cleaners or aerosols.
- **Disassembly:** Do not attempt to disassemble or modify the earphones. This will void the warranty and may cause damage.
- **Choking Hazard:** Keep small parts, such as ear tips, away from children and pets to prevent choking hazards.

2. PACKAGE CONTENTS

Verify that all items are present in your FiiO F9 package:

- FiiO F9 In-Ear Monitors (1 pair)
- 3.5mm single-ended cable with in-line remote and microphone (1)
- 2.5mm balanced cable (1)
- Assorted silicone ear tips (multiple pairs)
- Waterproof carrying case (1)
- User Manual (this document)





Image: FiiO F9 In-Ear Monitors shown with both the 3.5mm single-ended cable (with remote) and the 2.5mm balanced cable, along with various ear tips and a carrying case.

3. PRODUCT OVERVIEW

The FiiO F9 In-Ear Monitors feature a hybrid triple-driver design, combining one dynamic driver with two balanced armature drivers for a wide frequency response and detailed sound. The aluminum alloy shell provides durability and a premium feel. The detachable cable design allows for easy replacement and upgrade.



Image: A close-up view of the FiiO F9 Black In-Ear Monitor earpiece, highlighting its ergonomic design and over-ear cable routing.

Key Features:

- Hybrid Triple Driver Design (1 Dynamic + 2 Balanced Armature)
- Detachable MMCX Cable Design
- Includes both 3.5mm single-ended and 2.5mm balanced cables
- Aluminum Alloy Construction
- Over-ear wearing style for secure fit
- Android compatible in-line remote and microphone on 3.5mm cable



Image: The FiiO F9 In-Ear Monitor with its cable, accompanied by the Hi-Res Audio certification logo, indicating its capability to reproduce high-resolution audio.

4. SETUP AND CONNECTION

4.1 Choosing Ear Tips

Selecting the correct ear tips is crucial for optimal sound quality and comfort. Experiment with the various sizes and types provided to find the best fit for your ears. A good seal ensures proper bass response and noise isolation.

4.2 Attaching the Cable

The FiiO F9 uses standard MMCX connectors for its detachable cables. Ensure the cable is correctly oriented before connecting.

1. Identify the left (L) and right (R) earpieces and cable connectors.
2. Align the MMCX connector on the cable with the receptacle on the earpiece.
3. Push firmly until you feel a click. Do not twist forcefully.
4. To detach, grip the earpiece and the cable connector firmly, then pull straight apart. Avoid pulling on the cable itself.



Image: A detailed view of the FiiO F9 earpiece, illustrating the connection point for the detachable MMCX cable. The gold ring indicates the connection area.

4.3 Wearing the Earphones

The FiiO F9 is designed for an over-ear wearing style for a secure and comfortable fit.

1. Insert the earpieces into your ear canals.
2. Loop the cable over and behind your ears. The pre-formed ear hooks on the cable will help secure them in place.
3. Adjust the cable cinch (if present) to keep the cables tidy behind your head.

5. OPERATING INSTRUCTIONS

5.1 Connecting to Audio Source

Connect the 3.5mm or 2.5mm jack of the cable to the corresponding audio output port of your device (e.g., smartphone, digital audio player, amplifier).

- Use the 3.5mm cable for standard audio devices.
- Use the 2.5mm balanced cable with compatible balanced audio outputs for potentially improved sound quality and power.

5.2 Using the In-line Remote (3.5mm cable only)

The 3.5mm cable includes an in-line remote and microphone, compatible with most Android devices. Functionality may vary with different devices and operating systems.

- **Play/Pause:** Press the center button once.
- **Next Track:** Press the center button twice quickly.
- **Previous Track:** Press the center button three times quickly.
- **Answer/End Call:** Press the center button once during a call.
- **Volume Control:** Use the '+' and '-' buttons to adjust volume.
- **Microphone:** The built-in microphone allows for hands-free calls.

6. MAINTENANCE AND CARE

Proper care will extend the lifespan of your FiiO F9 In-Ear Monitors.

- **Cleaning Ear Tips:** Remove ear tips and clean them with mild soap and water. Ensure they are completely dry before reattaching.
- **Cleaning Earpieces:** Gently wipe the earpieces with a soft, dry, lint-free cloth. Do not use harsh chemicals.
- **Cable Care:** Avoid sharp bends or excessive pulling on the cables. When storing, coil the cables loosely.
- **Storage:** When not in use, store the earphones in the provided carrying case to protect them from dust, dirt, and physical damage.
- **Moisture:** Keep the earphones away from extreme temperatures and high humidity.

7. TROUBLESHOOTING

If you encounter issues with your FiiO F9, refer to the following common problems and solutions:

Problem	Possible Solution
No sound or sound from only one side	Ensure the cable is securely connected to both the earpieces and the audio source. Check the audio source's volume level and mute settings. Test with a different audio source or cable. Verify that the ear tips are not blocked by debris.
Poor sound quality (e.g., weak bass, tinny sound)	Ensure a proper seal with the ear tips. Try different sizes or types. Check the audio source's equalizer settings. Ensure the cable is fully inserted into the audio source.
In-line remote/microphone not working	Ensure you are using the 3.5mm cable with the remote. Verify compatibility with your specific device. Some functions may not work on all operating systems. Check for any software updates for your audio source device.
Cable detaches easily	Ensure the MMCX connectors are pushed in firmly until they click. Inspect the MMCX connectors on both the cable and earpiece for damage.

8. SPECIFICATIONS

Technical specifications for the FiiO F9 In-Ear Monitors:

Feature	Detail
Model	F9
Driver Type	Hybrid (1 Dynamic + 2 Balanced Armature)
Frequency Response	15 Hz - 40 kHz
Impedance	28 Ω
Sensitivity	106 dB/mW
Cable Connectors	MMCX detachable
Included Cables	3.5mm single-ended with remote/mic, 2.5mm balanced
Material	Aluminum
Weight	23 Grams (0.811 ounces)
Ear Placement	In Ear, Over Ear (wearing style)
Control Type	In-line remote (on 3.5mm cable)

9. WARRANTY AND SUPPORT

FiiO products typically come with a limited warranty. For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official FiiO website.

For technical support, service, or further inquiries, please contact FiiO customer service or visit the FiiO official store page:

[Visit the FiiO Store on Amazon](#)