

[Manuals.plus](#) /

> [Fresca](#) /

> Fresca Tiempo 24x30 Inch Wall Mount Medicine Cabinet with Dimmable LED Lights - User Manual

## Fresca Tiempo

# Fresca Tiempo 24x30 Inch Wall Mount Medicine Cabinet with Dimmable LED Lights - User Manual

Model: Tiempo (FMC012430-R)

## IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before installation and use. Retain this manual for future reference.

- Always keep the door open within a safe angle to prevent it from swinging back and causing injury.
- Ensure proper wall support and use appropriate safety measures when installing the cabinet to avoid damage or injury.
- Installation should be performed by a qualified professional if you are unsure about electrical connections or wall mounting procedures.
- Disconnect power at the circuit breaker before performing any electrical work.
- Do not expose the cabinet to excessive moisture or direct water spray.
- Avoid using abrasive cleaners or sharp objects on the mirror surface or frame.

## PRODUCT OVERVIEW

The Fresca Tiempo Medicine Cabinet is designed to provide functional storage and enhanced lighting for your bathroom. It features a frameless mirrored door, integrated dimmable LED task lighting, an anti-fog mirror, and an internal electrical/USB outlet. The interior includes three adjustable glass shelves and a mirrored back wall.



Image 1: Front view of the Fresca Tiempo medicine cabinet with LED lights illuminated and the digital clock displaying time.

## PACKAGE CONTENTS

---

Verify that all components are present before beginning installation:

- Fresca Tiempo Medicine Cabinet (1 unit)
- Adjustable Glass Shelves (3 units)
- Mounting Hardware (screws, anchors, etc. - specific types may vary)
- Instruction Manual (this document)

## SPECIFICATIONS

---

<b>Dimensions (W x H x D)</b>	23 5/8" x 29 1/2" x 4 7/8" (60cm x 75cm x 12.4cm)
<b>Frame Material</b>	IP44 Rated Anodized Aluminum
<b>Mirror Type</b>	5mm Copper Free Silver Mirrors
<b>Hinge Type</b>	BLUM Hinges (170-degree swing, Right Hinge)
<b>Lighting</b>	High Output Dimmable LED (Surface Task Light), Interior LED Light
<b>Special Features</b>	Defogger with Touch Switch, Digital Clock, Electrical / USB Outlet Combo, Infrared Touch Switch for Interior LED Light
<b>Number of Shelves</b>	3 (Adjustable Glass)
<b>Weight</b>	Approximately 50 lbs (22.7 kg)

## SETUP AND INSTALLATION

This medicine cabinet is designed for wall-mount installation. Professional installation is recommended, especially for electrical connections.

### Tools and Materials Required (Not Included):

- Measuring tape
- Pencil
- Level
- Drill with appropriate drill bits
- Screwdriver (Phillips and/or flathead)
- Wire strippers (for electrical connection)
- Safety glasses

### Installation Steps:

- 1. Prepare the Wall:** Identify the desired mounting location. Ensure there are no hidden electrical wires or plumbing. Use a stud finder to locate wall studs for secure mounting, if possible. If mounting to drywall without studs, use appropriate heavy-duty wall anchors (not always included).
- 2. Mark Mounting Points:** Hold the cabinet against the wall at the desired height and use a level to ensure it is straight. Mark the locations for the mounting screws.
- 3. Drill Pilot Holes:** Drill pilot holes at the marked locations. If using wall anchors, install them according to their instructions.
- 4. Electrical Connection:**
  - **WARNING:** Disconnect power at the main circuit breaker before proceeding with electrical connections.
  - Route the electrical wiring from the wall opening to the cabinet's junction box.
  - Connect the cabinet's wires to the household electrical supply wires (typically black to black, white to white, and ground to ground) using appropriate wire connectors.
  - Ensure all connections are secure and insulated.
- 5. Mount the Cabinet:** Carefully lift the cabinet and align the mounting holes with the drilled holes/anchors. Secure the

cabinet to the wall using the provided screws. Do not overtighten.

6. **Install Shelves:** Insert the shelf pins into the desired slots inside the cabinet. Place the glass shelves onto the pins.
7. **Restore Power:** Once installation is complete and all connections are secure, restore power at the circuit breaker.



Image 2: Interior view of the medicine cabinet showing the adjustable glass shelves and mirrored back wall.

## OPERATING INSTRUCTIONS

### 1. Dimmable LED Task Lighting

The cabinet features integrated LED lighting on the mirror surface. This light is controlled by a touch switch located on the mirror.

- **To Turn On/Off:** Lightly touch the power icon on the mirror surface.
- **To Dim:** Press and hold the power icon. The light intensity will cycle through its dimming range. Release when the desired brightness is achieved.



Image 3: The medicine cabinet installed in a bathroom, demonstrating the illuminated LED task lighting.

## 2. Anti-Fog Mirror (Defogger)

The anti-fog feature helps keep the mirror clear in steamy bathroom conditions. It is activated by a separate touch switch.

- **To Activate/Deactivate:** Lightly touch the defogger icon on the mirror surface. An indicator light may illuminate when active.
- For optimal performance, activate the defogger a few minutes before showering or bathing.

## 3. Digital Clock

The integrated digital clock displays the time. Refer to the specific instructions provided with the cabinet for setting the time, as this may vary slightly by production batch.

## 4. Electrical / USB Outlet Combo

An electrical outlet and USB charging port are located inside the cabinet for convenient power access for devices such as electric toothbrushes, shavers, or other small electronics.

- Ensure the cabinet door is fully open when plugging or unplugging devices to prevent obstruction.
- Do not overload the outlet. Refer to the electrical specifications for maximum wattage.



Image 4: Interior of the cabinet showing stored items, adjustable shelves, and the internal electrical/USB outlet.

## 5. Adjustable Glass Shelves

The three glass shelves can be adjusted to different heights to accommodate various item sizes.

- To adjust, carefully remove items from the shelf. Lift the shelf slightly and pull it out.
- Relocate the shelf pins to the desired slots.
- Reinsert the glass shelf onto the pins, ensuring it is level and secure.

## MAINTENANCE

### Cleaning the Mirror and Frame:

- Use a soft, damp cloth with a mild, non-abrasive glass cleaner or water.
- Wipe dry immediately with a clean, lint-free cloth to prevent water spots.
- Do not spray cleaner directly onto the mirror or frame; apply it to the cloth first.
- Avoid cleaners containing ammonia, vinegar, or abrasive particles, as these can damage the mirror coating or frame finish.

### Cleaning the Interior:

- Remove shelves for easier cleaning.
- Wipe interior surfaces with a soft, damp cloth and mild soap, then dry thoroughly.
- Clean glass shelves with glass cleaner and a soft cloth.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
LED lights do not turn on.	No power supply; loose electrical connection; faulty touch switch.	Check circuit breaker. Verify electrical connections ( <i>power off first!</i> ). Contact customer support if issue persists.
Anti-fog feature not working.	Defogger not activated; electrical issue.	Ensure defogger touch switch is activated. Check power supply.
Digital clock is blank or incorrect.	Power interruption; clock not set.	Reset and set the clock according to specific instructions (if provided separately). Check power supply.
Electrical/USB outlet not providing power.	No power supply; internal wiring issue.	Check circuit breaker. Ensure cabinet is properly wired. Test with another device.
Door does not close properly.	Hinges misaligned; obstruction.	Check for obstructions. Adjust hinges if necessary (refer to hinge manufacturer's instructions if available).

## WARRANTY INFORMATION

Fresca products are manufactured to high-quality standards. For specific warranty details regarding your Fresca Tiempo medicine cabinet, please refer to the warranty card included with your purchase or visit the official Fresca website. Keep your proof of purchase for warranty claims.

## CUSTOMER SUPPORT

If you have any questions, require technical assistance, or need to report a missing or damaged part, please contact Fresca customer support:

- **Website:** [www.frescabath.com](http://www.frescabath.com) (Note: This is a placeholder URL, please verify the actual Fresca support website)
- **Email:** Refer to the Fresca website for contact email.
- **Phone:** Refer to the Fresca website for contact phone number.

When contacting support, please have your model number (FMC012430-R) and purchase date available.



